

(RG50V3G-010K)

CONTENTS

◆ RGV3101040000 REEL ASSEMBLY.....	1
◆ RGV3201000000K THRESHING BODY ASSEMBLY.....	9
◆ RGV1503040000K DUST REMOVAL COVER ASSEMBLY.....	26
◆ RGV1705040000K ELECTRICAL ASSEMBLY OF ENGINE.....	32
◆ RGV3106020000K LEFT DIVIDER ASSEMBLY.....	35
◆ RGV3107020000K DIVIDER ASSEMBLY, RIGHT.....	38
◆ RGV3410010000K HANDLE THROTTLE ASSEMBLY.....	41
◆ RGV3301010000K GRAIN CLIMB MACHINE ASSEMBLY.....	44
◆ RGV3102040000K HEADER ASSEMBLY.....	52
◆ RV01103030000 CUTTER ASSEMBLY.....	66
◆ RGV3104000000K REEL BRACKET ASSEMBLY.....	76
◆ RGV3105030000 FEEDING AUGER ASSEMBLY.....	80
◆ RGV3412010000K CLUTCH CONTROL ASSEMBLY.....	88
◆ RGV3413020000K UNLOADING CLUTCH CONTROL.....	94
◆ RGV3214000000K MAIN ENGINE TRANSMISSION ASSEMBLY.....	98
◆ RGV3402020000K DRIVING AXLE ASSEMBLY.....	101
◆ RGV3302010000K TAILING AUGER ASSEMBLY.....	134
◆ RGV3202010000 CYLINDER COVER ASSEMBLY.....	144
◆ RGV3205010000K AXIAL FLOW ROLLER ASSEMBLY.....	148
◆ RGV3208050000 SIEVE BOX ASSEMBLY.....	155
◆ RGV3209020000 FAN ASSEMBLY.....	175


◆ RGV1702090000K ELECTRICAL ASSEMBLY OF BODY.....	182
◆ RV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY.....	185
◆ RGV3403020000K CHASSIS FRAME ASSEMBLY.....	199
◆ RGV3303050000K GRAIN TANK ASSEMBLY.....	203
◆ RGV3603250000 MULTI-WAY VALVE ASSEMBLY.....	215
◆ RGV3401020000K WHEEL SYSTEM ASSEMBLY.....	228
◆ RGV3504030000K FUEL SUPPLY COMBINATION.....	243
◆ RGV3406000000 SPEED CHANGING CONTROL ASSEMBLY.....	250
◆ RGV3407060000 STEPLESS SPEED CHANGING CONTROL ASSEMBLY.....	253
◆ DV01409010000 PARKING BRAKE.....	256
◆ DV01411000000 FLAMEOUT MECHANISM.....	262
◆ DV01416000000 HEADER CLUTCH CONTROL ASSEMBLY.....	265
◆ RGV3405010000K STEERING LIFTING CONTROL UNIT.....	268
◆ RGV3305010000K UNLOADING BOTTOM AUGER ASSEMBLY.....	272
◆ RGV3502000000K RADIATOR ASSEMBLY.....	279
◆ RGV3505000000K MANIFOLDS & INDUCTION SYSTEM.....	283
◆ D1681. 53 FIRE EXTINGUISHER.....	286
◆ RV03601020000 HEADER HYDRAULIC PRESSURE ASSEMBLY.....	289
◆ RV03602000000 STEERING HYDRAULIC PRESSURE ASSEMBLY.....	292
◆ RGV4604000000 STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY.....	295
◆ RGV1306050000K UNLOADING CANISTER ASSEMBLY.....	298
◆ RV03605000000 HYDRAULIC PRESSURE ASSEMBLY OF GEAR PUMP.....	318
◆ RGV3506130000K EXHAUST SYSTEM.....	321
◆ RGV1703010000 ELECTRICAL ASSEMBLY OF GRAIN BOX.....	324

◆ DV01704000000 HARNESS ASSEMBLY.....	327
◆ RGV3706050000 ACCUMULATOR ASSEMBLY.....	330
◆ RGV3709020000 AWNING FAN ASSEMBLY.....	333
◆ RGV1701100000K ELECTRICAL ASSEMBLY OF CAB.....	336
◆ RGV3801020000K AWNING ASSEMBLY.....	340
◆ RGV3108010000K BRIDGE ASSEMBLY.....	343
◆ RGV3803000000 SEAT INSTALLATION ASSEMBLY.....	361
◆ RGV3804010000 COVER ASSEMBLY.....	364
◆ RGV3805000000 REARVIEW MIRROR ASSEMBLY.....	370
◆ RV01806000000a REAR TAIL LADDER ASSEMBLY.....	373
◆ RGV3802030000K DRIVER' S PANEL ASSEMBLY.....	376

LOVOL

zsj D13750


RGV3101040000 REEL ASSEMBLY-1



RGV3101040000 REEL ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3101040000	REEL ASSEMBLY	001	1	
1	DV01101000005	CROSS PIN		2	
2	Q50114	LOCK PIN		2	
3	RGV3101040001	REEL WHEEL ASSEMBLY		1	
3.1	RGV3101040002	REEL ASSEMBLY		1	
3.2	RGV3101040004	ANTI ENTANGLEMENT TUBE		3	
3.3	RGV3101040003	ANTI ENTANGLEMENT TUBE		2	
3.4	CBT3496-JZ300GS	TIE		15	

RGV3101040000 REEL ASSEMBLY-2



RGV3101040000 REEL ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3101040002	REEL ASSEMBLY		1	
	RGV3101040001	REEL WHEEL ASSEMBLY		1	
	RGV3101040000	REEL ASSEMBLY		1	
1	DV01101000003	PULL MUSCLE		15	
2	RV01101000003	ECCENTRIC WHEEL SPOKE PLATE WELDMENT		1	
3	GBT889. 1-M8-8-A2L	HEXAGON LOCK NUTS WITH NON-METALLIC INSERT TYPE 1		30	
4	DG2002. 1-02	REEL SHAFT SEAT		15	
5	GBT97. 1-8-A3L	FLAT WASHERS		30	
6	GBT93-8-A3L	STANDARD SPRING WASHER		30	
7	GBT5782-M8X100-8. 8-A2L	HEX HEAD BOLTS		30	
8	DV01101000046	SPOKE PLATE		1	
9	RV03101040002	REEL TINE SHAFT ASSEMBLY 1		2	
9.1	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		14	
9.2	GBT93-8-A3L	STANDARD SPRING WASHER		14	
9.3	DV01101030008	SPRING TOOTH , TORSION SPRING TYPE		14	
9.4	GBT794-M8X40-8. 8	REINFORCED ROUND HEAD SQUARE NECK BOLTS		14	
9.5	RV03101040003	REEL TINE SHAFT WELDMENT 1		1	
10	RV03101040006	REEL TINE SHAFT ASSEMBLY 2		3	
10.1	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		14	
10.2	GBT93-8-A3L	STANDARD SPRING WASHER		14	
10.3	DV01101030008	SPRING TOOTH , TORSION SPRING TYPE		14	
10.4	GBT794-M8X40-8. 8	REINFORCED ROUND HEAD SQUARE NECK BOLTS		14	

RGV3101040000 REEL ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
10.5	RV03101040007	REEL TINE SHAFT WELDMENT 2		1	
11	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		9	
12	GBT93-10-A3L	STANDARD SPRING WASHER		10	
13	GBT97.1-10-A3L	FLAT WASHERS		6	
14	GBT12-M10X25-8.8-A3L	BOLT		6	
15	GBT5786-M16X1.5X40-8.8-A3L	HEX HEAD BOLTS		1	
16	GBT93-16-A3L	STANDARD SPRING WASHER		1	
17	GBT97.1-16-A3L	FLAT WASHERS		2	
18	GBT6171-M18X1.5-8-A3L	TYPE 1 HEX NUT		1	
19	GBT93-18-A3L	STANDARD SPRING WASHER		1	
20	GBT97.1-18-A3L	FLAT WASHERS		1	
21	RV03101020009	PULLEY		1	
22	DG2002.1-01	SLEEVE		4	
23	DV01101000029	WELDED RIGHT BEARING SEAT		1	
24	RV03101020007	ECCENTRIC ADJUSTING DISC WELDMENT		1	
25	DG2002.1-03	ROLLING WHEEL		3	
26	GBT96.1-10-A3L	LARGE WASHER		3	
27	DV02101000009	REEL SHAFT WELDMENT		1	
28	RV01101000001	SPOKE PLATE		1	
29	DV01101000004	RETAINING RING		1	
30	GBT5786-M10X1.25X30-8.8-A2L	HEX HEAD BOLTS		1	
31	GBT6170-M6-8-A2L	TYPE 1 HEX NUT		4	

RGV3101040000 REEL ASSEMBLY-2 (cont'd.)


No.	Part No.	Description	Version	QTY.	Remark
32	GBT93-6-A3L	STANDARD SPRING WASHER		4	
33	GBT97.1-6-A3L	FLAT WASHERS		8	
34	GBT5783-M6X20-8.8-A2L	HEXAGON BOLT		4	
35	RGV4101030005	ANTIWRAP BOARD		2	
36	RGV4101030006	PRESSURE PLATE		2	
37	GBT1096-8X7X45	FLAT KEY		1	
38	DV01101000048	WELDED LEFT BEARING SEAT		1	

LOVOL
zsj D13750

LOVOL

zsj D13750

RGV3201000000K THRESHING BODY ASSEMBLY-1



RGV3201000000K THRESHING BODY ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3201000000K	THRESHING BODY ASSEMBLY	001	1	
1	GBT5783-M6X20-8. 8-A2L	HEXAGON BOLT		4	
2	GBT93-6-A3L	STANDARD SPRING WASHER		12	
3	GBT97. 1-6-A3L	FLAT WASHERS		4	
4	DG2007. 12-06	SEAL PRESSNESS PLATE		1	
5	DG2007. 12-05	SEAL PLATE		1	
6	RGV3201060001g	ENGINE BLOCK		1	
7	GBT5783-M8X25-8. 8-A2L	HEX HEAD BOLTS		1	
8	GBT97. 1-8-A3L	FLAT WASHERS		5	
9	RV01201000100	PULLEY BRACKET WEDMENT		1	
10	GBT93-8-A3L	STANDARD SPRING WASHER		11	
11	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		1	
12	GBT96. 1-8-A3L	LARGE WASHER		1	
13	GBT16674. 1-M12X25-8. 8-A3L	HEX FLANGE BOLTS		2	
14	GBT894. 1-20	RETAINING RING FOR SHAFT		2	
15	GBT97. 1-20-A3L	FLAT WASHERS		1	
16	RGV3201060093a	TENSIONER ASSEMBLING		1	
16. 1	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	
16. 2	JBT7940. 1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
16. 3	GBT894. 1-20	RETAINING RING FOR SHAFT		1	
16. 4	GBT893. 1-47	RETAINING RING FOR HOLE		2	
16. 5	RGV3201060097	TENSION WHEEL WELDMENT		1	
16. 6	GBT276-6204-RS	DEEP GROOVE BALL BEARING		2	

RGV3201000000K THRESHING BODY ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
16.7	RGV3201060094a	SUPPORTING ARM		1	
16.7.1	DV01201010006	SLEEVE		1	
16.7.2	RGV3201060095b	ARM WELDMENT		1	
16.8	RGV3201060187	TENSION SPRING		1	
16.9	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		2	
16.10	DG2002.12.6b-02	ADJUSTING BOLT 2		1	
17	GBT62-M8-A2L	BUTTERFLY NUT		6	
18	RGV3201060077	LEFT HOLE COVER		1	
19	DV01102000149	DUSTPROOF CAP OF OIL CUP		3	
20	JBT7940.1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		3	
21	GBT894.1-25	RETAINING RING FOR SHAFT		1	
22	RGV3201060084	PULLEY INSTALLATION		1	
22.1	GBT893.1-52	RETAINING RING FOR HOLE		1	
22.2	GBT276-6205-RS	DEEP GROOVE BALL BEARING		1	
22.3	DG2002.12.10-02	SPACER		1	
22.4	GBT276-6005-RS	DEEP GROOVE BALL BEARING		1	
22.5	RGV3201060082	PULLEY		1	
22.6	GBT93-8-A3L	STANDARD SPRING WASHER		4	
22.7	GBT5783-M8X16-8.8-A2L	HEX HEAD BOLTS		4	
22.8	RGV3201060115	PULLEY FITTINGS		1	
22.8.1	RGV3201060083	REVERSE WHEEL		2	
22.8.2	GBT5783-M8X16-8.8-A2L	HEX HEAD BOLTS		6	


RGV3201000000K THRESHING BODY ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
22.8.3	GBT93-8-A3L	STANDARD SPRING WASHER		6	
22.8.4	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		6	
23	RGV3201000001K	TENSION WHEEL INSTALLATION 2		1	
23.1	GBT894.1-15	RETAINING RING FOR SHAFT		1	
23.2	DV01201030009	TENSIONER COMBINATION		1	
23.2.1	DG2002.12.6a.2-01	TENSIONER		1	
23.2.2	DG2002.12.6a.2-02	HUB		1	
23.2.3	RGV1903160006K	BEARING		1	
23.2.4	GBT893.1-35	RETAINING RING FOR HOLE		1	
23.3	RGV3201060088	SUPPORTING ARM		1	
23.3.1	RGV3201060087	ARM WELDMENT		1	
23.3.2	DG2002.12.6a-01	SLEEVE		1	
23.4	RGV3201060255	TENSION SPRING		1	
23.5	DG2002.12.6b-02	ADJUSTING BOLT 2		1	
23.6	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		2	
24	GBT894.1-15	RETAINING RING FOR SHAFT		1	
25	DG2002.12.9	TENSIONER ASSEMBLING		1	
25.1	DG2002.12.9-01	TENSIONER		1	
25.2	GBT276-6302-2RS	DEEP GROOVE BALL BEARING		1	
25.3	GBT893.1-42	RETAINING RING FOR HOLE		1	
26	GBT5783-M10X30-8.8-A3L	HEX HEAD BOLTS		11	
27	GBT97.1-10-A3L	FLAT WASHERS		20	

RGV3201000000K THRESHING BODY ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
28	GBT93-10-A3L	STANDARD SPRING WASHER		13	
29	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		9	
30	GBT16674.1-M6X16-8.8-A2L	HEX FLANGE BOLTS		8	
31	RGV3201060130	SEAL PLATE		1	
32	DG2002.12.2.3-02a	PRESSURE PLATE		1	
33	GBT6170-M6-8-A2L	TYPE 1 HEX NUT		6	
34	DG2007.12.5	REINFORCED PLATE		1	
35	GBT16674.1-M12X30-8.8-A3L	HEX FLANGE BOLTS		2	

RGV3201000000K THRESHING BODY ASSEMBLY-2



RGV3201000000K THRESHING BODY ASSEMBLY-2


No.	Part No.	Description	Version	QTY.	Remark
	RGV3201000000K	THRESHING BODY ASSEMBLY		1	
1	GBT5786-M12X1.5X55-8.8-A3L	HEX HEAD BOLTS		2	
2	GBT6171-M12X1.5-8-A3L	TYPE 1 HEX NUT		2	
3	GBT6173-M12X1.5-05-A3L	HEXAGON THIN NUT		2	
4	GBT97.1-12-A3L	FLAT WASHERS		1	
5	DV01201000187	SUPPORT WELD		1	
6	RGV3108010019	WASHER		1	
7	GBT6170-M16-8-A3L	TYPE 1 HEX NUT		2	
8	GBT6172.1-M16-04-A3L	HEXAGON THIN NUT		1	
9	DV01201000188	PAD		2	
10	GBT93-16-A3L	STANDARD SPRING WASHER		1	
11	GBT62-M8-A2L	BUTTERFLY NUT		6	
12	GBT93-8-A3L	STANDARD SPRING WASHER		11	
13	GBT62-M6-A2L	BUTTERFLY NUT		2	
14	GBT93-6-A3L	STANDARD SPRING WASHER		12	
15	GBT96.1-6-A3L	LARGE WASHER		2	
16	RV01201000154	AIR ADJUSTING BAFFLE 2		2	
17	RV01201000186	LEFT AIR REGULATOR WELDING		1	
18	RV01201000185	RIGHT WIND ADJUSTING PLATE		1	
19	DV01102000149	DUSTPROOF CAP OF OIL CUP		3	
20	JBT7940.1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		3	
21	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		6	
22	DV01201000119	SIEVE BOX SEAT PLATE		2	

RGV3201000000K THRESHING BODY ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	RGV3201060161	CURTAIN BAFFLE		1	
24	RGV3201060231	PRESSURE PLATE WELDMENT		1	
25	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		4	
26	RGV3201060225	COVER		1	
27	GBT5783-M10X60-8. 8-A3L	HEX HEAD BOLTS		2	
28	GBT93-10-A3L	STANDARD SPRING WASHER		13	
29	GBT96. 1-10-A3L	LARGE WASHER		2	
30	GBT16674. 1-M6X16-8. 8-A2L	HEX FLANGE BOLTS		8	
31	DV01201010008	PRESSURE PLATE		2	
32	DV01201010007	RETAINER		1	
33	RGV3201000002K	TENSIONER ASSEMBLING		1	
33. 1	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		2	
33. 2	GBT894. 1-15	RETAINING RING FOR SHAFT		1	
33. 3	DG2002. 12. 6b-02	ADJUSTING BOLT 2		1	
33. 4	D20012. 5-05	SPRING		1	
33. 5	RGV3201060248	SUPPORTING ARM WELDED PART		1	
33. 6	GBT276-6004-RS	DEEP GROOVE BALL BEARING		2	
33. 7	DV01201000234	RETAINING RING		1	
33. 8	GBT893. 1-42	RETAINING RING FOR HOLE		1	
33. 9	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	
33. 1 0	JBT7940. 1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
33. 1 1	RGV3201000003K	TENSIONER COMBINATION		1	

LOVOL
zsj D13750

RGV3201000000K THRESHING BODY ASSEMBLY-3



RGV3201000000K THRESHING BODY ASSEMBLY-3


No.	Part No.	Description	Version	QTY.	Remark
	RGV3201000000K	THRESHING BODY ASSEMBLY		1	
	RGV3201060001g	ENGINE BLOCK		1	
1	RV03804020011	FIXINGBRACKET		1	
2	GBT16674. 1-M8X20-8. 8-A2L	HEX FLANGE BOLTS		4	
3	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		1	
4	GBT16674. 1-M10X20-8. 8-A3L	HEX FLANGE BOLTS		2	
5	RV03804020010	BRACKET WELDMENT		2	
6	GBT6177. 1-M10-8-A3L	HEXAGON FLANGE NUT		2	
7	RV01201000102	CONNECTION PLATE		1	
8	GBT16674. 1-M8X25-8. 8-A2L	HEX FLANGE BOLTS		1	
9	RV03804020078	LEFT FRONT LOWER SHIELD FRONT BUCKLE SUPPORT		1	
10	GBT16674. 1-M6X20-8. 8-A2L	HEX FLANGE BOLTS		10	
11	RV03804020077	CONNECTING PLATE WELDMENT		1	
12	RV03804020070	SUPPORT BRACKET WELDING		1	
13	RV03804020069a	BRACKET WELDMENT		1	
14	RV03804020082	BUCKLE SUPPORT WELDING		2	
15	GBT16674. 1-M6X12-8. 8-A2L	HEX FLANGE BOLTS		8	
16	RV03804020071a	FIXINGBRACKET		1	
17	RV03201020007a	REAR SHIELD		1	
18	GBT16674. 1-M8X12-8. 8-A2L	HEX FLANGE BOLTS		2	
19	RGV3804000001	BACK BUCKLE SUPPORT		1	
20	DV01201080002	FEED PLATE WELDMENT		1	

RGV3201000000K THRESHING BODY ASSEMBLY-3 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
21	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		8	
22	GBT93-8-A3L	STANDARD SPRING WASHER		11	
23	GBT97. 1-8-A3L	FLAT WASHERS		8	
24	RV03201000600	CONCAVE ASSEMBLY		1	
25	RGV3303040046a	FIXING SEAT WELDMENT		1	
26	GBT5783-M10X25-8. 8-A3L	HEX HEAD BOLTS		4	
27	GBT93-10-A3L	STANDARD SPRING WASHER		4	
28	GBT96. 1-10-A3L	LARGE WASHER		4	
29	GBT5783-M8X16-8. 8-A2L	HEX HEAD BOLTS		3	
30	RV03201000045	GUIDE PLATE		1	
31	RGV3201060055	WELDING OF AIR GUIDE PLATE		1	
32	RGV3201060051	WELDING OF AIR GUIDE PLATE		1	
33	RGV3201060002g	CYLINDER BLOCK		1	
34	RGV3804080002	FIXINGBRACKET		1	

LOVOL
ZSJ D13750

RGV3201000000K THRESHING BODY ASSEMBLY-4



RGV3201000000K THRESHING BODY ASSEMBLY-4


No.	Part No.	Description	Version	QTY.	Remark
	RGV3201000000K	THRESHING BODY ASSEMBLY		1	
	RGV3201060001g	ENGINE BLOCK		1	
1	RV03201000600	CONCAVE ASSEMBLY		1	
1.1	RV03201000601	FRONT CONCAVE WELDMENT		2	
1.2	RV03201000602	REAR CONCAVE WELDMENT		2	
1.3	GBT5783-M8X25-8. 8-A2L	HEX HEAD BOLTS		8	
1.4	GBT93-8-A3L	STANDARD SPRING WASHER		8	
1.5	GBT97. 1-8-A3L	FLAT WASHERS		8	
1.6	GBT5782-M10X65-8. 8-A3L	HEX HEAD BOLTS		4	
1.7	DV01206000019	CONNECTION PLATE		4	
1.8	GBT6183. 1-M10-8-A3L	LOCKING NUT		4	
1.9	DV01206000022	CONNECTING PLANK		4	
2	DV01201080002	FEED PLATE WELDMENT		1	
2.1	DV01201000107	LEFT PLATE		1	
2.2	RGV3201060211	PLATE		1	
2.3	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		3	
2.4	GBT93-8-A3L	STANDARD SPRING WASHER		3	
2.5	GBT97. 1-8-A3L	FLAT WASHERS		6	
2.6	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		3	

LOVOL

zsj D13750

LOVOL
ZSJ D13750


RGV1503040000K DUST REMOVAL COVER ASSEMBLY-1



RGV1503040000K DUST REMOVAL COVER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1503040000K	DUST REMOVAL COVER ASSEMBLY	001	1	
1	BA150B2. 6. 7	HANDLE		1	
2	RGV1503040001K	WATER TANK BONNET		1	
3	GBT97. 1-10-A3L	FLAT WASHERS		2	
4	GBT5789-M8X16-8. 8-A2L	HEX FLANGE BOLTS		6	
5	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		4	
6	RGV3503060003	AGRAFFE		2	
7	RV01503110026	WIRE COMBINATION		1	
8	GBT97. 1-8-A3L	FLAT WASHERS		2	
9	GBT91-3. 2X14-A3L	COTTER PIN		2	
10	GBT5789-M8X20-8. 8-A2L	HEX FLANGE BOLTS		2	
11	DV01503010012	REAR CONNECTING SEAT WELDED PART		1	
12	DV01503000016	CONNECTING PLATE		1	
13	RGV3503010001	ENGINE SHIELD ASSEMBLY		1	
14	GBT16674. 1-M8X20-8. 8-A2L	HEX FLANGE BOLTS		4	

RGV1503040000K DUST REMOVAL COVER ASSEMBLY-2




RGV1503040000K DUST REMOVAL COVER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV1503040000K	DUST REMOVAL COVER ASSEMBLY		1	
	RGV3503010001	ENGINE SHIELD ASSEMBLY		1	
1	BA150B2. 6. 7	HANDLE		2	
2	RGV1503040001K	WATER TANK BONNET		6	
3	GBT97. 1-10-A3L	FLAT WASHERS		3	
4	GBT5789-M8X16-8. 8-A2L	HEX FLANGE BOLTS		2	
5	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		1	
6	RGV3503060003	AGRAFFE		2	
7	RV01503110026	WIRE COMBINATION		1	
8	GBT97. 1-8-A3L	FLAT WASHERS		2	
9	GBT91-3. 2X14-A3L	COTTER PIN		2	
10	GBT5789-M8X20-8. 8-A2L	HEX FLANGE BOLTS		3	
11	DV01503010012	REAR CONNECTING SEAT WELDED PART		1	
12	DV01503000016	CONNECTING PLATE		1	

LOVOL
ZSJ D13750

RGV1705040000K ELECTRICAL ASSEMBLY OF ENGINE

LOVOL
ZSJ D13750




RGV1705040000K ELECTRICAL ASSEMBLY OF ENGINE

No.	Part No.	Description	Version	QTY.	Remark
	RGV1705040000K	ELECTRICAL ASSEMBLY OF ENGINE	001	1	
1	RGV1705040001K	ENGINE HARNESS ASSEMBLY		1	
1.1	CE4R1808030006	FOUR WAY FUSE BOX		1	
1.2	RGV4706000005	TIGHTEN TYPE FUSE 80A		2	
1.3	RGV1705040002K	ENGINE HARNESS		1	
2	GF38B1. 29. 3-01	RPM SENSOR		1	
3	GBT5789-M10X25-8. 8-A3L	HEX FLANGE BOLTS		2	
4	RGV1705020002	GROUNDING WIRE		1	
5	DV01603000010	PLASTIC FASTENING STRIP		11	
6	FT800A. 48L. 106	HARNESS CLAMP		1	
7	RGV1705030003	CONNECTING WIRE		1	
8	GK30A6. 29. 3-01	WATER TEMPERATURE SENSOR		1	
9	GBT6177. 1-M10-8-A3L	HEXAGON FLANGE NUT		1	

RGV3106020000K LEFT DIVIDER ASSEMBLY

LOWVOLT
ZSJ D13750





RGV3106020000K LEFT DIVIDER ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3106020000K	LEFT DIVIDER ASSEMBLY	001	1	
1	GBT5783-M12X25-8.8-A3L	HEX HEAD BOLTS		2	
2	GBT93-12-A3L	STANDARD SPRING WASHER		2	
3	GBT97.1-12-A3L	FLAT WASHERS		2	
4	DV01106010001	LEFT BRACKET WELDMENT		1	
5	GBT97.1-10-A3L	FLAT WASHERS		6	
6	GBT93-10-A3L	STANDARD SPRING WASHER		6	
7	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		4	
8	GBT93-8-A3L	STANDARD SPRING WASHER		4	
9	GBT97.1-8-A3L	FLAT WASHERS		4	
10	GBT5783-M10X30-8.8-A3L	HEX HEAD BOLTS		3	
11	DV01106010006	DIVIDER BAR WELDMENT		1	
12	RGV3106020001K	LH SPIKE-SPLITTER WELDED PART		1	
13	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		4	
14	GBT96.1-8-A3L	LARGE WASHER		4	
15	GBT5783-M10X20-8.8-A3L	HEX HEAD BOLTS		3	

RGV3107020000K DIVIDER ASSEMBLY, RIGHT

LOVOL
ZSJ D13750




RGV3107020000K DIVIDER ASSEMBLY, RIGHT

No.	Part No.	Description	Version	QTY.	Remark
	RGV3107020000K	DIVIDER ASSEMBLY, RIGHT	001	1	
1	GBT5783-M12X25-8.8-A3L	HEX HEAD BOLTS		2	
2	GBT93-12-A3L	STANDARD SPRING WASHER		2	
3	GBT97.1-12-A3L	FLAT WASHERS		2	
4	RGV3107020001K	RH SPIKE-SPLITTER WELDED PART		1	
5	GBT97.1-10-A3L	FLAT WASHERS		6	
6	GBT93-10-A3L	STANDARD SPRING WASHER		7	
7	GBT5783-M10X20-8.8-A3L	HEX HEAD BOLTS		3	
8	GBT5783-M10X25-8.8-A3L	HEX HEAD BOLTS		1	
9	GBT96.1-10-A3L	LARGE WASHER		1	
10	DV01107010006	KNIFE HEAD BONNET WELDMENT		1	
11	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		5	
12	GBT93-8-A3L	STANDARD SPRING WASHER		5	
13	GBT97.1-8-A3L	FLAT WASHERS		5	
14	RGV1107020001K	RIGHT BRACKET WELDMENT		1	
15	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		4	
16	GBT96.1-8-A3L	LARGE WASHER		4	
17	GBT5783-M10X30-8.8-A3L	HEX HEAD BOLTS		3	

RGV3410010000K HANDLE THROTTLE ASSEMBLY

LOVOL
ZSJ D13750




RGV3410010000K HANDLE THROTTLE ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3410010000K	HANDLE THROTTLE ASSEMBLY	001	1	
1	GBT6172. 1-M14-04-A3L	HEXAGON THIN NUT		2	
2	GBT97. 1-14-A3L	FLAT WASHERS		3	
3	DV01410000001	SPRING		2	
4	DG2001. 34-01	HANDLESLEEVE		1	
5	DV01410000005	HANDLE WELDMENT		1	
6	GBT16674. 1-M6X16-8. 8-A2L	HEX FLANGE BOLTS		3	
7	RGV3410010001K	SEAT WELDMENT		1	
8	DV01410000009	FOOT THROTTLE WIRE ASSEMBLY		1	
9	GBT882-B6X16-A3L	PIN		1	
10	GBT97. 1-6-A3L	FLAT WASHERS		1	
11	GBT91-1. 6X12-A3L	COTTER PIN		1	

LOVOL
ZSJ D 13750

RGV3301010000K GRAIN CLIMB MACHINE ASSEMBLY-1




RGV3301010000K GRAIN CLIMB MACHINE ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3301010000K	GRAIN CLIMB MACHINE ASSEMBLY	004	1	
1	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		12	
2	RV01302010017K	END COVER		1	
3	GBT93-8-A3L	STANDARD SPRING WASHER		19	
4	RV01302010011K	BEARING SEAT		1	
5	RGV3301010005K	INSTALLATION SEAT		1	
6	GBT5783-M8X30-8.8-A2L	HEX HEAD BOLTS		6	
7	RGV3301010009K	VERTICAL COVER WELDMENT		1	
8	DV01301000065	GRAIN MOUTH SEAL STRIP		2	
9	GBT96.1-8-A3L	LARGE WASHER		4	
10	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		7	
11	GBT5783-M8X25-8.8-A2L	HEX HEAD BOLTS		2	
12	GBT97.1-8-A3L	FLAT WASHERS		9	
13	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	
14	RGV4301000009K	Grain box assembly		1	
15	RGV3301010001K	VERTICAL AUGER		1	
15.1	HE2001.17.2a-06	BALANCING BLOCK		1	
15.2	GBT12-M8X20-8.8-A2L	BOLT		4	
15.3	DG2003.17-04	VANE		2	
15.4	GBT889.1-M8-8	HEXAGON LOCK NUTS WITH NON-METALLIC INSERT TYPE 1		4	
15.5	RGV3301010002K	VERTICAL AUGER WELDMENT		1	

RGV3301010000K GRAIN CLIMB MACHINE ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
16	GBT3882-UE205	BEARING		1	
17	JBT7940.1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		1	

RGV3301010000K GRAIN CLIMB MACHINE ASSEMBLY-2



RGV3301010000K GRAIN CLIMB MACHINE ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3301010000K	GRAIN CLIMB MACHINE ASSEMBLY		1	
1	RGV3301000018a	GRAIN HORIZONTAL AUGER INSTALLATION		1	
1.1	RGV3301000003	HORIZONTAL AUGER WELDMENT		1	
1.2	GBT1096-C8X7X32	FLAT KEY		1	
1.3	RGV3301000019	BEARING BLOCK		1	
1.4	GBT893. 1-52	RETAINING RING FOR HOLE		1	
1.5	RV01302000140	BEARING		1	
1.6	DH1381. 21. 3-02	ADJUSTMENT MATS		3	
1.7	RV01301000018	DRIVE BELT PULLEY		1	
1.8	BZF0002. 1-100	ADJUSTING GASKET		1	
1.9	GBT93-14-A3L	STANDARD SPRING WASHER		1	
1.10	GBT6170-M14-8-A3L	TYPE 1 HEX NUT		1	
2	RGV4301000009K	Grain box assembly		1	
2.1	GBT9877. 1-FB35X52X8D	ROTARY SHAFT LIP SEAL WITH INNER FRAME		2	
2.2	GBT893. 1-52	RETAINING RING FOR HOLE		2	
2.3	RV01302000140	BEARING		2	
2.4	RGV3301000048	ADJUSTING WASHER		2	
2.5	RV01301000040	15 TEETH BEVEL GEAR		2	
2.6	BZF0086-201	SCREW PLUG M18X1. 5		1	
2.7	RGV3301000036	Grain transmission box		1	
2.8	RGV3301000044	INSPECTION WINDOW		1	
2.9	RGV3301000037	INSPECTION WINDOW		1	
2.10	GBT97. 1-8-A3L	FLAT WASHERS		2	


RGV3301010000K GRAIN CLIMB MACHINE ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
2. 11	GBT93-8-A3L	STANDARD SPRING WASHER		2	
2. 12	GBT5783-M8X16-8. 8-A2L	HEX HEAD BOLTS		2	

LOVOL
ZSJ D13750

LOVOL
ZSJ D13750

RGV3102040000K HEADER ASSEMBLY-1




RGV3102040000K HEADER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3102040000K	HEADER ASSEMBLY	011	1	
1	DV01102000100	PRESSURE PLATE WELDMENT 1		2	
2	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		6	
3	DV01102000102	PRESSURE PLATE WELDMENT 2		1	
4	RV01104010002	CHAIN 122/08B		1	
5	RGV4102030006K	TENSION ORGANIZATION ASSEMBLY		1	
6	GBT5789-M10X20-8.8-A3L	HEX FLANGE BOLTS		8	
7	DV01102000103	PRESSURE PLATE 1		1	
8	RGV3102040001d	HEADER WELDMENT		1	
9	DV01102030043	COVER WELDMENT		1	
10	GBT93-10-A3L	STANDARD SPRING WASHER		2	
11	RV01102010005	CHAIN-76/10A		1	
12	RGV3102010001K	Drive chain		1	
13	GBT93-12-A3L	STANDARD SPRING WASHER		1	
14	RGV4102030003K	ROCK ARM		1	
14.1	GBT6170-M14-8-A3L	TYPE 1 HEX NUT		1	
14.2	GBT93-14-A3L	STANDARD SPRING WASHER		1	
14.3	RV01103000019	OIL SEAL 20 X42X6		2	
14.4	GBT893.1-42	RETAINING RING FOR HOLE		2	
14.5	RV02208000125	BEARING		1	
14.6	RV01103000021	SLEEVE		2	
14.7	RGV3102040007a	SWING ARM		1	
14.8	RV01103000018	CONNECTING BOLT		1	

RGV3102040000K HEADER ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
15	GBT5786-M12X1.5X55-8.8-A3L	HEX HEAD BOLTS		1	
16	GBT5783-M10X30-8.8-A3L	HEX HEAD BOLTS		2	
17	GBT5789-M12X40-8.8-A3L	HEX FLANGE BOLTS		2	
18	RGV3102040001K	SWING RING TRANSMISSION		1	
19	GBT5789-M8X16-8.8-A2L	HEX FLANGE BOLTS		6	
20	GBT6171-M12X1.5-8-A3L	TYPE 1 HEX NUT		1	

RGV3102040000K HEADER ASSEMBLY-2




RGV3102040000K HEADER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3102040000K	HEADER ASSEMBLY		1	
1	GBT5783-M10X70-8. 8-A3L	HEX HEAD BOLTS		1	
2	GBT5789-M6X12-8. 8-A2L	HEX FLANGE BOLTS		4	
3	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		6	
4	GBT5789-M6X16-8. 8-A2L	HEX FLANGE BOLTS		2	
5	GBT96. 1-8-A3L	LARGE WASHER		3	
6	DV01102000138	PRESSING SPRING		1	
7	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		2	
8	G15. 2-13	STRAW FENDER PLATE		2	
9	RV03102010001	HEADER COVER WELDMENT		1	
10	GBT5789-M8X16-8. 8-A2L	HEX FLANGE BOLTS		6	
11	RGV4102030007K	TENSION SPROCKET ASSEMBLY		1	
11.1	RGV3102040045	Tension Bolt Weldment		1	
11.2	RGV3102040056	TOOTHED GASKET		1	
11.3	RGV3102040049	SHAFT SEAT		1	
11.4	RGV1102020013K	TENSION SPROCKET ASSEMBLY		1	
11.5	GBT97. 1-10-A3L	FLAT WASHERS		1	
11.6	GBT93-10-A3L	STANDARD SPRING WASHER		1	
11.7	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		1	

LOVOL
ZSJ D13750

RGV3102040000K HEADER ASSEMBLY-3



RGV3102040000K HEADER ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV3102040000K	HEADER ASSEMBLY		1	
	RGV3102040001K	SWING RING TRANSMISSION		1	
1	GBT894. 1-25	RETAINING RING FOR SHAFT		1	
2	RV02208000127	BEARING 6305		1	
3	BZF0028. 5-119	SPROCKET WHEEL		1	
4	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		2	
5	GBT84-M8X25-33H	LOCKING BOLT		2	
6	RGV3102040021	SWING RING TRANSMISSION SHAFT		1	
7	DV01102000074	BEARING BLOCK		1	
8	RV01102020002	GASKET		1	
9	RDL1301000036	BEARING		1	
10	BZF0028. 3-501	SPROCKET WHEEL		1	
11	GBT93-8-A3L	STANDARD SPRING WASHER		2	
12	GBT70. 1-M8X12-8. 8-A2L	HEXAGON SOCKET HEAD CAP SCREW		2	
13	RGV3102040018	THE ECCENTRIC SHAFT HEAD WELD		1	
14	RGV1102010002K	SWING RING ASSEMBLY		1	
14. 1	RGV3102040016	SWING ROD WELDMENT		1	
14. 2	GBT893. 1-35	RETAINING RING FOR HOLE		2	
14. 3	RGV1903160006K	DEEP GROOVE BALL BEARING 6202		2	
14. 4	GBT893. 1-80	RETAINING RING FOR HOLE		1	
14. 5	RGV4102030005K	DEEP GROOVE BALL BEARING 6208		2	
14. 6	RV01102000037	PENDULUM RING SEAT		1	
15	JBZQ4342-40	HEAVY SHAFT WITH ELASTIC RING		1	


RGV3102040000K HEADER ASSEMBLY-3 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
16	RGV3102040074	BEARING		1	
16.1	DV01102000140	BEARING SEAT		1	
16.2	GBT3882-UE206	BEARING		1	
16.3	DV01102000150	DUSTPROOF CAP OF OIL CUP		1	
17	GBT1096-8X7X45	FLAT KEY		1	

LOVOL

zsj D13750

RGV3102040000K HEADER ASSEMBLY-4



RGV3102040000K HEADER ASSEMBLY-4


No.	Part No.	Description	Version	QTY.	Remark
	RGV3102040000K	HEADER ASSEMBLY		1	
1	RGV3102040001d	HEADER WELDMENT		1	
1.1	GBT6177. 1-M6-8-0	HEXAGON FLANGE NUT		4	
1.2	GBT96. 1-6-0	LARGE WASHER		4	
1.3	RV01102000059	SHIELD		2	
1.4	RGV3102040002e	HEADER WELDMENT		1	
2	RGV4102030006K	TENSION ORGANIZATION ASSEMBLY		1	
2.1	GBT91-4X28-A3L	COTTER PIN		1	
2.2	GBT97. 1-16-A3L	FLAT WASHERS		1	
2.3	DG2002. 2A. 2-06	GASKET		2	
2.4	DG2002. 12. 6b-02	ADJUSTING BOLT 2		1	
2.5	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		2	
2.6	GBT894. 1-17	RETAINING RING FOR SHAFT		1	
2.7	RV01102000072	BRACKET WELDING		1	
2.8	DG2002. 2A. 2-03	SPRING		1	
2.9	RGV1108010006K	TENSION SPROCKET ASSEMBLY		1	

LOVOL

zsj D13750

LOVOL
ZSJ D13750


RV01103030000 CUTTER ASSEMBLY-1



RV01103030000 CUTTER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RV01103030000	CUTTER ASSEMBLY	005	1	
1	GBT5783-M10X25-8.8-A3L	HEX HEAD BOLTS		9	
2	GBT93-10-A3L	STANDARD SPRING WASHER		9	
3	RV01103000025	WASHER		9	
4	RV01103030001a	CUTTER		1	

RV01103030000 CUTTER ASSEMBLY-2



RV01103030000 CUTTER ASSEMBLY-2


No.	Part No.	Description	Version	QTY.	Remark
	RV01103030000	CUTTER ASSEMBLY		1	
	RV01103030001a	CUTTER		1	
1	GBT12-M10X40-8.8-A3L	BOLT		12	
2	DV01103010015	CUTTER GUARD		6	
3	DG2004.3.1-04	GASKET		9	
4	DV01103010012	BRAKE DISC		8	
5	RV01103030002b	KNIFE BEAM		1	
6	DV01103010017	KNIFE GUARD		16	
7	GBT93-10-A3L	STANDARD SPRING WASHER		32	
8	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		32	
9	GBT12-M10X30-8.8-A3L	BOLT		15	
10	RGV3103030012	MOVING CUTTER COMBINATION		1	
11	GBT12-M10X35-8.8-A3L	BOLT		3	
12	RV01103000013	SUPPORT PLATE		1	
13	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		7	
14	GBT93-8-A3L	STANDARD SPRING WASHER		7	
15	RGV3103060006	CUTTER GUARD		1	
16	GBT12-M10X55-8.8-A2L	BOLT		2	
17	RV01103000016	ADJUSTMENT MATS		1	
18	GBT5783-M8X25-8.8-A2L	HEX HEAD BOLTS		2	
19	GBT6170-M14-8-A3L	TYPE 1 HEX NUT		1	
20	GBT93-14-A3L	STANDARD SPRING WASHER		1	
21	RV01103000020	LINK		2	

RV01103030000 CUTTER ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
22	RV01103000021	SLEEVE		2	
23	RV01103000019	OIL SEAL 20 X42X6		2	
24	GBT893. 1-42	RETAINING RING FOR HOLE		2	
25	RGV3102040069	BEARING		1	
26	RV01103000018	CONNECTING BOLT		1	
27	GBT5783-M8X16-8. 8-A2L	HEX HEAD BOLTS		5	
28	RV01103030005	LEFT TOOTHED PLATE		1	
29	RGV3103030008	RIGHT AID CONVEYOR		1	
30	RGV3103030009	GASKET		1	
31	RGV3103030010	CUTTER FRICTION DISC		2	
32	RGV3103030011	CUTTER GUARD		1	
33	RV01103000014	HALF THE BLADE SPACER		2	

LOVOL
zsj D 13750

RV01103030000 CUTTER ASSEMBLY-3




RV01103030000 CUTTER ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RV01103030000	CUTTER ASSEMBLY		1	
	RV01103030001a	CUTTER		1	
	RGV3103030012	MOVING CUTTER COMBINATION		1	
1	GBT867-6X16	RIVET		44	
2	RV01103000009	HALF BLADE		1	
3	DV01103010003	KNIFE SECTION		29	
4	RV01103030004	KNIFE BACK		1	
5	GBT867-6X20	RIVET		18	
6	RV01103000006	HELP SHIP THE BRACKET		5	
7	RGV3103030006	MOVING CUTTER BIT		1	
8	RV01103000007	HALF BLADE		1	

LOVOL
ZSJ D13750

RGV3104000000K REEL BRACKET ASSEMBLY

LOVOL
ZSJ D13750



RGV3104000000K REEL BRACKET ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3104000000K	REEL BRACKET ASSEMBLY	001	1	
1	RV03104020005a	BRACKET WELDMENT		1	
2	RV03104010046a	SUPPORTING ARM WELDED PART		1	
2.1	RV03104010047a	TENSIONER WELDED PART		1	
2.2	DG2002. 8. 2a-01	SLEEVE		2	
3	RGV3104000001K	SPEED CHANGING BELT PULLEY		1	
3.1	BZF0028. 1-001	SPROCKET		1	
3.2	GBT893. 1-47	RETAINING RING FOR HOLE		2	
3.3	RGV1903160001K	BEARING		2	
3.4	DV01104000168	SPACING SLEEVE		1	
3.5	GBT6170-M6-8-A2L	TYPE 1 HEX NUT		6	
3.6	GBT93-6-A3L	STANDARD SPRING WASHER		6	
3.7	RV03104010012	VARIABLE SPEED PULLEY		1	
3.8	GBT5783-M6X25-8. 8-A2L	HEX HEAD BOLTS		6	
4	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		2	
5	GBT96. 1-10-A3L	LARGE WASHER		2	
6	RV03104010050	ADJUSTMENT MATS		1	
7	D1801. 4. 3-01	TENSIONER		2	
8	DV01104000004	SLEEVE		4	
9	DV01104010007	TENSION PULL ROD		1	
10	DV01104000002	TENSION SPRING		1	
11	GBT5789-M6X12-8. 8-A2L	HEX FLANGE BOLTS		5	
12	GBT894. 1-15	RETAINING RING FOR SHAFT		2	


RGV3104000000K REEL BRACKET ASSEMBLY (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
13	DV01104000051	RETAINING RING		5	
14	RV03104010010	COVER WITHIN 1		1	
15	RV03104010035	BONNET		1	
16	RV03104010005	SHIELD		1	
17	DV01104000162	AXIS		1	
18	DV01104000163	SHAFT END RETAINING RING		1	
19	GBT93-8-A3L	STANDARD SPRING WASHER		1	
20	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		1	
21	GBT879. 1-8X35	ELASTIC CYLINDRICAL PIN		1	
22	GBT1171-B2860	V-BELT		1	
23	GBT5789-M8X16-8. 8-A2L	HEX FLANGE BOLTS		4	

LOVOL

zsj D13750

RGV3105030000 FEEDING AUGER ASSEMBLY-1




RGV3105030000 FEEDING AUGER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3105030000	FEEDING AUGER ASSEMBLY	004	1	
1	GBT5783-M10X30-8.8-A3L	HEX HEAD BOLTS		1	
2	GBT93-10-A3L	STANDARD SPRING WASHER		18	
3	DG2002.5-07	BEZEL		1	
4	RV03105010025	AUGER CHAIN PULLEY WELDMENT		1	
5	GBT97.1-10-A3L	FLAT WASHERS		12	
6	RV01105000022	BEARING SEAT		1	
6.1	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	
6.2	JBT7940.1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
6.3	RV01105000001	BEARING SEAT		1	
6.4	DG2003.17.3a-01	BEARING		1	
7	GBT5783-M10X70-8.8-A3L	HEX HEAD BOLTS		1	
8	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		9	
9	GBT96.1-10-A3L	LARGE WASHER		4	
10	RV01105000002	RIGHT ADJUSTING PLATE		1	
11	GBT12-M10X25-8.8-A3L	BOLT		4	
12	GBT5783-M10X25-8.8-A3L	HEX HEAD BOLTS		13	
13	RV01105000013	DRIVING SHAFT		1	
13.1	DV01105010035	DRIVING SHAFT PLATE WELDMENT		1	
13.2	RV01105000014	DRIVING SHAFT		1	
13.3	GBT1096-8X7X63	FLAT KEY		1	
14	DV01105010034	LEFT DRAW TOOTH SEAT		1	
15	RV03105020007	EXTENSIBLE TOOTH SHAFT		1	

RGV3105030000 FEEDING AUGER ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
16	GBT97. 1-18-A3L	FLAT WASHERS		1	
17	GBT93-18-A3L	STANDARD SPRING WASHER		1	
18	GBT6171-M18X1. 5-10-A3L	TYPE 1 HEX NUT		1	
19	RGV3105030015	DRAW TOOTH ROD COMBINATION		15	
19. 1	GBT5783-M8X40-8. 8-A2L	HEX HEAD BOLTS		1	
19. 2	GBT97. 1-8-A3L	FLAT WASHERS		1	
19. 3	RGV3105030016	TOOTH SEAT		1	
19. 4	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		1	
19. 5	RV03105010021	EXTENSIBLE TOOTH ROD		1	
20	GBT1096-C8X7X50	FLAT KEY		1	
21	F103135	BOLT		3	
22	RV01105020011	DIAL THE TOOTH RIGHT HOLDER ASSEMBLY		1	
22. 1	GBT893. 1-52	RETAINING RING FOR HOLE		1	
22. 2	DG2002. 5-05	RIGHT TEETH HOLDER		1	
22. 3	GBT276-6205-2RS	DEEP GROOVE BALL BEARING		1	
23	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		3	

RGV3105030000 FEEDING AUGER ASSEMBLY-2



RGV3105030000 FEEDING AUGER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3105030000	FEEDING AUGER ASSEMBLY		1	
1	GBT5783-M10X25-8.8-A3L	HEX HEAD BOLTS		13	
2	GBT93-10-A3L	STANDARD SPRING WASHER		18	
3	RV01105020010	BEARING SEAT ASSEMBLY I		2	
3.1	GBT3882-UEL206	BEARING		1	
3.2	RV01105000001	BEARING SEAT		1	
3.3	JBT7940.2-45dM6	JOINT TYPE PRESSURE OIL CUP		1	
3.4	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	
4	RV03105020006	ECCENTRIC ADJUSTING SHAFT		1	
5	GBT1096-8X7X40	FLAT KEY		1	
6	GBT882-B10X90-A3L	PIN		1	
7	DV01105010010	FLOATING BLOCK		1	
8	GBT97.1-10-A3L	FLAT WASHERS		12	
9	Q50110	LOCK PIN		1	
10	D20012.5-05	SPRING		1	
11	HC1801.28.2-01	TENSION BOLT		1	
12	GBT96.1-8-A3L	LARGE WASHER		1	
13	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		2	
14	DV01105010049	ADJUSTMENT BLOCK		1	
15	DV01105010011	FIXING PLATE		1	
16	GBT93-12-A3L	STANDARD SPRING WASHER		2	
17	GBT5783-M12X45-8.8-A3L	HEX HEAD BOLTS		2	
18	RV03105010022	DRAW TOOTH BUSH		15	

RGV3105030000 FEEDING AUGER ASSEMBLY-2 (cont'd.)


No.	Part No.	Description	Version	QTY.	Remark
19	GBT93-8-A3L	STANDARD SPRING WASHER		12	
20	GBT97.1-8-A3L	FLAT WASHERS		12	
21	RGV3105030024	AUGER INSTALLATION HOPE CAP WELDMENT		1	
22	RGV3105030001a	Beat the dragon fitting		1	
23	GBT70.1-M8X16-8.8-A2L	HEXAGON SOCKET HEAD CAP SCREW		12	
24	RV03105010010	AUGER INSTALLATION HOPE CAP WELDMENT		1	
25	GBT9074.17-M8X20-8.8-A2L	BOLT AND WASHER ASSEMBLY		30	

LOVOL

zsj D13750

LOVOL
ZSJ D13750


RGV3412010000K CLUTCH CONTROL ASSEMBLY-1



RGV3412010000K CLUTCH CONTROL ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3412010000K	CLUTCH CONTROL ASSEMBLY	002	1	
1	GBT16674. 1-M8X20-8. 8-A2L	HEX FLANGE BOLTS		5	
2	RGV3412010001	MAIN TENSION PULLEY ASSEMBLY		1	
3	DG2004. 37-01	HANDLE SLEEVE		1	
4	RV01412000021e	THRESHING CLUTCH WELDMENT		1	
5	GBT97. 1-10-A3L	FLAT WASHERS		2	
6	GBT91-3. 2X20-A3L	COTTER PIN		2	
7	RGV3412010017	SPRING		1	
8	RGV3412010018	PULL ROD WELDMENT		1	
9	GBT6170-M10-10-A3L	TYPE 1 HEX NUT		2	
10	RGV3412010012	WELDED FRAME		1	
11	DG2002. 37. 1-01a	BENDING		1	
12	GBT91-2X16-A3L	COTTER PIN		1	
13	GBT882-B8X22-A3L	PIN		1	
14	GBT97. 1-8-A3L	FLAT WASHERS		1	
15	GBT91-3. 2X28-A0P	COTTER PIN		1	
16	GBT97. 1-12-A3L	FLAT WASHERS		1	
17	GBT882-B12X30-A3L	PIN		1	
18	GBT16674. 1-M10X20-8. 8-A3L	HEX FLANGE BOLTS		2	
19	RV01501040001a	UPPER LIMITING ROD WELDMENT		1	
20	GBT16674. 1-M12X30-10. 9-A3L	HEX FLANGE BOLTS		6	
21	RGV3501070002	PULLEY - POWER OUTPUT		1	

RGV3412010000K CLUTCH CONTROL ASSEMBLY-2




RGV3412010000K CLUTCH CONTROL ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3412010001	MAIN TENSION PULLEY ASSEMBLY		1	
	RGV3412010000K	CLUTCH CONTROL ASSEMBLY		1	
1	RGV3412010009	LONG SHAFT SLEEVE		1	
2	GBT893. 1-52	RETAINING RING FOR HOLE		2	
3	GBT276-6205-RS	DEEP GROOVE BALL BEARING		2	
4	RGV3412010010	SPACER BUSH 3		1	
5	RGV3412010011	TENSIONER		1	
6	DG2002. 37. 3-05	SPACER BUSH-2		1	
7	RGV3412010007	SUPPORT SHAFT		1	
8	GBT93-12-A3L	STANDARD SPRING WASHER		1	
9	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		1	
10	RGV3412010002	BRACKET WELDMENT		1	
11	RGV3412010008	SUPPORTING SHAFT		1	
12	GBT5789-M6X12-8. 8-A2L	HEX FLANGE BOLTS		2	
13	RV01412000010	LIMIT PLATE		1	
14	JBT7940. 1-M10X1	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
15	DV01102030037	DUSTPROOF CAP OF OIL CUP		1	

LOVOL
zsj D13750

RGV3413020000K UNLOADING CLUTCH CONTROL

LOVOL
ZSJ D13750



RGV3413020000K UNLOADING CLUTCH CONTROL


No.	Part No.	Description	Version	QTY.	Remark
	RGV3413020000K	UNLOADING CLUTCH CONTROL ASSY	001	1	
1	GBT91-3. 2X40-A3L	COTTER PIN		1	
2	GBT97. 1-18-A3L	FLAT WASHERS		1	
3	RV01413030050	JOYSTICK WELDING		1	
4	RGV3413010003	CLUTCH SPRING		1	
5	RGV3413020001K	PULL ROD COMBINATION		1	
5.1	HG2201. 20B. 4a-01	BOLT		1	
5.2	GBT6170-M8-LH-8-A2L	TYPE 1 HEX NUT		1	
5.3	RV02413010022	SCREW BUSH		1	
5.4	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		1	
5.5	RGV3413020002K	TROLLEY 1		1	
6	DG2004. 37-01	HANDLE SLEEVE		1	
7	RV01413030007	BELT		2	
8	GBT894. 1-17	RETAINING RING FOR SHAFT		1	
9	DV01413020028a	TENSIONER COMBINATION		1	
9.1	GBT893. 1-40	RETAINING RING FOR HOLE		1	
9.2	GBT276-6203-2RS	DEEP GROOVE BALL BEARING		1	
9.3	RGV3413000016	TENSIONER		1	
10	Q50108	LOCK PIN		1	
11	GBT97. 1-8-A3L	FLAT WASHERS		1	
12	GBT894. 1-20	RETAINING RING FOR SHAFT		1	
13	D1682. 37. 3-03	RETAINING RING		1	
14	RV01413030046	BRACKET WELDMENT		1	

RGV3413020000K UNLOADING CLUTCH CONTROL (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
14.1	GBT12613.1-P22X20X30	SLEEVE		1	
14.2	RV01413030047	BRACKET WELDING		1	
15	RV01413030040	UNLOADING SEAT		1	
16	GBT5783-M10X30-8.8-A3L	HEX HEAD BOLTS		4	
17	GBT93-10-A3L	STANDARD SPRING WASHER		4	
18	GBT97.1-10-A3L	FLAT WASHERS		6	
19	GBT16674.1-M8X20-8.8-A2L	HEX FLANGE BOLTS		3	
20	DV01501050004	ROD		1	
21	DV01413020006	BELT SEAT		1	
22	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		2	
23	RGV2413030006	PULLEY BRACKET WEDMENT		1	
24	DV01501050002	PULLEY BRACKET WEDMENT		1	
25	DV01413020010	BELT SEAT		1	
26	GBT16674.1-M8X45-8.8-A2L	HEX FLANGE BOLTS		2	

RGV3214000000K MAIN ENGINE TRANSMISSION ASSEMBLY

LOVOL
ZSD13750




RGV3214000000K MAIN ENGINE TRANSMISSION ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3214000000K	MAIN ENGINE TRANSMISSION ASSEMBLY	001	1	
1	RGV3214030006	V-BELT SB45		1	
2	RGV3214000001	BAND GROUP		1	
3	RGV3214000004	BELT		1	
4	RV02214000001	DRIVING BELT		1	
5	RV02214000003	BRIDGE-CROSSING INPUT BAND		2	
6	RGV3214000029	BELT		1	

LOVOL
ZSJ D13750


RGV3402020000K DRIVING AXLE ASSEMBLY-1



RGV3402020000K DRIVING AXLE ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402020000K	DRIVING AXLE ASSEMBLY	001	1	
1	RV01402040001	V-BELT SB65. 5		3	
2	DV01402080011	WASHER		4	
3	GBT6171-M12X1. 25-8-A2L	TYPE 1 HEX NUT		4	
4	GBT93-12-A3L	STANDARD SPRING WASHER		8	
5	GBT93-10-A3L	STANDARD SPRING WASHER		4	
6	GBT5783-M10X30-8. 8-A3L	HEX HEAD BOLTS		4	
7	RGV3402090001	GEARBOX ASSEMBLY		1	
8	RGV4402000011	BRAKE BRACKET ASSEMBLY		1	
8. 1	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		2	
8. 2	GBT93-8-A3L	STANDARD SPRING WASHER		2	
8. 3	GBT97. 1-8-A3L	FLAT WASHERS		2	
8. 4	DG2001. 28. 3. 4	LOCATION SHAFT WELDMENT		2	
8. 5	DG2001. 28. 3. 3	ROTARY SHAFT WELDMENT 2		1	
8. 6	DG2001. 28. 3. 2	ROTARY SHAFT WELDMENT 1		1	
8. 7	DG2001. 28. 3-01	RETURN SPRING OF BRAKE		1	
8. 8	RGV4402000012	BRACKET WELDING		1	
8. 9	GBT97. 1-16-A3L	FLAT WASHERS		2	
8. 10	GBT91-4X36-A3L	COTTER PIN		2	
9	GBT97. 1-10-A3L	FLAT WASHERS		2	
10	GBT93-8-A3L	STANDARD SPRING WASHER		4	
11	GBT97. 1-8-A3L	FLAT WASHERS		4	
12	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		4	

RGV3402020000K DRIVING AXLE ASSEMBLY-2



RGV3402020000K DRIVING AXLE ASSEMBLY-2


No.	Part No.	Description	Version	QTY.	Remark
	RGV3402020000K	DRIVING AXLE ASSEMBLY		1	
1	RV03402000030b	RUNNING TENSION WHEEL COMBINATION		1	
1.1	DV01402040005	SPACER BUSH		1	
1.2	DV01402040026	ADJUSTMENT MATS		2	
1.3	DV01402040006	GASKET		1	
1.4	GBT93-10-A3L	STANDARD SPRING WASHER		1	
1.5	GBT5783-M10X20-8.8-A3L	HEX HEAD BOLTS		1	
1.6	RV03402000031d	RUNNING TENSION WHEEL COMBINATION		1	
1.6.1	TD800.311C.1-01	DUSTPROOF CAP OF OIL CUP		1	
1.6.2	JBT7940.1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
1.6.3	DV01402000064	SPACER BUSH 3		1	
1.6.4	GBT276-6204-RS	DEEP GROOVE BALL BEARING		4	
1.6.5	DV01402040004	SPACER		1	
1.6.6	RV03402000032b	TENSION BRACKET WELDMENT		1	
1.6.7	DV01402000067	SUPPORTING SHAFT		1	
1.6.8	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		1	
1.6.9	GBT893.1-47	RETAINING RING FOR HOLE		2	
1.6.10	DV01402000066	SPACER BUSH 1		1	
1.6.11	DG2001.28.2b-03	RUNNING TENSION BELT PULLEY		1	
1.6.12	DV01402000065	SPACER BUSH 2		1	
1.6.13	GBT93-12-A3L	STANDARD SPRING WASHER		1	
1.6.14	GBT276-6204-2RS	DEEP GROOVE BALL BEARING		2	
2	RV03402000051	TENSION SPRING		1	

RGV3402020000K DRIVING AXLE ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
3	RV01402060036	TIE ROD		1	
4	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		3	
5	GBT96. 1-12-A3L	LARGE WASHER		3	
6	RV01402060037	SPACER		1	
7	GBT850-12	CONE WASHER		1	
8	GBT849-12	SPHERICAL WASHER		1	
9	GBT5782-M12X90-8. 8-A3L	HEX HEAD BOLTS		1	
10	GBT5783-M12X30-8. 8-A3L	HEX HEAD BOLTS		2	
11	RV03402000034	CONNECTING SEAT WELDMENT OF GEARBOX		1	
12	GBT97. 1-12-A3L	FLAT WASHERS		3	
13	GBT93-12-A3L	STANDARD SPRING WASHER		8	

LOVOL
ZSJ D13750

RGV3402020000K DRIVING AXLE ASSEMBLY-3



RGV3402020000K DRIVING AXLE ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402090002	GEARBOX ASSEMBLY		1	
	RGV3402020000K	DRIVING AXLE ASSEMBLY		1	
1	RGV3402060010A	HST SEAT ASSEMBLY		1	
1.1	GBT5789-M10X25-10.9-A2L	HEX FLANGE BOLTS		1	
1.2	GBT1096-10X8X40	FLAT KEY		1	
1.3	RV02402000027	WASHER		1	
1.4	RGV3402060005	INPUT BELT PULLEY		1	
1.5	RGV3402060013A	HST CONNECTION BASE ASSEMBLY		1	
1.5.1	GN601.2A.14.1	SWING RING BOX AIR DISCHARGING PLUG		1	
1.5.2	GL07102010064	CONNECTING HOSE		1	
1.5.3	RGV3402060004A	HST CONNECTING SEAT		1	
1.5.4	Q617B08	HEXAGON PLUG		1	
1.5.5	JBT982-8	COMBINATION GASKET		1	
1.5.6	GBT9877.1-FB38X62X8D	ROTARY SHAFT LIP SEAL WITH INNER FRAME		1	
1.5.7	DV01402010087	ADJUSTING SHIM-IV SHAFT BEARING		1	
1.5.8	RGV3402060006	INPUT SHAFT		1	
1.5.9	GBT276-6305	DEEP GROOVE BALL BEARING		1	
1.5.10	GBT283-NJ206E	COLUMN ROLLER BEARING		1	
1.5.11	GBT893.1-62	RETAINING RING FOR HOLE		1	
1.5.12	RV02402000026	INPUT SHAFT OIL SEAL RACE		1	
1.5.13	RGV3402060023	SPACER BUSH OF INPUT SHAFT		1	
2	GL05501020011	BOLT CAP		4	
3	GBT5783-M12X35-10.9-A3L	HEX HEAD BOLTS		16	

RGV3402020000K DRIVING AXLE ASSEMBLY-3 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
4	S0110A010061AC	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
5	RGV3402000019	HST GASKET		1	
6	TD904. 311K. 1-13	SCREW PLUG		1	
7	GBT3452. 1-21. 2X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
8	RGV3402000004	GEARBOX HOUSING		1	
9	GBT119. 1-8h8X22-A3L	CYLINDRICAL PIN		4	
10	GBT70. 1-M12X40-10. 9-A3L	HEXAGON SOCKET HEAD CAP SCREW		2	
11	GBT93-12-A3L	STANDARD SPRING WASHER		18	
12	CP4D304010028	SCREW PLUG		1	
13	GBT893. 1-22	RETAINING RING FOR HOLE		1	
14	DV01402010086	SPLINE SHAFT BUSH		1	
15	DV01402040020	HST CONNECTING SEAT GUARD PLATE		1	

LOVOL
ZSJ D13750

RGV3402020000K DRIVING AXLE ASSEMBLY-4


No.	Part No.	Description	Version	QTY.	Remark
	RGV3402020000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402090002	GEARBOX ASSEMBLY		1	
1	DV01402010102	PLUG COVER		1	
2	GBT893.1-52	RETAINING RING FOR HOLE		1	
3	RGV3402060021	BREATHER PLUG		1	
4	GBT93-8-A3L	STANDARD SPRING WASHER		42	
5	GBT283-NJ305E	COLUMN ROLLER BEARING		3	
6	RV01402160021	FIRST SHAFT SPACER BUSH		1	
7	DV01402010120	Left side cover		1	
8	RV01402160064	FRONT COVER GASKET		1	
9	RGV3402090003	1ST SHAFT ASSEMBLY		1	
9.1	GBT283-NJ2205E	COLUMN ROLLER BEARING		1	
9.2	RV01402160017	THRUST PAD		1	
9.3	RGV3402000006	NORMALLY ENGAGED GEAR		1	
9.4	GBT20056-K32X38X20	NEEDLE AND CARRIER COMBINATION		1	
9.5	RV01402160008	FIRST GEAR DRIVING GEAR ASSEMBLY		1	
9.6	RV01402160013	GEAR BUSH		1	
9.7	RGV3402000018	1ST SHAFT		1	
9.8	RV01402160020	NEEDLE BEARING		1	
9.9	RV01402160012	3RD DRIVING GEAR		1	
9.10	RGV3402000017	BUSH		1	
9.11	RGV4402040024	2ND GEAR DRIVING GEAR		1	
9.12	GBT20056-K38X43X17	NEEDLE AND CARRIER COMBINATION		2	

RGV3402020000K DRIVING AXLE ASSEMBLY-4 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
9. 13	RGV3402000021	SECOND GEA HUB SLEEVE		1	
9. 14	RGV4402040025	SPACER		1	
10	RGV3402000015	FRONT COVER		1	
11	GBT5783-M8X16-10. 9-A2L	HEX HEAD BOLTS		4	
12	RGV3402060022	VENT PLUG		1	
13	GBT893. 1-42	RETAINING RING FOR HOLE		2	
14	RV03402000022	SPACER		1	
15	GBT276-6008	DEEP GROOVE BALL BEARING		1	
16	RGV3402000005	INPUT GEAR		1	
17	GBT894. 1-24	RETAINING RING FOR SHAFT		1	
18	RGV3402040039	OIL SEAL		2	
19	Q673B23	STEEL BAND ELASTIC HOOP		1	

LOVOL
ZSJ D13750

RGV3402020000K DRIVING AXLE ASSEMBLY-5




RGV3402020000K DRIVING AXLE ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402020000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402090002	GEARBOX ASSEMBLY		1	
1	DV01402010104	PLUG COVER		1	
2	DV01402010103	O-RING		1	
3	GBT893. 1-62	RETAINING RING FOR HOLE		2	
4	GBT283-NJ305E	COLUMN ROLLER BEARING		3	
5	RV01402160026	Second shaft spacer 1		1	
6	RV01402160023	1ST DRIVEN GEAR		1	
7	RV01402160025	THIRD GEAR DRIVEN GEAR		1	
8	RV01402160024	II GEAR DRIVEN GEAR		1	
9	RV01402160022	SECOND SHAFT		1	
10	RV01402160027	Second shaft spacer 2		1	
11	RV01402160028	Second shaft spacer 3		1	
12	S0114A010044AC	PLUG COVER		1	
13	RGV4402040004	RIGHT HALF SHAFT ASSEMBLY		2	

LOVOL
ZSJ D13750

RGV3402020000K DRIVING AXLE ASSEMBLY-6




RGV3402020000K DRIVING AXLE ASSEMBLY-6

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402020000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402090002	GEARBOX ASSEMBLY		1	
1	GBT879. 1-4X26	ELASTIC CYLINDRICAL PIN		1	
2	GBT879. 1-6X26	ELASTIC CYLINDRICAL PIN		1	
3	DV01402010088	OUTSIDE GEARSHIFT ROCKER		1	
4	GBT1235-24X2. 4	RUBBER O-SEAL RING		1	
5	DV01402010068	GEARSHIFT SHAFT BUSH		1	
6	GBT1235-16X2. 4	RUBBER O-SEAL RING		2	
7	DV01402010079	OUTSIDE GEARSHIFT ROCKER WELDMENT		1	
8	GBT308-6. 35-G100-b	STEEL BALL		1	
9	RV02402000086	SELF-LOCKING SPRING		1	
10	RGV3402000025	LEVER FORK		1	
11	RGV3402000013	FORK SHAFT		1	
12	GBT5783-M8X25-10. 9-A2L	HEX HEAD BOLTS		41	
13	DV01402010108	BAFFLE		1	
14	DV01402010093	FORK SHAFT COVER		2	
15	GBT93-8-A3L	STANDARD SPRING WASHER		43	
16	GBT5783-M8X20-10. 9-A2L	HEX HEAD BOLTS		4	
17	RGV3402060020	MANUAL FIXED BRAKE AXLE		1	
18	GBT6170-M8-10-A2L	TYPE 1 HEX NUT		1	
19	JBT982-8	COMBINATION GASKET		1	
20	RV01402160041	FIXED PLATE		1	

LOVOL
ZSJ D13750

RGV3402020000K DRIVING AXLE ASSEMBLY-7




RGV3402020000K DRIVING AXLE ASSEMBLY-7

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402020000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402090002	GEARBOX ASSEMBLY		1	
1	GL02501010080	ADJUSTING WASHER		1	
2	RV01402160038	SPRING		2	
3	RV01402160042	WASHER		2	
4	RV01402160040	WASHER		4	
5	RGV3402000008	FRICTION PIECE ASSEMBLY		2	
5.1	RV01402160043	INNER CLUTCH PATH		7	
5.2	RV01402160044	O. CLUTCH DISC		8	
6	RV01402160036	LEFT BEARING SEAT		1	
7	GBT93-10-A3L	STANDARD SPRING WASHER		12	
8	GBT5783-M10X35-10.9-A3L	HEX HEAD BOLTS		8	
9	RV01402160046	RETAINING RING		1	
10	RV01402160033	THREE AXLE SLIDING GEAR ASSEMBLY		2	
11	RV01402160030	DENTAL CHIMERA		1	
12	RV01402160037	RIGHT BEARING SEAT		1	
13	RV01402160029	THREE SHAFT CONSTANT CLOSING GEAR		1	
14	GBT5783-M8X20-10.9-A2L	HEX HEAD BOLTS		2	
15	GBT93-8-A3L	STANDARD SPRING WASHER		42	
16	RV01402160039	BEARING COVER		2	
17	RV01402160045	BRAKE PRESSING PLATE		2	
18	GBT297-30207	TAPERED ROLLER BEARING-30211-J2-Q		2	

LOVOL
ZSJ D13750

RGV3402020000K DRIVING AXLE ASSEMBLY-8




RGV3402020000K DRIVING AXLE ASSEMBLY-8

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402020000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402090002	GEARBOX ASSEMBLY		1	
1	DV01402010087	ADJUSTING SHIM-IV SHAFT BEARING		1	
2	GBT297-32207	TAPERED ROLLER BEARING-30211-J2-Q		2	
3	RV01402160072	THRUST PAD		2	
4	RGV4402040027	FOUR AXLE GEAR AND BUSHING ASSEMBLY		2	
5	GBT894. 1-78	RETAINING RING FOR SHAFT		3	
6	RV01402160063	4-AXIS GLAND GASKET		2	
7	RV01402160052	SIDE GEAR		2	
8	RV01402160050	COVER		1	
9	RGV4402040019	SPACER SLEEVE		1	
10	RV01402160048	SHAFT IV		1	
11	GBT5783-M8X25-10. 9-A2L	HEX HEAD BOLTS		37	
12	GBT93-8-A3L	STANDARD SPRING WASHER		42	

LOVOL
ZSJ D13750

RGV3402020000K DRIVING AXLE ASSEMBLY-9




RGV3402020000K DRIVING AXLE ASSEMBLY-9

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402020000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402090002	GEARBOX ASSEMBLY		1	
1	GBT93-12-A3L	STANDARD SPRING WASHER		18	
2	GBT5783-M8X25-10.9-A2L	HEX HEAD BOLTS		37	
3	GBT93-8-A3L	STANDARD SPRING WASHER		42	
4	RGV4402040018	RIGHT BRAKE ROCKER		1	
5	RGV4402040017	LEFT BRAKE ROCKER		1	
6	GBT70.3-M8X20-8.8-A2L	HEX SOCKET COUNTERSUNK HEAD SCREW		1	
7	9YFD190220300222	OIL PLUG ASSEMBLY		1	
8	GBT893.1-42	RETAINING RING FOR HOLE		2	
9	GBT276-6004	DEEP GROOVE BALL BEARING		2	
10	DV01402010011	FORK SPACER		2	
11	RGV4402040016	FORK WELDMENT		2	
12	RV01402160062	STEERING DIAL BLOCK		4	
13	GBT3452.1-100X2.65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		2	
14	GBT899-AM12-M12X1.25X60-8.8-A2 L	DOUBLE END STUDS		4	
15	GBT5783-M12X35-10.9-A3L	HEX HEAD BOLTS		16	
16	GBT3452.1-17.0X2.65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	

LOVOL
ZSJ D13750

RGV3402020000K DRIVING AXLE ASSEMBLY-10



RGV3402020000K DRIVING AXLE ASSEMBLY-10


No.	Part No.	Description	Version	QTY.	Remark
	RGV3402020000K (10)	DRIVING AXLE ASSEMBLY		1	
	RGV3402090002	GEARBOX ASSEMBLY		1	
	RGV4402040004	RIGHT HALF SHAFT ASSEMBLY		2	
1	GBT6171-M24X2-10-A3L	TYPE 1 HEX NUT		2	
2	RGV4402040006	Right half shaft sub-assembly		1	
2.1	YP4. 2. 2-32	OIL SEAL		1	
2.2	GBT5783-M8X25-8. 8-A2L	HEX HEAD BOLTS		6	
2.3	GBT93-8-A3L	STANDARD SPRING WASHER		6	
2.4	DV01402040032	OIL SEAL SEAT		1	
2.5	DV01402040029	FELT RING COMBINATION		1	
2.6	DV01402010098	BUSHING MAT , OIL SEAL SEAT		1	
2.7	GBT9877. 1-FB60X80X8D	ROTARY SHAFT LIP SEAL WITH INNER FRAME		2	
2.8	RGV4402040014	OIL SEAL SEAT		1	
2.9	RGV4402040008	RIGHT HALF SHAFT		1	
2.10	GBT297-30210	TAPERED ROLLER BEARING-30211-J2-Q		2	
2.11	RGV4402040011	RIGHT AXLE PIPE WELDMENT		1	
2.12	RGV4402030020	RIGHT HALF SHAFT GEAR SET		1	
2.13	RGV3402000026	LOCKING NUT		1	
3	RV01402060031	DRIVING WHEEL GASKET		1	
4	RV01402110002	DRIVE WHEEL		1	

LOVOL
ZSJ D13750

LOVOL

zsj D13750

RGV3302010000K TAILING AUGER ASSEMBLY-1



RGV3302010000K TAILING AUGER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3302010000K	TAILING AUGER ASSEMBLY	004	1	
1	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		7	
2	RV01302010017K	END COVER		1	
3	GBT93-8-A3L	STANDARD SPRING WASHER		18	
4	GBT97. 1-8-A3L	FLAT WASHERS		19	
5	GBT3882-UE205	BEARING		1	
6	RV01302010011K	BEARING SEAT		1	
7	RGV3302010001K	TOP COVER PLATE		1	
8	GBT96. 1-8-A3L	LARGE WASHER		5	
9	GBT6187. 1-M8-8	FULL METAL HEXAGON FLANGE LOCKING NUT		6	
10	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		4	
11	GBT5783-M8X30-8. 8-A2L	HEX HEAD BOLTS		7	
12	RV01302000115	MIXED REMNANT HOUSING BODY		1	
12. 1	GBT819. 2-M6X16-8. 8-A2L	CROSS RECESSED COUNTERSUNK HEAD SCREWS		4	
12. 2	RV01302000061	LINER PLATE		1	
12. 3	RV01302000180	WASHER		4	
12. 4	GBT6187. 1-M6-8	FULL METAL HEXAGON FLANGE LOCKING NUT		4	
12. 5	RV01302000116	MIXED REMNANT HOUSING BODY WELDMENT		1	
12. 6	RV01302000057	COVER PLATE WELDMENT		1	
12. 7	GBT5783-M6X16-8. 8-A2L	HEX HEAD BOLTS		4	
12. 8	GBT93-6-A3L	STANDARD SPRING WASHER		4	
12. 9	GBT97. 1-6-A3L	FLAT WASHERS		4	
13	RV01302000110	SEAL STRIP		1	

RGV3302010000K TAILING AUGER ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
14	GBT5783-M8X16-8.8-A2L	HEX HEAD BOLTS		7	
15	RGV4302000001K	TRANSMISSION BOX ASSEMBLY		1	
15.1	GBT9877.1-FB25X52X7D	ROTARY SHAFT LIP SEAL WITH INNER FRAME		1	
15.2	GBT893.1-52	RETAINING RING FOR HOLE		2	
15.3	RV01302000089	ADJUSTMENT MATS		1	
15.4	RGV4302000003K	DEEP GROOVE BALL BEARING 6304		1	
15.5	GBT894.1-20	RETAINING RING FOR SHAFT		1	
15.6	RV01302000066	AXIS		1	
15.7	RV01302000067	15 TEETH BEVEL GEAR		1	
15.8	RV01302000065	SLEEVE		1	
15.9	RGV4302000002K	DEEP GROOVE BALL BEARING 6002		1	
15.10	BA150B2.98.2.2	SMALL COVER PARTS		1	
15.11	RGV4302070041	GEARBOX		1	
15.12	RV01301000040	15 TEETH BEVEL GEAR		1	
15.13	RV01302000140	BEARING		1	
15.14	GBT9877.1-FB35X52X8D	ROTARY SHAFT LIP SEAL WITH INNER FRAME		1	
16	RV01302000111a	VERTICAL AUGER ASSEMBLY		1	
16.1	GBT889.1-M8-8	HEXAGON LOCK NUTS WITH NON-METALLIC INSERT TYPE 1		2	
16.2	RV01302000112a	WELDING OF VERTICAL AUGER		1	
16.3	HE2001.17.2a-06	BALANCING BLOCK		1	
16.4	RV01302000085	VANE		1	
16.5	GBT12-M8X16-8.8-A2L	BOLT		2	

RGV3302010000K TAILING AUGER ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
17	JBT7940. 1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
18	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	

RGV3302010000K TAILING AUGER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3302010000K	TAILING AUGER ASSEMBLY		1	
1	GBT6187. 1-M8-8	FULL METAL HEXAGON FLANGE LOCKING NUT		6	
2	GBT96. 1-8-A3L	LARGE WASHER		5	
3	RGV3302010006K	CHAIN BOX ASSEMBY		1	
3. 1	GBT5789-M6X12-8. 8-A2L	HEX FLANGE BOLTS		8	
3. 2	GBT9877. 1-FB25X40X7D	ROTARY SHAFT LIP SEAL WITH INNER FRAME		1	
3. 3	RV01302000070	COVER		1	
3. 4	RV01302000069	SEAL RUBBER WASHER		1	
3. 5	GBT893. 1-52	RETAINING RING FOR HOLE		1	
3. 6	RV01302000140	BEARING		1	
3. 7	GBT9877. 1-FB30X42X7D	ROTARY SHAFT LIP SEAL WITH INNER FRAME		1	
3. 8	RV01302000068	CHAIN CASE		1	
3. 9	RV01302000081	CHAIN ASSEMBLY		1	
3. 10	RGV3302030012	SPROCKET WHEEL		1	
3. 11	GBT894. 1-25	RETAINING RING FOR SHAFT		1	
3. 12	RV01302000119	BEARING		1	
3. 13	GBT893. 1-47	RETAINING RING FOR HOLE		1	
4	GBT6171-M14X1. 5-8-A3L	TYPE 1 HEX NUT		2	
5	GBT93-14-A3L	STANDARD SPRING WASHER		2	
6	BZF0002. 1-100	ADJUSTING GASKET		2	
7	RGV3302030013	SPROCKET WHEEL		1	
8	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		3	
9	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		4	

RGV3302010000K TAILING AUGER ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
10	GBT5783-M8X16-8.8-A2L	HEX HEAD BOLTS		7	
11	RV01302000024	END COVER		1	
12	RV01302000026	RUBBER SLEEVE		1	
13	RV01302000018	DUSTPROOF COVER		1	
14	RV01302000154	COMPLES SHELL		1	
14.1	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		8	
14.2	GBT93-8-A3L	STANDARD SPRING WASHER		8	
14.3	GBT97.1-8-A3L	FLAT WASHERS		10	
14.4	RV01302000073a	TOOTHED PLATE WELDMENT		1	
14.5	RV01302000023	LINING PLATE		1	
14.6	GBT819.2-M6X16-8.8-A2L	CROSS RECESSED COUNTERSUNK HEAD SCREWS		4	
14.7	RV01302000155	RETHRESHER BOX WELDMENT		1	
14.8	BA150B2.98.1.10	COVER WELDMENT		1	
14.9	RV01302000063	WASHER		4	
14.10	GBT6187.1-M6-8-A2L	FULL METAL HEXAGON FLANGE LOCKING NUT		6	
14.11	Q1980616	BOLT		2	
14.12	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		2	
14.13	RV01302000180	WASHER		2	
15	BA150B2.88-07	SEALING STRIP		1	
16	GBT1096-C8X7X25	FLAT KEY		2	
17	RV01302000150	HORIZONTAL AUGER INSTALLATION		1	
17.1	RV01302000019	WELDED REFRESHING BOARD 1		2	


RGV3302010000K TAILING AUGER ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
17.2	RV01302000021	WELDED REFRESHING BOARD 2		2	
17.3	BA150B2. 89. 7	BOLT M8X20		8	
17.4	HE2001. 17. 2a-06	BALANCING BLOCK		1	
17.5	RV01302000151	HORIZONTAL AUGER WELDMENT		1	
18	RV01302000094	BEARING BLOCK		1	
19	RV01302000140	BEARING		1	
20	DH1381. 21. 3-02	ADJUSTMENT MATS		2	
21	RV01302000017	BELT PULLEY		1	
22	GBT5783-M8X30-8. 8-A2L	HEX HEAD BOLTS		7	
23	GBT93-8-A3L	STANDARD SPRING WASHER		18	
24	GBT97. 1-8-A3L	FLAT WASHERS		19	

LOVOL
ZSJ D13750

RGV3202010000 CYLINDER COVER ASSEMBLY

LOVOL
ZSJ D13750



RGV3202010000 CYLINDER COVER ASSEMBLY


No.	Part No.	Description	Version	QTY.	Remark
	RGV3202010000	CYLINDER COVER ASSEMBLY	005	1	
1	RGV3202010001a	CYLINDER COVER		1	
1.1	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		12	
1.2	GBT93-8-A3L	STANDARD SPRING WASHER		12	
1.3	GBT97.1-8-A3L	FLAT WASHERS		12	
1.4	RGV3202010002b	CYLINDER COVER WELDMENT		1	
1.5	DG2002.13.4	GUIDE GRASS PLATE WELDMENT 2		4	
2	GBT93-8-A3L	STANDARD SPRING WASHER		6	
3	GBT97.1-8-A3L	FLAT WASHERS		6	
4	GBT70.1-M8X20-8.8-A2L	HEXAGON SOCKET HEAD CAP SCREW		6	
5	GBT5783-M6X12-8.8-A2L	HEX HEAD BOLTS		4	
6	DG2007.13B-07	SCREW ROD		3	
7	GBT93-12-A3L	STANDARD SPRING WASHER		3	
8	DG2007.13B-08	PAD		3	
9	DG2002.13.7	PNEUMATIC SPRING		1	
10	GBT91-2X20-A3L	COTTER PIN		2	
11	DG2002.13-10	FRONT/BACK SEAL PIECE		2	
12	DG2002.13-12	RIGHT SEAL STRIP 2		2	
13	RV03202000007	RIGHT SEAL STRIP 1		2	
14	RV03202000006	SEAL STRIP		1	
15	GBT93-6-A3L	STANDARD SPRING WASHER		4	
16	GBT97.1-6-A3L	FLAT WASHERS		4	
17	GBT882-B10X80-A3L	PIN		2	

RGV3202010000 CYLINDER COVER ASSEMBLY (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
18	GBT96. 1-10-A3L	LARGE WASHER		4	
19	GBT91-3. 2X20-A3L	COTTER PIN		2	
20	RGV3202050023a	BRACKET WELDMENT		1	
20.1	GBT70. 1-M8X20-8. 8-A2L	HEXAGON SOCKET HEAD CAP SCREW		2	
20.2	GBT93-10-A3L	STANDARD SPRING WASHER		2	
20.3	RGV3202050024a	BRACKET WELDMENT		1	
20.4	RV01306050281	ARC PLATE WELDING		1	

LOVOL
ZSJ D13750


RGV3205010000K AXIAL FLOW ROLLER ASSEMBLY-1



RGV3205010000K AXIAL FLOW ROLLER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3205010000K	AXIAL FLOW ROLLER ASSEMBLY	001	1	
1	GBT894. 1-50	RETAINING RING FOR SHAFT		1	
2	RGV3205010001K	FRONT RETAINER RING INSTALLATION		1	
2.1	RGV1903160003K	BEARING 6210		1	
2.2	HG2201. 15. 2. 1a	FRONT RETAINER RING WELDMENT		1	
3	RGV3205040001a	CYLINDER INSTALLATION		1	
4	DV01205000069	REAR RETAINER RING WELDMENT		1	
5	RGV3205040022	BEARING		1	
5.1	DV01102000150	DUSTPROOF CAP OF OIL CUP		1	
5.2	JBT7940. 1-M8X1	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
5.3	RGV3205040021	BEARING SEAT		1	
5.4	GBT3882-UEL207-E207	BEARING		1	
5.5	G40. 14. 6-01	ECCENTRIC SLEEVE 207		1	
6	GBT818-M5X16-4. 8-A2L	CROSS RECESSED PAN HEAD SCREWS		2	
7	GBT93-12-A3L	STANDARD SPRING WASHER		4	
8	GBT5783-M12X35-8. 8-A3L	HEX HEAD BOLTS		4	
9	GBT93-5-A3L	STANDARD SPRING WASHER		2	
10	GBT97. 1-5-A3L	FLAT WASHERS		2	
11	DV01205000014	SHIELD		1	

RGV3205010000K AXIAL FLOW ROLLER ASSEMBLY-2



RGV3205010000K AXIAL FLOW ROLLER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3205010000K	AXIAL FLOW ROLLER ASSEMBLY		1	
	RGV3205040001a	CYLINDER INSTALLATION		1	
1	RV03205000012	FEED TAPER BODY INSTALLATION		1	
1.1	GBT70. 1-M8X16-8. 8-A2L	HEXAGON SOCKET HEAD CAP SCREW		28	
1.2	DV01205000008	OUTER VANE		2	
1.3	RV03205000013	FEED TAPER BODY WELDMENT		1	
1.4	DG2002. 15. 1. 2-02	CONNECTINGSEAT		14	
2	GBT5783-M10X35-10. 9-A3L	HEX HEAD BOLTS		6	
3	GBT70. 1-M10X25-8. 8-A3L	HEXAGON SOCKET HEAD CAP SCREW		2	
4	DV01205000065	SPLINE BUSH		1	
5	RGV3205040002a	CYLINDER SHAFT WELDMENT		1	
6	GBT5783-M8X25-8. 8-A2L	HEX HEAD BOLTS		56	
7	GBT97. 1-8-A3L	FLAT WASHERS		60	
8	GBT93-8-A3L	STANDARD SPRING WASHER		60	
9	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		24	
10	RV03205000017	RACK BAR WELDMENT		3	
11	Q72142	PLUG PIECE		1	
12	GBT93-10-A3L	STANDARD SPRING WASHER		14	
13	DV01205000066	SHAFT EMD		1	
14	RV03205000019	RACK BAR WELDMENT		3	
15	RGV3205000005	COUNTERWEIGHT BLOCK		4	
16	RGV3205000004	COUNTERWEIGHT BLOCK		4	
17	RGV3205000003	COUNTERWEIGHT BLOCK		4	


RGV3205010000K AXIAL FLOW ROLLER ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
18	RGV3205000002	COUNTERWEIGHT BLOCK		4	
19	GBT5783-M8X30-8.8-A2L	HEX HEAD BOLTS		4	
20	GBT5783-M10X25-8.8-A3L	HEX HEAD BOLTS		6	
21	GBT97.1-10-A3L	FLAT WASHERS		6	

LOVOL
ZSJ D13750

LOVOL
ZSJ D13750

RGV3208050000 SIEVE BOX ASSEMBLY-1




RGV3208050000 SIEVE BOX ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3208050000	SIEVE BOX ASSEMBLY	012	1	
1	GBT5783-M6X16-8. 8-A2L	HEXAGON BOLT		13	
2	GBT93-6-A3L	STANDARD SPRING WASHER		24	
3	DG2002. 18-02	FRONT PRESSURE PLATE		1	
4	RGV3208050123	HEADBOARD		1	
5	RGV3208050091	GRAIN ADJUSTING PLATE		1	
6	RGV3208050075a	SIEVE BOX WELDMENT		1	
7	RGV3208050073a	MISCELLANEOUS EXTENSION BOARD		1	
8	RGV3208050035a	PRESSURE PLATE		1	
9	GBT97. 1-6-A3L	FLAT WASHER		13	
10	GBT6170-M6-8-A2L	HEXAGON NUT, TYPE-1		11	
11	RGV3208050062	SIDE COMPRESS PLATE		2	
12	RGV3208050121	SIDE BAFFLE		2	
13	GBT93-8-A3L	STANDARD SPRING WASHER		38	
14	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		22	
15	RGV3208050068	PRESSBOARD		1	
16	RGV3208050026	GRAIN SLIDE PLATE		1	
17	GBT5783-M8X16-8. 8-A2L	HEXAGON BOLT		4	
18	RGV3208050053	GRAIN SLIDE PLATE SEAT		1	
19	RGV3208050013	REAR SIDE PANEL		2	
20	RGV3208050066	PRESS PLATE		1	
21	RGV3208050067	PLATE		1	
22	GBT5789-M8X16-8. 8-A2L	HEXAGON FLANGE NUT		18	

RGV3208050000 SIEVE BOX ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		1	
24	GBT96.1-10-A3L	BIG WASHER		1	
25	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		5	
26	GBT93-10-A3L	STANDARD SPRING WASHER		11	

RGV3208050000 SIEVE BOX ASSEMBLY-2




RGV3208050000 SIEVE BOX ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3208050000	SIEVE BOX ASSEMBLY		1	
1	RGV3208050112	SIEVE BOX DRIVE WELDMENT		1	
2	RGV3208050058	SIDE COMPRESS PLATE		2	
3	RGV3208050060	SIDE BAFFLE		2	
4	GBT5783-M6X16-8.8-A2L	HEXAGON BOLT		13	
5	GBT93-6-A3L	STANDARD SPRING WASHER		24	
6	GBT97.1-6-A3L	FLAT WASHER		13	
7	RV02208000125	BEARING		2	
8	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		22	
9	GBT93-8-A3L	STANDARD SPRING WASHER		38	
10	GBT97.1-8-A3L	FLAT WASHER		22	
11	GBT62-M6-A2L	BUTTERFLY NUT		4	
12	DV01208000001	BACKBOARD PLATE		1	
13	DG2002.18-12a	REAR PLASTIC PLATE		1	
14	RGV3208050063	FRONT FINGER SCREEN		1	
15	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		5	
16	GBT5783-M10X30-8.8-A3L	HEXAGON BOLT		10	
17	GBT93-10-A3L	STANDARD SPRING WASHER		11	
18	GBT97.1-10-A3L	FLAT WASHER		4	
19	RGV3208050030	SHIELD WELDMENT		1	
20	GBT16674.1-M6X50-8.8-A2L	HEXAGON FLANGE NUT		1	
21	GBT6177.1-M6-8-A2L	HEXAGON FLANGE NUT		1	
22	GBT16674.1-M6X12-8.8-A2L	HEXAGON FLANGE NUT		1	

LOVOL
ZSJ D13750

RGV3208050000 SIEVE BOX ASSEMBLY-3




RGV3208050000 SIEVE BOX ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV3208050000	SIEVE BOX ASSEMBLY		1	
1	RGV3903060003	BRAIDED SCREEN		1	
2	RGV3208050055	LOWER SIEVE SIDE PLATE		2	
3	GBT93-8-A3L	STANDARD SPRING WASHER		38	
4	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		24	
5	DG2002. 18-19	LOWER SIEVE SPLINT		1	
6	GBT96. 1-8-A3L	BIG WASHER		8	
7	GBT97. 1-6-A3L	FLAT WASHER		13	
8	GBT93-6-A3L	STANDARD SPRING WASHER		24	
9	GBT6170-M6-8-A2L	HEXAGON NUT, TYPE-1		11	
10	GBT5783-M6X20-8. 8-A2L	HEXAGON BOLT		3	
11	DB200A1. 18. 5-01	PLATE		3	
12	RGV3208050025	FRONT PLATE		1	

LOVOL
ZSJ D13750

RGV3208050000 SIEVE BOX ASSEMBLY-4




RGV3208050000 SIEVE BOX ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RGV3208050000	SIEVE BOX ASSEMBLY		1	
1	RGV3208050038	UPPER SCREEN FITTING 1		1	
1.1	GBT91-1.6X16-A3L	SPLIT PIN		28	
1.2	GBT97.1-6-A3L	FLAT WASHER		28	
1.3	RGV3208050042	SELECT THE WELDING OF LOWER PLATE		2	
1.4	RGV3208050044	UPPER CONNECTING PLATE 2		1	
1.5	DV01208000011	SIEVE PIECE WELDMENT		7	
1.6	DV01208000006	ADJUSTING SIEVE PIECE WELDMENT		1	
1.7	RGV3208050041	UPPER CONNECTING PLATE 1		1	
2	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		24	
3	GBT93-8-A3L	STANDARD SPRING WASHER		38	
4	GBT97.1-8-A3L	FLAT WASHER		22	
5	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		22	
6	GBT96.1-8-A3L	BIG WASHER		8	
7	DV01208000002	GUIDE PLATE WELDMENT		2	
8	RGV3208050039	UPPER SCREEN FITTING 2		1	
8.1	GBT91-1.6X16-A3L	SPLIT PIN		32	
8.2	GBT97.1-6-A3L	FLAT WASHER		32	
8.3	RGV3208050048	SELECT THE WELDING OF LOWER PLATE		2	
8.4	RGV3208050049	UPPER CONNECTING PLATE 3		1	
8.5	DV01208000011	SIEVE PIECE WELDMENT		8	
8.6	DV01208000006	ADJUSTING SIEVE PIECE WELDMENT		1	
8.7	RGV3208050051	UPPER CONNECTING PLATE 4		1	

LOVOL
ZSJ D13750

RGV3208050000 SIEVE BOX ASSEMBLY-5




RGV3208050000 SIEVE BOX ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
	RGV3208050000	SIEVE BOX ASSEMBLY		1	
1	RGV3208050018a	TAILING SCREEN ASSEMBLY		1	
1.1	RGV3208050020	TRAILING BAR SCREENING		2	
1.2	GBT6170-M6-8-A2L	HEXAGON NUT, TYPE-1		36	
1.3	GBT93-6-A3L	STANDARD SPRING WASHER		36	
1.4	RGV3208050019	SIEVE PIECE WELDMENT		18	
1.5	RGV3208050021	TAIL SIEVE SUPPORT WELDMENT		1	
1.6	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		1	
1.7	GBT96.1-8-A3L	BIG WASHER		2	
1.8	RGV3208050092	UPPER SUPPORTING PLATE		1	
1.9	RGV3208050093	LOWER SUPPORT PLATE		1	
1.10	GBT93-8-A3L	STANDARD SPRING WASHER		1	
1.11	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		1	
2	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		22	
3	GBT93-8-A3L	STANDARD SPRING WASHER		38	
4	GBT97.1-8-A3L	FLAT WASHER		22	

LOVOL
zsj D13750

RGV3208050000 SIEVE BOX ASSEMBLY-6



RGV3208050000 SIEVE BOX ASSEMBLY-6

No.	Part No.	Description	Version	QTY.	Remark
	RGV3208050000	SIEVE BOX ASSEMBLY		1	
	RGV3208050112	SIEVE BOX DRIVE WELDMENT		1	
1	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		3	
2	GBT93-8-A3L	STANDARD SPRING WASHER		2	
3	GBT97. 1-8-A3L	FLAT WASHER		2	
4	RV01208020003	BALANCING BLOCK 1		1	
5	DG2002. 18. 4. 1a	DRIVE PULLEY WELDMENT		1	
6	GBT1096-8X7X45	FLAT KEY		1	
7	GBT821-M8X25-33H	TIGHTENING SCREW, W/ SQUARE HEAD FLAT END		1	
8	GBT5783-M8X50-8. 8-A2L	HEXAGON BOLT		2	
9	GBT3882-UB205	BEARING		1	
10	GBT1096-8X7X36	FLAT KEY		2	
11	DG2002. 18. 4-05a	BEARING SEAT		2	
12	DV01208000042	SPACER BUSH 1		2	
13	JBT7940. 1-M6	STRAIGHT FORCED FILLING OIL CUP		2	
14	DV01102000149	DUSTPROOF CAP OF OIL CUP		2	
15	GBT6170-M12-8-A3L	HEXAGON NUT, TYPE-1		4	
16	GBT93-12-A3L	STANDARD SPRING WASHER		8	
17	GBT5782-M12X75-8. 8-A2L	HEXAGON BOLT		4	
18	RGV3208050111	ECCENTRIC ASSEMBLY		2	
18.1	RV01208000032	ECCENTRIC WHEEL		1	
18.2	GBT893. 1-90	CIRCLIPS FOR HOLE		1	
18.3	DG2002. 18. 4-07	BEARING 61913-2RLD		1	


RGV3208050000 SIEVE BOX ASSEMBLY-6 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
18.4	RGV3208030003	BEARING SEAT		1	
19	GBT5786-M12X1.25X40-10.9-A2L	HEXAGON BOLT		4	
20	GBT97.1-12-A3L	FLAT WASHER		4	
21	RGV3208030002	ROCKER		2	
22	RV01208020002	DRIVING WHEEL SHAFT		1	
23	RV01208020012	SPACER BUSH		1	
24	DG2004.22-11	BEARING		1	
25	RV01208020004	BALANCING BLOCK 2		1	
26	RV01301000045	WASHER		1	
27	GBT93-14-A3L	STANDARD SPRING WASHER		1	
28	GBT6170-M14-8-A3L	HEXAGON NUT, TYPE-1		1	
29	GBT1096-C8X7X28	FLAT KEY		1	

LOVOL
ZSJ D13750

LOVOL
ZSJ D13750

RGV3209020000 FAN ASSEMBLY-1




RGV3209020000 FAN ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3209020000	FAN ASSEMBLY		1	
1	RGV3209020003	INPUT PULLEY ASSEMBLY		1	
1.1	RGV3209020004	INPUT BELT PULLEY		1	
1.2	RV03209000007	INPUT HUB		1	
1.3	GBT93-12-A3L	STANDARD SPRING WASHER		6	
1.4	GBT5783-M12X35-8.8-A3L	HEX HEAD BOLTS		6	
2	GBT5783-M10X60-8.8-A3L	HEX HEAD BOLTS		1	
3	GBT93-10-A3L	STANDARD SPRING WASHER		1	
4	RGV3209020019a	SPACER 42X7		1	
5	GBT93-8-A3L	STANDARD SPRING WASHER		4	
6	GBT16674.1-M8X20-10.9-A2L	HEX FLANGE BOLTS		4	
7	RGV3209020005a	ROD		1	
8	GBT97.1-8-A3L	FLAT WASHERS		4	
9	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		1	
10	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		8	
11	GBT93-12-A3L	STANDARD SPRING WASHER		12	
12	RGV3209020032	BEARING BLOCK		2	
13	GBT5783-M12X35-8.8-A3L	HEX HEAD BOLTS		8	
14	GBT1096-10X8X70	FLAT KEY		1	
15	RGV3209020008	VANE COMPONENT		1	
16	GBT1096-C10X8X63	FLAT KEY		1	
17	RGV3209020025	LEFT FIXING PLATE		1	
18	GBT5783-M12X30-8.8-A3L	HEX HEAD BOLTS		4	

RGV3209020000 FAN ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
19	GBT97. 1-12-A3L	FLAT WASHERS		4	
20	GBT893. 1-80	RETAINING RING FOR HOLE		2	
21	RGV3209020031	DEEP GROOVE BALL BEARING 6307		2	
22	RGV3209020029	ADJUSTING WASHER		3	
23	RV01209000011	OUTPUT BELT PULLEY		1	
24	DG2002. 29-04b	AXLE GASKET		1	
25	GBT93-16-A3L	STANDARD SPRING WASHER		1	
26	GBT6171-M16X1. 5-8-A3L	TYPE 1 HEX NUT		1	
27	RGV3209020027	WELDING OF PUMMEY SUPPORT ROD		1	
28	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		4	

RGV3209020000 FAN ASSEMBLY-2




RGV3209020000 FAN ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3209020000	FAN ASSEMBLY		1	
	RGV3209020008	VANE COMPONENT		1	
1	RGV3209020020	HEX HEAD BOLTS		4	
2	GBT6171-M10X1.25-8-A2L	TYPE 1 HEX NUT		4	
3	RGV3209020010	SPOKE PLATE		1	
4	RGV3209020009	SHAFT-FAN		1	
5	GBT96.1-8-A3L	LARGE WASHER		16	
6	DG2001.20.1-02	FAN BLADE		4	
7	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		16	
8	GBT93-8-A3L	STANDARD SPRING WASHER		16	
9	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		16	

LOVOL
ZSJ D13750

RGV1702090000K ELECTRICAL ASSEMBLY OF BODY

LOVOL
ZSJ D13750




RGV1702090000K ELECTRICAL ASSEMBLY OF BODY

No.	Part No.	Description	Version	QTY.	Remark
	RGV1702090000K	ELECTRICAL ASSEMBLY OF BODY	002	1	
1	CR3D806070002	SOLENOID PUMP		1	
2	RGV3701030003a	WORKING LAMP		1	
3	RGV3702030002	WORKING LAMP		2	
4	RV01702020004a	CONNECTING LINE		1	
5	DG2002. 51. 2. 3	REVERSE ALARM ASSEMBLY		1	
5. 1	GBT16674. 1-M6X16-8. 8-A2L	HEX FLANGE BOLTS		1	
5. 2	DG2002. 51. 2. 3-01	PARKING ALARM		1	
5. 3	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		1	
6	DG2007. 51. 2. 3	OVERCURRENTTRIPCOIL		2	
7	DV01603000010	PLASTIC FASTENING STRIP		17	
8	RGV1702060001d	CYLINDER BLOCK HARNESS		1	
9	DV01704000002	SUPPORT		1	
10	FT800A. 48L. 106	HARNESS CLAMP		1	
11	GBT16674. 1-M6X16-8. 8-A2L	HEX FLANGE BOLTS		1	
12	GF38B1. 29. 5-05	WIRE CLIP		1	
13	G25A3. 29. 1-01	WIRE CLIP		1	
14	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		2	
15	GBT16674. 1-M8X20-8. 8-A2L	HEX FLANGE BOLTS		2	

LOVOL
ZSJ D13750


RV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-1



RV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RV01215000000	ROLLER TRANSMISSION BOX ASSEMBLY	005	1	
1	GBT16674. 1-M8X20-8. 8-A2L	HEX FLANGE BOLTS		4	
2	RV01215000006a	BRACKET WELDMENT		1	
3	GBT5783-M12X40-8. 8-A3L	HEX HEAD BOLTS		4	
4	DV01215000003	SPLINT WELDMENT		1	
5	DG2001. 28. 3-01	RETURN SPRING OF BRAKE		1	
6	DV01215000002	ADJUSTMENT MATS		2	
7	RV01215000001	ROLLER TRANSMISSION BOX		1	
8	GBT93-12-A3L	STANDARD SPRING WASHER		8	
9	GBT5783-M12X35-8. 8-A3L	HEX HEAD BOLTS		4	

RV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-2



RV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RV01215000000	ROLLER TRANSMISSION BOX ASSEMBLY		1	
	RV01215000010	ROLLER TRANSMISSION BOX ASSEMBLY		1	
1	GBT6171-M16X1.5-8-A3L	TYPE 1 HEX NUT		1	
2	GBT93-16-A0P	STANDARD SPRING WASHER		1	
3	DV01215000017	WASHER I		1	
4	GBT1096-8X7X30	FLAT KEY		1	
5	DV01215000012	REVERSAL BELT PULLEY		1	
6	DV01215000031	RETAINER RING FOR SHAFT 100		1	
7	DV01215000016	HANDLE		1	
8	DV01215000030	REVERSAL ADJUSTING WASHER		1	
9	RV01215000011	WELDING OF INVERTED BRACKET		1	
10	DV01214010010	SEALING RING		1	
11	GBT893.1-80	RETAINING RING FOR HOLE		1	
12	DV01214010100	ADJUSTMENT MATS		1	
13	GBT276-6307	DEEP GROOVE BALL BEARING		2	
14	GBT276-6202-2RS	DEEP GROOVE BALL BEARING		3	
15	GBT5783-M10X30-8.8-A3L	HEX HEAD BOLTS		6	
16	GBT93-10-A0P	STANDARD SPRING WASHER		12	
17	DV01215000037	REVERSAL BOX		1	
18	GBT3452.1-87.5X3.55G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
19	DV01215000040	REVERSAL BEVEL GEAR		1	
20	GBT894.1-35	RETAINING RING FOR SHAFT		1	


RV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
21	DV01215000048	TRANSMISSION BOX		1	
22	GBT894. 1-15	RETAINING RING FOR SHAFT		1	
23	DV01215000026	REVERSAL TENSIONER		1	
24	DV01214010101	ADJUSTMENT MATS		1	
25	DV01214010102	ADJUSTMENT MATS		1	
26	DV01215000010	REVERSAL TRANSMISSION SHAFT		1	

LOVOL

zsj D13750

RV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-3




RV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RV01215000000	ROLLER TRANSMISSION BOX ASSEMBLY		1	
	RV01215000010	ROLLER TRANSMISSION BOX ASSEMBLY		1	
1	DV01214010018	AIR VENT		1	
2	Q673B12	STEEL BAND ELASTIC HOOP		1	
3	DV01214010019	SCREW PLUG		1	
4	GBT3452. 1-17. 0X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
5	GBT5783-M10X25-8. 8-A3L	HEX HEAD BOLTS		6	
6	GBT9877. 1-FB45X70X8D	ROTARY SHAFT LIP SEAL WITH INNER FRAME		1	
7	GBT276-6309	DEEP GROOVE BALL BEARING		1	
8	DV01215000049	OUTPUT SHAFT		1	
9	DV01215000039	DRIVEN BEVEL GEAR		1	
10	RV02215000034	ADJUSTMENT PAD 1		1	
11	GBT276-6407	DEEP GROOVE BALL BEARING		1	
12	GBT3452. 1-132X3. 55G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
13	DV01215000050	END COVER		1	
14	GBT3452. 1-10. 6X1. 80G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		2	
15	9F650-26B230016A0	SCREW PLUG		2	
16	GBT93-10-A0P	STANDARD SPRING WASHER		12	
17	RV02215000035	ADJUSTMENT PAD 2		1	
18	RV02215000036	ADJUSTING GASKET 3		1	

LOVOL
ZSJ D13750

RV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-4



RV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RV01215000000	ROLLER TRANSMISSION BOX ASSEMBLY		1	
	RV01215000010	ROLLER TRANSMISSION BOX ASSEMBLY		1	
1	GBT894. 1-40	RETAINING RING FOR SHAFT		1	
2	DV01215000038	DRIVING BEVEL GEAR		1	
3	DL13402010093	HALF AXIS ADJUSTMENT PAD		1	
4	DV01215000041	INPUT SHAFT		1	
5	GBT1096-10X8X40	FLAT KEY		1	
6	DV01215000027	TENSION ADJUSTING WASHER		1	
7	DV01215000033	RETAINER RING		1	
8	DV01215000028	INPUT SHAFT OIL SEAL		1	
9	DV01215000022	TENSIONER BRACKET		1	
10	DV01215000032	RETAINER RING FOR SHAFT 110		1	
11	GBT5783-M8X16-8. 8-A2L	HEX HEAD BOLTS		1	
12	GBT93-8-A0P	STANDARD SPRING WASHER		1	
13	GBT96. 1-8-A0P	LARGE WASHER		1	
14	RV01215000008	TENSIONER SHAFT		1	
15	GBT893. 1-35	RETAINING RING FOR HOLE		2	
16	GBT276-6202-2RS	DEEP GROOVE BALL BEARING		3	
17	RV01215000004	TENSIONER		1	
18	RV01215000002	BELT PULLEY		1	
19	DV01215000034	WASHER 2		1	
20	GBT93-20-A0P	STANDARD SPRING WASHER		1	
21	GBT6171-M20X1. 5-8-A3L	TYPE 1 HEX NUT		1	

RV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-4 (cont'd.)


No.	Part No.	Description	Version	QTY.	Remark
22	GBT276-6308	DEEP GROOVE BALL BEARING		2	
23	GBT827-2.5X4-A0P	LABEL RIVET		4	
24	RV01215000009	BEARING SPACING SLEEVE		1	
25	DV01215000200	CLASS C NAMEPLATE FOR INNER CEREALS		1	
26	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		1	
27	GBT93-12-A0P	STANDARD SPRING WASHER		1	
28	GBT97.1-12-A0P	FLAT WASHERS		1	

LOVOL

zsj D13750

RGV3403020000K CHASSIS FRAME ASSEMBLY

LOVOL
ZSJ D13750



RGV3403020000K CHASSIS FRAME ASSEMBLY


No.	Part No.	Description	Version	QTY.	Remark
	RGV3403020000K	CHASSIS FRAME ASSEMBLY	001	1	
1	GBT91-5X50-A3L	COTTER PIN		1	
2	GBT97. 1-20-A3L	FLAT WASHERS		3	
3	DG2002. 27-10	PIN		1	
4	GBT882-B10X40-A3L	PIN		1	
5	GBT97. 1-10-A3L	FLAT WASHERS		3	
6	GBT91-3. 2X18-A3L	COTTER PIN		1	
7	GBT5783-M10X20-8. 8-A3L	HEX HEAD BOLTS		2	
8	GBT93-10-A3L	STANDARD SPRING WASHER		4	
9	RGV3403090108	SUPPORT SEAT WELDMENT		1	
10	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		2	
11	GBT16674. 1-M8X16-8. 8-A2L	HEX FLANGE BOLTS		5	
12	RGV3403090268a	FOOT PEDAL		1	
13	HE2001. 27-02	UPPER COVER OF DRIVING AXLE SUPPORT SEAT		2	
14	GBT93-12-A3L	STANDARD SPRING WASHER		8	
15	RGV3403090063a	PULLEY BRACKET WEDMENT		1	
16	GBT16674. 1-M12X30-8. 8-A3L	HEX FLANGE BOLTS		2	
17	RGV3403090215	UPPER PEDAL WELDMENT		1	
18	JBT982-12	COMBINATION GASKET		1	
19	RGV4403020133	SCREW PLUG		1	
20	DG2004. 27-04	RUBBER WASHER 1		2	
21	GBT5782-M10X50-8. 8-A3L	HEX HEAD BOLTS		2	

RGV3403020000K CHASSIS FRAME ASSEMBLY (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
22	RGV3403020001K	CHASSIS WELDMENT		1	
23	GBT5783-M12X30-8.8-A3L	HEX HEAD BOLTS		8	

LOVOL
ZSJ D13750


RGV3303050000K GRAIN TANK ASSEMBLY-1



RGV3303050000K GRAIN TANK ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3303050000K	GRAIN TANK ASSEMBLY	001	1	
1	GBT16674. 1-M8X16-8. 8-A2L	HEX FLANGE BOLTS		11	
2	RGV3303050003K	RAIN TANK UNIT		1	
3	GBT96. 1-8-A3L	LARGE WASHER		2	
4	GBT16674. 1-M6X12-8. 8-A2L	HEX FLANGE BOLTS		2	
5	RGV1303050021K	UPPER COVER UNIT		1	
6	GBT12618-4X12	RIVET		8	
7	RV01303100055	LONG PREEURE PLATE		2	
8	RV01303100056	FRONT UP SIGHT WINDOW		1	
9	GBT5783-M12X40-8. 8-A3L	HEX HEAD BOLTS		2	
10	GBT96. 1-12-A3L	LARGE WASHER		4	
11	DV01303060114	RIGHT SIGHT WINDOW		1	
12	DC2382. 42. 3	BOLT		1	
13	RGV1303050027K	SHIELD		1	
14	RGV3303050001K	LOCKING MECHANISM ASSEMBLY		1	
15	DV01303060071	SHAFT SEAT		2	
16	DV01303060025	FORK WELDMENT		1	
17	DV01303060115	RETAINING RING		1	
18	RV01303060017	ADJUSTING PLATE		1	
19	GBT93-12-A3L	STANDARD SPRING WASHER		2	
20	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		2	
21	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		1	

RGV3303050000K GRAIN TANK ASSEMBLY-2




RGV3303050000K GRAIN TANK ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3303050000K	GRAIN TANK ASSEMBLY		1	
	RGV3303050001K	LOCKING MECHANISM ASSEMBLY		1	
1	GBT5783-M10X25-8. 8-A3L	HEX HEAD BOLTS		4	
2	GBT93-10-A3L	STANDARD SPRING WASHER		4	
3	GBT96. 1-10-A3L	LARGE WASHER		4	
4	DG2007. 14A. 7-04	TENSION SPRING		1	
5	RGV1303050026K	TIE ROD		1	
6	GBT5783-M6X12-8. 8-A2L	HEX HEAD BOLTS		1	
7	GBT93-6-A3L	STANDARD SPRING WASHER		1	
8	GBT96. 1-6-A3L	LARGE WASHER		1	
9	GBT97. 1-12-A3L	FLAT WASHERS		2	
10	DG2007. 14A. 7-01a	HANDLE		1	
11	GBT97. 1-8-A3L	FLAT WASHERS		1	
12	GBT91-2. 5X20-A3L	COTTER PIN		2	
13	DG2007. 14A. 7. 1	LOCKING SEAT WELDMENT		1	

LOVOL
zsj D13750

RGV3303050000K GRAIN TANK ASSEMBLY-3




RGV3303050000K GRAIN TANK ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV3303050000K	GRAIN TANK ASSEMBLY		1	
	RGV3303050003K	RAIN TANK UNIT		1	
1	RV02303000097	ADJUSTING PLATE		2	
2	DV01303060034	FLASHBOARD WELDMENT		2	
3	RV02303000091	SPLITTER PLATE		1	
4	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		2	
5	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		8	
6	RGV3303040080	BRACKET WELDING OF ALARM		1	
7	GBT5789-M8X16-8. 8-A2L	HEX FLANGE BOLTS		10	
8	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		4	
9	GBT6172. 1-M8-04-A2L	HEXAGON THIN NUT		4	
10	RGV3303050002K	GRAIN TANK WELDMENT		1	
11	RGV1303050020K	LONG PULL ROD		2	
12	RDL1303000063	COVER PLATE		1	
13	GBT5789-M6X12-8. 8-A2L	HEX FLANGE BOLTS		8	
14	GBT96. 1-8-A3L	LARGE WASHER		2	

LOVOL
zsj D13750

RGV3303050000K GRAIN TANK ASSEMBLY-4




RGV3303050000K GRAIN TANK ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RGV3303050000K	GRAIN TANK ASSEMBLY		1	
	RGV1303050021K	UPPER COVER UNIT		1	
1	RGV1303050022K	UPPER COVER		1	
1.1	RV02303000122	UPPER COVER WELDING		1	
1.2	RGV1303050023K	UPPER COVER		1	
1.3	Q32208	NUT		2	
2	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		4	
3	DV01303060070	SPRING PIECE		2	

LOVOL
zsj D13750

LOVOL
zsj D13750


RGV3603250000 MULT I-WAY VALVE ASSEMBLY-1



RGV3603250000 MULTI-WAY VALVE ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3603250000	MULTI-WAY VALVE ASSEMBLY	001	1	
1	GBT16674. 1-M6X12-8. 8-A2L	HEX FLANGE BOLTS		8	
2	DG2001. 50. 11	FUEL TANK FIXING STRIP WELDMENT		1	
3	RGV3603120007	HYDRAULIC OIL TANK INSTALLATION		1	
4	DG2009. 50. 6	MULTI-WAY VALVE		1	
5	JBT982-18	COMBINATION GASKET		6	
6	HE2001. 50. 2-02	TRANSITION JOINT		1	
7	RGV3603080003	RUBBER TUBE		1	
8	DV01603000010	PLASTIC FASTENING STRIP		8	
9	HE2001. 50. 2. 5	CONNECTING JOINT -PIPE 8		1	
10	BZF0050. 1-004	END STRAIGHT CONNECTING JOINT		5	
10. 1	BZF0050. 1-0040001	END STRAIGHT THREAD CONNECTOR BODY		1	
10. 2	TS09580010004	O-RING		1	
11	DV01603050050	CYLINDER		1	
12	Q617B18	HEXAGON PLUG		1	
13	GBT70. 1-M10X100-8. 8-A3L	HEXAGON SOCKET HEAD CAP SCREW		1	
14	DG2001. 50-09	RUBBER STRIP		1	

RGV3603250000 MULTI-WAY VALVE ASSEMBLY-2




RGV3603250000 MULTI-WAY VALVE ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3603250000	MULTI-WAY VALVE ASSEMBLY		1	
1	HE2001. 50. 3. 11	OIL TUBE		1	
2	HE2001. 50. 2-01	TRANSITION JOINT		2	
3	JBT982-18	COMBINATION GASKET		6	
4	RV03603000003	JOINT		1	
5	RV03603000002	OIL PIPE ASSEMBLY		1	
6	Q67632	B TYPE WORM DRIVE TYPE HOSE HOOP		4	
7	HE2001. 50. 3-01	OIL RETURNING RUBBER PIPE OF MULTI-WAY VALVE		1	
8	HE2001. 50. 2. 6	CONNECTING JOINT		1	
9	HE2001. 50. 2-03	TRANSITION JOINT		1	
10	GBT70. 1-M8X20-8. 8-A2L	HEXAGON SOCKET HEAD CAP SCREW		2	
11	GBT93-8-A3L	STANDARD SPRING WASHER		7	
12	GBT97. 1-8-A3L	FLAT WASHERS		3	
13	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		3	
14	HF2902. 50. 3. 12	HYDRAULIC OIL TANK BREATHER		1	
14. 1	HF2902. 50. 3. 12-01	BREATH FILTER ELEMENT		1	
15	Q67627	B TYPE WORM DRIVE TYPE HOSE HOOP		1	
16	HF2902. 50. 3-04	BREATH CONNECTING TUBE		1	
17	DV01603020013	BREATH OIL PIPE		1	

LOVOL
ZSJ D13750

RGV3603250000 MULTI-WAY VALVE ASSEMBLY-3



RGV3603250000 MULTI-WAY VALVE ASSEMBLY-3


No.	Part No.	Description	Version	QTY.	Remark
	RGV3603250000	MULTI-WAY VALVE ASSEMBLY		1	
1	GBT70. 1-M12X40-8. 8-A3L	HEXAGON SOCKET HEAD CAP SCREW		4	
2	GBT93-12-A3L	STANDARD SPRING WASHER		4	
3	RV01603040010	ROTARY MOTOR		1	
4	GBT70. 1-M8X25-8. 8-A2L	HEXAGON SOCKET HEAD CAP SCREW		4	
5	GBT93-8-A3L	STANDARD SPRING WASHER		7	
6	RV01603040021	FLANGE JOINT		2	
7	GBT3452. 1-23. 6X1. 80G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		2	
8	RV01603040011	OIL TUBE 1		1	
9	RV01603040013	OIL TUBE 2		1	
10	GBT5783-M8X30-8. 8-A2L	HEX HEAD BOLTS		1	
11	RV01603040020	OIL PIPE FIXING CLAMP		2	
12	RGV3603080002	CONNECTING RUBBER TUBE ASSEMBLY 2		1	
13	RGV3603080001	CONNECTING RUBBER TUBE ASSEMBLY 1		1	
14	BZF0050. 1-004	END STRAIGHT CONNECTING JOINT		5	
14. 1	TS09580010004	O-RING		1	
14. 2	BZF0050. 1-0040001	END STRAIGHT THREAD CONNECTOR BODY		1	
15	GBT16674. 1-M6X12-8. 8-A2L	HEX FLANGE BOLTS		8	
16	3203505D9-L	CABLE TIE		3	
17	RV01603040002	CONTROL VALVE ASSEMBLY		1	
18	RV01603040018	OIL RETURN STEEL PIPE ASSEMBLY		1	
19	Q67516	A TYPE WORM DRIVE TYPE HOSE HOOP		2	

RGV3603250000 MULTI-WAY VALVE ASSEMBLY-3 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
20	RV01603040004	RETURN PIPE		1	
21	RV01603040003	INTAKE PIPE		1	

LOVOL
ZSJ D13750

RGV3603250000 MULTI-WAY VALVE ASSEMBLY-4




RGV3603250000 MULTI-WAY VALVE ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RGV3603120007	HYDRAULIC OIL TANK INSTALLATION		1	
	RGV3603250000	MULTI-WAY VALVE ASSEMBLY		1	
1	GBT70. 1-M5X16-8. 8-A2L	HEXAGON SOCKET HEAD CAP SCREW		6	
2	GBT93-5-A0P	STANDARD SPRING WASHER		6	
3	TA700. 55A. 7-01a	OIL FILLING SCREW PLUG		1	
4	JBT982-33	COMBINATION GASKET		1	
5	DV01603020009	FILLING CAP		1	
6	DV01603020008	RUBBER MAT		1	
7	DV01603020002b	WELDING OF HYDRAULIC OIL TANK		1	
8	WU-40X80	OIL SUCTION FILTER		2	
9	GBT3452. 1-50. 0X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		2	
10	DG2001. 50. 1. 4	OIL SUCTION JOINT WELDMENT		1	
11	GBT93-6-A0P	STANDARD SPRING WASHER		8	
12	GBT5783-M6X20-8. 8-A2L	HEXAGON BOLT		8	
13	Q617B12	HEXAGON PLUG		1	
14	JBT982-12	COMBINATION GASKET		1	
15	RGV4604000005	OIL SUCTION JOINT WELDMENT		1	
16	Q676B16	C-TYPE WORM TRANSMISSION HOSE CLAMP		2	
17	RV01603070012	PIPE		1	

LOVOL
ZSJ D13750

LOVOL
ZSJ D13750


RGV3401020000K WHEEL SYSTEM ASSEMBLY-1



RGV3401020000K WHEEL SYSTEM ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3401020000K	WHEEL SYSTEM ASSEMBLY	005	1	
1	D1681. 26-05	LOCK PIN		2	
2	DG2003K. 26-03	LOCKING PLATE		2	
3	DG2003K. 26-01a	IDLING ROD		2	
4	DV01401020001a	PUSHING BLOCK		2	
5	RV02401000052a	TENSIONER COMBINATION		1	
6	GBT5786-M10X1. 25X25-8. 8-A2L	HEX HEAD BOLTS		4	
7	GBT5785-M14X1. 5X60-8. 8-A3L	HEX HEAD BOLTS		8	
8	GBT93-14-A3L	STANDARD SPRING WASHER		20	
9	GBT97. 1-14-A3L	FLAT WASHERS		20	
10	RGV1401050004K	BEARING WHEEL INSTALLATION		12	
11	RGV3401020005K	REAR GUIDE		2	
12	RGV3401000031	FRONT GUIDE		2	
13	RGV3401010001K	橡胶高齿60履带500X90X56		2	
14	GBT93-10-A3L	STANDARD SPRING WASHER		4	
15	RGV3401000015	BALANCING WHEEL ASSEMBLY		6	
16	GBT5785-M14X1. 5X80-8. 8-A3L	HEX HEAD BOLTS WITH FINE TEETH		12	
17	GBT93-12-A3L	STANDARD SPRING WASHER		14	
18	GBT5786-M12X1. 5X25-8. 8-A3L	HEX HEAD BOLTS		14	
19	RV02401000053a	RIGHT TENSIONER COMBINATION		1	

RGV3401020000K WHEEL SYSTEM ASSEMBLY-2




RGV3401020000K WHEEL SYSTEM ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV1401050004K	BEARING WHEEL INSTALLATION		12	
	RGV3401020000K	WHEEL SYSTEM ASSEMBLY		1	
1	GBT5783-M6X16-8. 8-A2L	HEX HEAD BOLTS		3	
2	GBT93-6-A3L	STANDARD SPRING WASHER		3	
3	RV01401090004	END COVER		1	
4	GBT3452. 1-71. 0X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
5	DG2003K. 26. 1-10	ADJUSTMENT MATS		1	
6	GBT65-M6X8-4. 8-A2L	SLOTTED COLUMN HEAD SCREW		1	
7	DG2003K. 26. 1-01	RETAINING RING		2	
8	RGV1903160007K	BEARING 6306		2	
9	RV01401130005	ROLLERS		1	
10	DG2003K. 26. 1-11	SPACER		1	
11	DV01401060010	OIL SEAL		1	
12	RV01401130006	BEARING WHEEL SHAFT		1	
13	GBT93-12-A3L	STANDARD SPRING WASHER		1	
14	GBT5786-M12X1. 5X25-8. 8-A3L	HEX HEAD BOLTS		1	

LOVOL
ZSJ D13750

RGV3401020000K WHEEL SYSTEM ASSEMBLY-3




RGV3401020000K WHEEL SYSTEM ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV3401020000K	WHEEL SYSTEM ASSEMBLY		1	
	RGV3401000015	BALANCING WHEEL ASSEMBLY		6	
1	GBT5783-M6X16-8. 8-A2L	HEX HEAD BOLTS		3	
2	GBT93-6-A3L	STANDARD SPRING WASHER		3	
3	RGV3401000006	END COVER		1	
4	GBT3452. 1-61. 5X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
5	RGV3401000019	OIL SEAL		1	
6	GBT65-M6X8-4. 8-A2L	SLOTTED COLUMN HEAD SCREW		1	
7	DG2003K. 26. 1-01	RETAINING RING		2	
8	RGV3401000018	BEARING		2	
9	RGV3401000016	BALANCING WHEEL		1	
10	RGV3401000017	SPACER		1	
11	GBT5786-M12X1. 5X25-8. 8-A3L	HEX HEAD BOLTS		1	
12	RV01401130006	BEARING WHEEL SHAFT		1	
13	GBT93-12-A3L	STANDARD SPRING WASHER		1	

LOVOL
zsj D 13750

RGV3401020000K WHEEL SYSTEM ASSEMBLY-4




RGV3401020000K WHEEL SYSTEM ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RGV3401020000K	WHEEL SYSTEM ASSEMBLY		1	
	RV02401000052a	TENSIONER COMBINATION		2	
1	RV03401000062	CRAWLER TENSION WHEEL ASSEMBLY		1	
1.1	GBT802-M20-6	COMBINED COVER NUT		2	
1.2	GBT93-20-A3L	STANDARD SPRING WASHER		2	
1.3	DV01401000048	RETAINING RING		2	
1.4	DV01401060010	OIL SEAL		2	
1.5	GBT67-M6X10-4.8-A2L	SLOTTED PAN HEAD SCREW		1	
1.6	RGV3401000009	DEEP GROOVE BALL BEARING		2	
1.7	DV01401000051a	TENSIONER SHAFT		1	
1.8	RV03401000039a	GUIDE WHEEL		1	
1.9	DG2003K. 26. 1-10	ADJUSTMENT MATS		2	
2	RV02401000057a	PUSH ROD B		1	
3	RV02401000055a	PUSH ROD A		1	

LOVOL
ZSJ D13750

RGV3401020000K WHEEL SYSTEM ASSEMBLY-5




RGV3401020000K WHEEL SYSTEM ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
	RV02401000053a	TENSIONER COMBINATION		2	
	RGV3401020000K	WHEEL SYSTEM ASSEMBLY		1	
1	RV03401000062	CRAWLER TENSION WHEEL ASSEMBLY		1	
1.1	GBT802-M20-6	COMBINED COVER NUT		2	
1.2	GBT93-20-A3L	STANDARD SPRING WASHER		2	
1.3	DV01401000048	RETAINING RING		2	
1.4	DV01401060010	OIL SEAL		2	
1.5	GBT67-M6X10-4.8-A2L	SLOTTED PAN HEAD SCREW		1	
1.6	RGV3401000009	DEEP GROOVE BALL BEARING		2	
1.7	DV01401000051a	TENSIONER SHAFT		1	
1.8	RV03401000039a	GUIDE WHEEL		1	
1.9	DG2003K. 26. 1-10	ADJUSTMENT MATS		2	
2	RV02401000057a	PUSH ROD B		1	
3	RV02401000055a	PUSH ROD A		1	

LOVOL
ZSJ D13750

LOVOL
ZSJ D13750

RGV3504030000K FUEL SUPPLY COMBINATION-1




RGV3504030000K FUEL SUPPLY COMBINATION-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3504030000K	FUEL SUPPLY COMBINATION	001	1	
1	RGV3504030004K	FUEL TANK INSTALLATION		1	
2	GBT5783-M10X35-8.8-A3L	HEX HEAD BOLTS		2	
3	GBT96.1-10-A3L	LARGE WASHER		4	
4	RV03504030008	RUBBER MAT		2	
5	Q67522	A TYPE WORM DRIVE TYPE HOSE HOOP		7	
6	RGV3504020006a	OIL OUTLET PIPE ASSEMBLY		1	
7	RGV3504020008a	ELEC. VALVE CONNECTING HOSE		1	
8	RGV3504030007K	ENGINE OIL INLET PIPE		1	
9	Q67405200	PLASTIC FASTENING STRIP		4	
10	RGV3504030006K	ENGINE OIL RETURN PIPE		1	
11	GBT93-10-A3L	STANDARD SPRING WASHER		2	
12	GBT5789-M10X30-8.8-A2L	HEX FLANGE BOLTS		2	
13	GBT6177.1-M10-8-A3L	HEXAGON FLANGE NUT		3	
14	GBT5783-M10X70-8.8-A3L	HEX HEAD BOLTS		2	
15	GBT5789-M10X16-8.8-A3L	HEX FLANGE BOLTS		2	
16	RGV3504030001K	BRACKET WELDING		1	
17	RV03504030036	RUBBER MAT		2	
18	GBT5783-M10X100-8.8-A3L	HEX HEAD BOLTS		1	
19	GBT5789-M10X55-8.8-A3L	HEX FLANGE BOLTS		1	
20	RV03504030016b	HOOP BELT WELDMENT		1	
21	RV03504030019	RUBBER MAT		1	

RGV3504030000K FUEL SUPPLY COMBINATION-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
22	RV03504030035a	RUBBER WASHER 2		1	
23	JB982-18	COMBINATION GASKET		1	

RGV3504030000K FUEL SUPPLY COMBINATION-2




RGV3504030000K FUEL SUPPLY COMBINATION-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3504030004K	FUEL TANK INSTALLATION		1	
	RGV3504030000K	FUEL SUPPLY COMBINATION		1	
1	RV01504150028	OIL TANK FILLING PORT COVER ASSEMBLY		1	
2	RV01504150027	FILTER MESH ASSEMBLY		1	
3	RGV3504030008K	FUEL TANK WELDING		1	
4	RV03504030005	INDICATOR CONNECTING PIPE , OIL QTY		1	
5	Q67516	A TYPE WORM DRIVE TYPE HOSE HOOP		4	
6	RV03504030052	OIL INDICATOR MARKING		1	
7	RV03504030025	AIR OUTLET PIPE		1	
8	JB982-12	COMBINATION GASKET		1	
9	Q617B12	HEXAGON PLUG		1	

LOVOL
ZSJ D13750

RGV3406000000 SPEED CHANGING CONTROL ASSEMBLY

LOVOL
ZSJ D13750




RGV3406000000 SPEED CHANGING CONTROL ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3406000000	VARIABLE SPEED STEERING ASSEMBLY	001	1	
1	GBT91-3. 2X25-A3L	COTTER PIN		1	
2	GBT97. 1-10-A3L	FLAT WASHERS		1	
3	RV01406000016	CONNECTING JOINT WELDMENT		1	
4	GBT882-B10X26-A3L	PIN		1	
5	RGV3406000003	PULL ROD UNIT		1	
5.1	GBT6171-M10X1. 25-LH-8-A2L	TYPE 1 HEX NUT		2	
5.2	RGV3406000005	LONG PULL ROD		1	
5.3	RGV3406000006	ADJUSTING NUT		1	
5.4	GBT6171-M10X1. 25-8-A2L	TYPE 1 HEX NUT		2	
5.5	RGV3406000004	TIE ROD		1	
5.6	D1681. 35. 2-01a	SELF LUBRICATING BALL JOINT		1	
6	RGV3406000001	SPEED CHANGING CONTROL HANDLE WELDMENT		1	
7	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		1	
8	RV01406000019	HANDLEBALL		1	

RGV3407060000 STEPLESS SPEED CHANGING CONTROL ASSEMBLY

LOVOL
ZSJ D13750




RGV3407060000 STEPLESS SPEED CHANGING CONTROL ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3407060000	STEPLESS SPEED CHANGING CONTROL ASSEMBLY	001	1	
1	DG2001. 35. 6	HANDLESLEEVE		1	
2	GBT6172. 1-M12-04-A3L	HEXAGON THIN NUT		1	
3	DG2001. 35. 5a	WELDED HANDLE BAR		1	
4	D168X. 5. 7-04	TORSION SPRING		1	
5	DG2001. 35-01	BRAKE DISC		2	
6	GBT882-B10X90-A3L	PIN		1	
7	GBT97. 1-10-A3L	FLAT WASHERS		1	
8	GBT91-3. 2X22-A3L	COTTER PIN		1	
9	RV01407010001	STEPLESS SPEED PULL ROD		1	
9. 1	D1681. 35. 2-01a	SELF LUBRICATING BALL JOINT		1	
9. 2	GBT6171-M10X1. 25-8-A2L	TYPE 1 HEX NUT		1	
9. 3	RV01407010002	STEPLESS SPEED PULL ROD		1	
9. 4	GBT6171-M10X1. 25-LH-8-A2L	TYPE 1 HEX NUT		1	
9. 5	DG2001. 35. 2-01a	LEFT-HAND SELF-LUBRICATION BALL CONNECTOR		1	
10	GBT6170-M20-8	TYPE 1 HEX NUT		2	
11	GBT70. 1-M6X25-8. 8-A2L	HEXAGON SOCKET HEAD CAP SCREW		1	
12	GBT93-6-A3L	STANDARD SPRING WASHER		1	
13	RGV3407060003	CONNECTION PLATE		1	
14	BA150B2. 21. 2-02	DISC SPRING		3	
15	DG2001. 35-02	PAD		1	
16	RGV3407060005	ROCKER WELDMENT		1	

LOVOL
zsj D13750


DV01409010000 PARKING BRAKE-1



DV01409010000 PARKING BRAKE-1

No.	Part No.	Description	Version	QTY.	Remark
	DV01409010000	PARKING BRAKE	004	1	
1	DA18027. 40-04	HANDLEBALL		1	
2	DV01409010002	PEDAL LOCKING ROD		1	
3	RGV3409000007	PEDAL HOOK		1	
4	GBT16674. 1-M6X12-8. 8-A2L	HEX FLANGE BOLTS		2	
5	DG2002. 40. 4	PEDAL WELDMENT		1	
6	GBT882-B8X50-A3L	PIN		1	
7	GBT16674. 1-M8X20-8. 8-A2L	HEX FLANGE BOLTS		2	
8	D20011. 40-02	PEDAL LOCKING SPRING		1	
9	GBT97. 1-8-A3L	FLAT WASHERS		2	
10	RGV3409000001	PEDAL SUPPORT WELDMENT		1	
11	DG2002. 40-01	PEDAL RETURN SPRING		1	
12	GBT91-2X25-A3L	COTTER PIN		2	
13	GBT894. 1-16	RETAINING RING FOR SHAFT		1	
14	GBT882-B8X24-A3L	PIN		1	

DV01409010000 PARKING BRAKE-2




DV01409010000 PARKING BRAKE-2

No.	Part No.	Description	Version	QTY.	Remark
	DV01409010004	PARKING BRAKE STEEL WIRE ASSEMBLY		1	
	DV01409010000	PARKING BRAKE		1	
1	D20012. 36. 3-09	SLEEVE TUBE		2	
2	D20012. 36. 3-03	CONNECTING FORK - I		1	
3	DV01409010006	CORE		1	
4	D20012. 36. 3-04	BOLT		1	
5	DV01409010005	CONNECTING FORK 2		1	
6	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		4	
7	D20012. 36. 3-08	RUBBER SLEEVE		2	
8	DV01409010007	FLEXIBLE CABLE SLEEVE		1	
9	D20012. 36. 3-07	BOLT		1	
10	GBT6172. 1-M10-04-A3L	HEXAGON THIN NUT		1	
11	GBT97. 1-10-A3L	FLAT WASHERS		2	
12	D20012. 36. 3-06	NUT		1	
13	D20012. 36. 3-05	PRESSING SPRING		1	

LOVOL
ZSJ D13750

DV01411000000 FLAMEOUT MECHANISM

LOVOL
ZSJ D 13750




DV01411000000 FLAMEOUT MECHANISM

No.	Part No.	Description	Version	QTY.	Remark
	DV01411000000	FLAMEOUT MECHANISM		1	
1	GBT5783-M6X12-8.8	HEX HEAD BOLTS		3	
2	DV01411000002	FIXING PLATE 1		2	
3	DV01411000003	FIXING PLATE 2		1	
4	GBT93-6-A0P	STANDARD SPRING WASHER		3	
5	GBT6170-M6-8-A2L	TYPE 1 HEX NUT		2	
6	GBT5783-M10X20-8.8	HEX HEAD BOLTS		1	
7	GBT93-10-A0P	STANDARD SPRING WASHER		1	
8	DV01411000004	FIXING PLATE 3		1	
9	DV01411000001	FLAMEOUT MECHANISM WIRE ASSEMBLY		1	

DV01416000000 HEADER CLUTCH CONTROL ASSEMBLY

LOVOL
ZSJ D13750




DV01416000000 HEADER CLUTCH CONTROL ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	DV01416000000	HEADER CLUTCH CONTROL ASSEMBLY		1	
1	DG2004. 37-01	HANDLE SLEEVE		1	
2	DV01416000010	COMBINE CLUTCH HANDLE		1	
3	GBT91-3. 2X25-A0P	COTTER PIN		1	
4	GBT97. 1-10-A0P	FLAT WASHERS		1	
5	DV01416000001	CLUTCH SUPPORT SHAFT		1	
6	DV01416000006	FIXING PLATE WELDMENT		1	
7	GBT97. 1-8-A0P	FLAT WASHERS		1	
8	GBT91-3. 2X18-A0P	COTTER PIN		1	
9	GBT97. 1-6-A0P	FLAT WASHERS		1	
10	DV01416000022	LOCK PIN		1	
11	DV01416000008	COMBINE STEEL WIRE ASSEMBLY		1	
12	DV01414000001	PLASTIC FASTENING STRIP		1	
13	Q67405200	PLASTIC FASTENING STRIP		2	
14	DV01416000012	SPRING		1	

RGV3405010000K STEERING LIFTING CONTROL UNIT

LOVOL
ZSJ D13750



RGV3405010000K STEERING LIFTING CONTROL UNIT


No.	Part No.	Description	Version	QTY.	Remark
	RGV3405010000K	STEERING LIFTING CONTROL UNIT	001	1	
1	RV01405010001	STEERING HANDLE BALL		1	
2	DG2001. 33-03	FLEX RUBBER		1	
3	DG2009. 33. 1b	STEERING HANDLE WELDMENT		1	
4	DG2009. 33-01a	TIE ROD		1	
5	GBT91-3. 2X25-A3L	COTTER PIN		1	
6	GBT97. 1-14-A3L	FLAT WASHERS		1	
7	HE2001. 33-02a	CONNECTION PLATE		1	
8	GBT882-B6X28-A3L	PIN		3	
9	D168B. 5. 8. 14	FORK HEAD WELDMENT		3	
10	GBT97. 1-6-A3L	FLAT WASHERS		3	
11	GBT91-2X16-A3L	COTTER PIN		8	
12	GBT882-B5X22-A3L	PIN		4	
13	DG2009. 33-03	TIE ROD		2	
14	GBT97. 1-5-A3L	FLAT WASHERS		5	
15	DG2001. 33-02	GLAND		4	
16	GBT16674. 1-M8X20-8. 8-A2L	HEX FLANGE BOLTS		2	
17	DG2001. 33. 5	SUPPORT PLATE		1	
18	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		2	
19	GBT882-B5X28-A3L	PIN		1	
20	RGV3405010001	HANDLE WELDMENT		1	
21	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		1	
22	RV03405000047	HANDLEBALL		1	

RGV3405010000K STEERING LIFTING CONTROL UNIT (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	RGV3405010003	ROTARY SHAFT WELDMENT		1	
24	DG2009. 33. 5a	HANDLE WELDMENT II		1	
25	DG2009. 33. 2	STEERING PUSHING ROD UNIT		1	
25. 1	DG2001. 35. 2-01a	LEFT-HAND SELF-LUBRICATION BALL CONNECTOR		1	
25. 2	GBT6171-M10X1. 25-LH-8-A2L	TYPE 1 HEX NUT		1	
25. 3	DG2009. 33. 2-01a	TIE ROD		1	
25. 4	GBT6171-M10X1. 25-8-A2L	TYPE 1 HEX NUT		1	
25. 5	D1681. 35. 2-01a	SELF LUBRICATING BALL JOINT		1	

LOVOL
ZSJ D13750


RGV3305010000K UNLOADING BOTTOM AUGER ASSEMBLY-1



RGV3305010000K UNLOADING BOTTOM AUGER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3305010000K	UNLOADING BOTTOM AUGER ASSEMBLY	001	1	
1	RV02305000001	UNLOADING AUGER		1	
2	RV01305030010	ECCENTRIC WHEEL		1	
3	GBT276-61908-2RZ	DEEP GROOVE BALL BEARING		1	
4	GBT894. 1-40	RETAINING RING FOR SHAFT		1	
5	DV01305060022	TRANSMISSION CASE		1	
6	GBT93-10-A3L	STANDARD SPRING WASHER		4	
7	GBT5783-M10X30-8. 8-A3L	HEX HEAD BOLTS		4	
8	GBT1096-C6X6X36	FLAT KEY		1	
9	RGV3305010001	INPUT BELT PULLEY		1	
10	GBT96. 1-12-A3L	LARGE WASHER		1	
11	GBT93-12-A3L	STANDARD SPRING WASHER		1	
12	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		1	
13	RGV3305010002	SPACER		1	

RGV3305010000K UNLOADING BOTTOM AUGER ASSEMBLY-2



RGV3305010000K UNLOADING BOTTOM AUGER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	DV01305060022	TRANSMISSION CASE		1	
	RGV3305010000K	UNLOADING BOTTOM AUGER ASSEMBLY		1	
1	DV01305060026	INPUT SHAFT		1	
2	DV01305060034	GUM COVER		1	
3	HE2001. 25. 5-07	ROTARY SHAFT LIP SEAL		1	
4	GBT893. 1-62	RETAINING RING FOR HOLE		1	
5	DV01306060113	ADJUSTING WASHER		1	
6	HE2001. 25. 5-03	ADJUSTING WASHER		1	
7	GBT276-6007	DEEP GROOVE BALL BEARING		1	
8	DV01305060025	PINION		1	
9	DV01305060023	CABINET		1	
10	GBT276-6204	DEEP GROOVE BALL BEARING		1	
11	GBT893. 1-47	RETAINING RING FOR HOLE		1	
12	DV01305060030	COVER		1	
13	GBT276-6006-2RS	DEEP GROOVE BALL BEARING		1	
14	GBT893. 1-55	RETAINING RING FOR HOLE		1	
15	DV01305060038	ROTARY SHAFT LIP SEAL		1	
16	GBT893. 1-68	RETAINING RING FOR HOLE		1	
17	DV01305060039	ADJUSTING WASHER		1	
18	DV01305060040	ADJUSTING WASHER		1	
19	GBT276-6008	DEEP GROOVE BALL BEARING		1	
20	DV01305060024	BIG TAPER GEAR		1	
21	Q72126	PLUG PIECE		1	

RGV3305010000K UNLOADING BOTTOM AUGER ASSEMBLY-2 (cont'd.)


No.	Part No.	Description	Version	QTY.	Remark
22	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		6	
23	GBT93-8-A3L	STANDARD SPRING WASHER		6	
24	GBT97.1-8-A3L	FLAT WASHERS		6	
25	HE2001.25.5.1-01	BOX COVER		1	

LOVOL

zsj D13750

RGV3502000000K RADIATOR ASSEMBLY

LOVOL
ZSJ D13750



RGV3502000000K RADIATOR ASSEMBLY


No.	Part No.	Description	Version	QTY.	Remark
	RGV3502000000K	RADIATOR ASSEMBLY	001	1	
1	GBT16674. 1-M8X16-8. 8-A2L	HEX FLANGE BOLTS		4	
2	RGV3502020005	REAR SUPPORT WELDMENT		1	
3	GBT6182-M12-9-A3L	HEXAGON LOCKING NUT, TYPE-2		2	
4	Q67657	B TYPE WORM DRIVE TYPE HOSE HOOP		4	
5	RV01502100004	ENGINE WATER OUTLET HOSE		1	
6	RV01502100007	ENGINE WATER INLET HOSE		1	
7	RGV3502020001a	WATER RADIATOR ASSEMBLY		1	
7.1	RGV3502020008a	HEAT SINK		1	
7.2	RGV3502020002a	GUIDE RING		1	
8	RGV3502020003	SUPPORT WELD		1	
9	GBT14-M12X80-4. 8-A3L	BIG CUP HEAD SQUARE NECK BOLT		2	
10	DG2002. 47-05	RUBBER MAT		4	
11	D20010. 47-05	WASHER		2	
12	GBT97. 1-12-A3L	FLAT WASHERS		2	
13	RGV3502020015	Connecting hose		1	
14	Q67405200	PLASTIC FASTENING STRIP		1	
15	TG1204. 13A-09	BREATH RUBBER PIPE		1	
16	Q673B11	STEEL BAND ELASTIC HOOP		3	
17	TB400. 13C. 4	AUXILIARY RADIATOR ASSEMBLY		1	
18	RGV3502030008	FIXING BRACKET		1	
19	GBT5783-M6X16-8. 8-A2L	HEX HEAD BOLTS		2	

RGV3502000000K RADIATOR ASSEMBLY (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
20	GBT97. 1-6-A3L	FLAT WASHERS		2	
21	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		2	

RGV3505000000K MANIFOLDS & INDUCTION SYSTEM

LOVOL
ZSJ D13750




RGV3505000000K MANIFOLDS & INDUCTION SYSTEM

No.	Part No.	Description	Version	QTY.	Remark
	RGV3505000000K	MANIFOLDS & INDUCTION SYSTEM	001	1	
1	RGV3505030007a	AIR FILTER FIXING BRACKET		1	
2	GBT16674. 1-M10X20-8. 8-A3L	HEX FLANGE BOLTS		4	
3	GBT16674. 1-M10X25-8. 8-A3L	HEX FLANGE BOLTS		2	
4	GBT6177. 1-M10-8-A3L	HEXAGON FLANGE NUT		2	
5	RGV3505030010	SUPPORT PLATE		1	
6	Q676127	B TYPE WORM DRIVE TYPE HOSE HOOP		1	
7	RGV3505020001	AIR INLET CONNECTING PIPE		1	
8	SAEJ1508-SLTB56	HOOP		1	
9	RGV3505130002a	AIR FILTER ASSEMBLY		1	
9. 1	RGV3505020004	PRIMARY FILTER		1	
9. 2	RGV3505130003a	AIR FILTER		1	
9. 2. 1	RGV2505010030	MAIN FILTER ELEMENT		1	
9. 2. 2	RGV2505010031	SECURITY FILTER ELEMENT		1	
10	RGV3505040002	SUPPORT PLATE		1	

D1681. 53 FIRE EXTINGUISHER

LOVOL
zsj D13750




D1681. 53 FIRE EXTINGUISHER

No.	Part No.	Description	Version	QTY.	Remark
	D1681. 53	FIRE EXTINGUISHER		1	
1	D1681. 53. 1	FIREEXTINGUISHER		1	
2	D1681. 53. 2	BRACKET WELDMENT		1	
3	GBT97. 1-5-A0P	FLAT WASHERS		2	
4	GBT93-5-A0P	STANDARD SPRING WASHER		2	
5	GBT818-M5X12-4. 8-A2L	CROSS RECESSED PAN HEAD SCREWS		2	

RV03601020000 HEADER HYDRAULIC PRESSURE ASSEMBLY

LOVOL
ZSJ D13750




RV03601020000 HEADER HYDRAULIC PRESSURE ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RV03601020000	HEADER HYDRAULIC PRESSURE ASSEMBLY	003	1	
1	GBT882-B12X70-A3L	PIN SHAFT		2	
2	DV01601000009	REEL CYLINDER ASSY.		2	
3	Q50112	LOCK PIN		2	
4	DV01601000002	REEL CYLINDER PIN		2	
5	RV03601010001	LOCK PIN		4	
6	DV01603050003	CONNECTING JOINT		2	
7	DV01601000008	REEL PIPE		2	
8	GBT5783-M8X35-8.8-A2L	HEXAGON BOLT		3	
9	GBT93-8-A3L	STANDARD SPRING WASHER		3	
10	F600209	SINGLE HOLE PIPE CLAMP		6	
11	DV02601000003	LEFT OIL PIPE ASSEMBLY		1	
12	GBT5789-M6X20-8.8-A2L	HEXAGON FLANGE NUT		2	
13	DC2003K.50-03	PIPE CLAMP		1	
14	DC2003K.50-02	DIFFERENT DIAMETER TEE JOINT 14-18		1	
15	GBT6177.1-M6-8-A2L	HEXAGON FLANGE NUT		2	
16	DV02601000001	RIGHT OIL PIPE ASSEMBLY		1	
17	GBT97.1-8-A0P	FLAT WASHER		3	

RV03602000000 STEERING HYDRAULIC PRESSURE ASSEMBLY

LOVOL
ZSJ D13750



RV03602000000 STEERING HYDRAULIC PRESSURE ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RV03602000000	STEERING HYDRAULIC PRESSURE ASSEMBLY	004	1	
1	Q67632	B TYPE WORM DRIVE TYPE HOSE HOOP		2	
2	HE2001. 50. 2-04	STEERING VALVE OIL RETURN HOSE		1	
3	RV03602000002	HEADER OIL PIPE ASSY.		1	
4	HE2001. 50. 2-01	TRANSITION JOINT		2	
5	JBT982-18	COMBINATION GASKET		6	
6	RV03602000003	HEADER CYLINDER ASSEMBLY		1	
7	DV01603000010	PLASTIC FASTENING STRIP		9	
8	HE2001. 50. 2. 6	CONNECTING JOINT		1	
9	HE2001. 50. 2-03	TRANSITION JOINT		1	
10	SZ25	STEERING CYLINDER		1	
11	GBT93-8-A3L	STANDARD SPRING WASHER		4	
12	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		4	
13	GBT5789-M6X16-8. 8-A2L	HEX FLANGE BOLTS		4	
14	HE2001. 50. 2. 4	STEERING OIL PIPE ASSEMBLY 2		1	
15	TC04400010017	END STRAIGHT THREAD CONNECTOR BODY M18-12		1	
16	DG2009. 50. 1	VALVE		1	
17	HE2001. 50. 2-02	TRANSITION JOINT		3	
18	HE2001. 50. 2. 5	JOINT		3	
19	HE2001. 50. 2. 3	STEERING OIL PIPE ASSEMBLY 1		1	
20	DG2009. 50. 2	OIL RETURN PIPE ASSEMBLY		1	

RGV4604000000 STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY


LOVOL
ZSJ D13750

RGV4604000000 STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV4604000000	STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY	002	1	
1	GBT16674. 1-M10X25-8. 8-A3L	HEX FLANGE BOLTS		2	
2	DV01604000004	FILTER INSTALL BOARD		1	
3	GBT16674. 1-M10X16-8. 8-A3L	HEX FLANGE BOLTS		2	
4	RL05606000007	FILTER ASSEMBLY		1	
5	RV02604000016	OIL FILTER TO HST HOSE		1	
6	DV01603000010	PLASTIC FASTENING STRIP		4	
7	Q67632	B TYPE WORM DRIVE TYPE HOSE HOOP		3	
8	DV01604000003	HST FILTER HOSE		1	
9	HF2901. 50. 4. 6	HST slippage pump		1	
10	RGV4604000002	OIL SUCTION PIPE ASSEMBLY		1	
11	HF2901. 50. 4. 2	HST OIL SUCTION JOINT		2	
12	RGV4604010001	HYDRAULIC STEPLESS SPEED CHANGING ASSEMBLY		1	
13	RV02604000002	RADIATOR		1	
14	DV01604000002	HST OUTPUT PIPE ASSEMBLY		1	
15	HF2901. 50. 4. 7	HST JOINT		1	
16	JBT982-33	COMBINATION GASKET		2	
17	HF2901. 50. 4-01	FILTER OIL OUTLET		2	
18	HE2001. 50. 4-01	OIL RETURN RUBBER HOSE OF RADIATOR		1	
19	RGV4604000007	HST SUCTION PIPE		1	
20	Q67638	B TYPE WORM DRIVE TYPE HOSE HOOP		2	

LOVOL
ZSJ D13750

RGV1306050000K UNLOADING CANISTER ASSEMBLY-1




RGV1306050000K UNLOADING CANISTER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1306050000K	UNLOADING CANISTER ASSEMBLY	001	1	
1	RGV1306020004K	UPPER BOX ASSEMBLY		1	
2	RV01306050055	VERTICAL AUGER WELDMENT		1	
3	RV01306050001	UNLOADING CANISTER WELDMENT		1	
4	GBT5783-M10X30-8.8-A3L	HEX HEAD BOLTS		13	
5	GBT93-10-A3L	STANDARD SPRING WASHER		58	
6	RGV1306020001K	UPPER BOX		1	
7	GBT5783-M10X25-8.8-A3L	HEX HEAD BOLTS		32	
8	GBT97.1-10-A3L	FLAT WASHERS		24	
9	DV01303000096	WASHER		4	
10	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		2	
11	GBT5783-M8X16-8.8-A2L	HEX HEAD BOLTS		5	
12	GBT93-8-A3L	STANDARD SPRING WASHER		7	
13	RV01306050124	RETAINING CLIP		5	
14	RGV1306050002K	REAR BRACKET WELDMENT		1	
15	GBT96.1-10-A3L	LARGE WASHER		26	
16	RV01306050209	BRACKET WELDMENT		1	
17	RV01306050215	FIXED SEAT 2		1	
18	GBT96.1-6-A3L	LARGE WASHER		9	
19	GBT5782-M10X110-8.8-A1L	HEX HEAD BOLTS		2	
20	RGV1306050001K	SUPPORT BEAM WELDMENT		1	
21	GBT5782-M10X75-8.8-A2L	HEX HEAD BOLTS		2	
22	RGV1306050014K	STAY BAR WELDMENT		1	

RGV1306050000K UNLOADING CANISTER ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	RGV1306050006K	REAR BEAM		1	
24	GBT5783-M6X16-8.8-A2L	HEX HEAD BOLTS		15	
25	GBT93-6-A3L	STANDARD SPRING WASHER		15	
26	GBT97.1-6-A3L	FLAT WASHERS		6	
27	RV01306050090	BOTTOM PLATE WELDING		1	
28	RV01306050011	SHIELD		1	
29	RV01306050202	SIDE COVER BOARD		1	
30	RV01306050272	MOTOR PEDESTAL		1	
31	JBT7940.2-45dM6	JOINT TYPE PRESSURE OIL CUP		1	
32	DV01102000149	DUSTPROOF CAP OF OIL CUP		2	
33	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		4	
34	GBT96.1-8-A3L	LARGE WASHER		2	

RGV1306050000K UNLOADING CANISTER ASSEMBLY-2



RGV1306050000K UNLOADING CANISTER ASSEMBLY-2


No.	Part No.	Description	Version	QTY.	Remark
	RGV1306050000K	UNLOADING CANISTER ASSEMBLY		1	
1	GBT5783-M10X30-10.9-A3L	HEX HEAD BOLTS		6	
2	GBT93-10-A3L	STANDARD SPRING WASHER		58	
3	RV01306050223	LEADER UNIT		1	
4	GBT5783-M10X25-8.8-A3L	HEX HEAD BOLTS		32	
5	GBT96.1-10-A3L	LARGE WASHER		26	
6	DV01102000149	DUSTPROOF CAP OF OIL CUP		2	
7	JBT7940.1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
8	RGV3306010006	HOOP		1	
9	GBT97.1-10-A3L	FLAT WASHERS		24	
10	RV01306050219	FIXED SEAT		1	
11	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		2	
12	GBT93-8-A3L	STANDARD SPRING WASHER		7	
13	GBT91-5X36-A3L	COTTER PIN		1	
14	RV01306050048	SCREW BUSH		1	
15	RV01306050124	RETAINING CLIP		5	
16	GBT5783-M8X16-8.8-A2L	HEX HEAD BOLTS		5	
17	RV01306050212	ROCK ARM		1	
18	GBT882-B20X70-A3L	PIN		1	
19	GBT6177.1-M10-10-A3L	HEXAGON FLANGE NUT		7	
20	RV01306050113	WASHER		1	
21	GBT91-5X50-A3L	COTTER PIN		1	
22	GBT5783-M10X35-10.9-A3L	HEX HEAD BOLTS		7	

RGV1306050000K UNLOADING CANISTER ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	RV02306000067	HORIZONTAL UNLOADING CANISTER		1	
24	GBT6170-M10-10-A3L	TYPE 1 HEX NUT		13	
25	GBT5783-M10X30-8.8-A3L	HEX HEAD BOLTS		13	
26	RGV1306030002K	UNLOADING CANISTER ASSEMBLY		1	
27	GBT6177.1-M8-8-A2L	HEXAGON FLANGE NUT		5	
28	RV01306050110	LAMPSHADE		1	
29	GBT5783-M6X16-8.8-A2L	HEX HEAD BOLTS		15	
30	GBT93-6-A3L	STANDARD SPRING WASHER		15	
31	GBT96.1-6-A3L	LARGE WASHER		9	
32	RV01306050102	RETAINING CLIP		1	
33	RV01306050101	STRAW OUTLET COVER		1	
34	RV01306050103	LOCKING CLAMP-LONG		1	
35	RV01306050248	RETAINING RING		1	
36	RV01306050173	GEAR 12 TEETH		1	
37	GBT5783-M10X25-10.9-A3L	HEX HEAD BOLTS		1	
38	GBT97.1-20-A3L	FLAT WASHERS		1	
39	RV02306000069	SHIELD		1	
40	RV02306000062	SHIELD		1	
41	GBT5789-M6X12-8.8-A2L	HEX FLANGE BOLTS		6	

LOVOL
ZSJ D13750

RGV1306050000K UNLOADING CANISTER ASSEMBLY-3



RGV1306050000K UNLOADING CANISTER ASSEMBLY-3


No.	Part No.	Description	Version	QTY.	Remark
	RGV1306050000K	UNLOADING CANISTER ASSEMBLY		1	
	RGV1306020004K	UPPER BOX ASSEMBLY		1	
1	GBT5783-M10X30-8. 8-A3L	HEX HEAD BOLTS		2	
2	GBT93-10-A3L	STANDARD SPRING WASHER		8	
3	GBT97. 1-10-A3L	FLAT WASHERS		5	
4	RV01306050027	RETAINER BODY 2		1	
5	RGV1306020005K	LOWER BOX		1	
5. 1	GBT5783-M8X16-8. 8-A2L	HEX HEAD BOLTS		3	
5. 2	GBT93-8-A3L	STANDARD SPRING WASHER		3	
5. 3	GBT96. 1-8-A3L	LARGE WASHER		1	
5. 4	RV01306050042	INSPECTION WINDOW		1	
5. 5	GBT97. 1-8-A3L	FLAT WASHERS		2	
5. 6	RV01306050036	INSPECTION WINDOW		1	
5. 7	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	
5. 8	JBT7940. 1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
5. 9	RV01306050033	SEAL COVER		1	
5. 10	RV01306050052	VERTICAL BOX (DOWN)		1	
5. 11	RV01306050022	15 TEETH BEVEL GEAR		2	
5. 12	GBT276-6007-2RS	DEEP GROOVE BALL BEARING		2	
5. 13	RV01306050032	WASHER-2		1	
5. 14	GBT893. 1-62	RETAINING RING FOR HOLE		2	
5. 15	RV01306050031	WASHER-1		1	

RGV1306050000K UNLOADING CANISTER ASSEMBLY-3 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
6	GBT5783-M10X16-8.8-A3L	HEX HEAD BOLTS		2	
7	GBT5783-M10X25-8.8-A3L	HEX HEAD BOLTS		2	

LOVOL
ZSJ D13750

RGV1306050000K UNLOADING CANISTER ASSEMBLY-4



RGV1306050000K UNLOADING CANISTER ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RGV1306050000K	UNLOADING CANISTER ASSEMBLY		1	
	RGV1306020001K	UPPER BOX		1	
1	RGV1306020003K	LEVEL BOX BODY		1	
1.1	GBT5783-M8X16-8.8-A2L	HEX HEAD BOLTS		2	
1.2	GBT93-8-A0P	STANDARD SPRING WASHER		2	
1.3	GBT96.1-8-A0P	LARGE WASHER		2	
1.4	RV01306050042	INSPECTION WINDOW		2	
1.5	RV01306050054	LEVEL BOX BODY		1	
1.6	RV01306050033	SEAL COVER		1	
1.7	RV01306050022	15 TEETH BEVEL GEAR		2	
1.8	GBT276-6007-2RS	DEEP GROOVE BALL BEARING		2	
1.9	RV01306050032	WASHER-2		1	
1.10	GBT893.1-62	RETAINING RING FOR HOLE		2	
1.11	RV01306050031	WASHER-1		1	
2	RV01306050170	SEAL RING 210		1	
3	RV01306050062	AUGER		1	
4	RGV1306020002K	VERTICAL BOX		1	
4.1	GBT5783-M8X16-8.8-A2L	HEX HEAD BOLTS		1	
4.2	GBT93-8-A3L	STANDARD SPRING WASHER		1	
4.3	GBT96.1-8-A3L	LARGE WASHER		1	
4.4	RV01306050042	INSPECTION WINDOW		1	
4.5	GBT12613.1-P28X25X30	SLEEVE		1	
4.6	RV01306050033	SEAL COVER		1	

RGV1306050000K UNLOADING CANISTER ASSEMBLY-4 (cont'd.)


No.	Part No.	Description	Version	QTY.	Remark
4. 7	DV01102000149	DUSTPROOF CAP OF OIL CUP		2	
4. 8	JBT7940. 1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		2	
4. 9	RV01306050051	VERTICAL BOX (UPPER)		1	
4. 10	RV01306050022	15 TEETH BEVEL GEAR		2	
4. 11	GBT276-6007-2RS	DEEP GROOVE BALL BEARING		2	
4. 12	RV01306050032	WASHER-2		1	
4. 13	GBT893. 1-62	RETAINING RING FOR HOLE		2	
4. 14	RV01306050031	WASHER-1		1	
5	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		2	
6	GBT93-8-A3L	STANDARD SPRING WASHER		6	
7	RV01306050111	PRESSING PLATE		1	
8	GBT5783-M8X35-8. 8-A2L	HEX HEAD BOLTS		2	
9	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		2	
10	GBT5783-M8X30-8. 8-A2L	HEX HEAD BOLTS		4	
11	RV01306050116	CONNECTION PLATE		4	
12	GBT5782-M10X70-8. 8-A3L	HEX HEAD BOLTS		1	
13	RV01306050114	RETAINER BODY		2	
14	RV01306050197	CONNECTING PLANK 1		1	
15	RV01306050100	CONNECTION PLATE		1	
16	RV01306050118	PAD BOARD 2		1	
17	RV01306050119	PAD BOARD 2		2	
18	RV01306050120	PAD BOARD 3		2	

RGV1306050000K UNLOADING CANISTER ASSEMBLY-4 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
19	RV01306050117	RETAINER BODY		1	
20	GBT93-10-A3L	STANDARD SPRING WASHER		3	
21	GBT5782-M10X85-8.8-A2L	HEX HEAD BOLTS		2	

LOVOL
ZSJ D13750

RGV1306050000K UNLOADING CANISTER ASSEMBLY-5




RGV1306050000K UNLOADING CANISTER ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
	RGV1306050000K	UNLOADING CANISTER ASSEMBLY		1	
1	RV02306000067	HORIZONTAL UNLOADING CANISTER		1	
1.1	RV02306000068	UNLOADING CANISTER WELDMENT		1	
1.2	RV01306050239	HORIZONTAL AUGER WELDMENT		1	
1.3	GBT276-6304-2RS	DEEP GROOVE BALL BEARING		1	
1.4	GBT893.1-52	RETAINING RING FOR HOLE		1	
2	RGV1306030002K	UNLOADING CANISTER ASSEMBLY		1	
2.1	RGV1306030003K	UNLOADING CANISTER WELDMENT		1	
2.2	RV01306050104	HORIZONTAL AUGER WELDMENT-BACK		1	
2.3	RV01306050127	BEARING BLOCK		1	
2.4	GBT276-6004-2RS	DEEP GROOVE BALL BEARING		1	
2.5	GBT893.1-42	RETAINING RING FOR HOLE		1	
2.6	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		2	
2.7	GBT93-8-A3L	STANDARD SPRING WASHER		2	
2.8	GBT97.1-8-A3L	FLAT WASHERS		2	

LOVOL
zsj D13750

RV03605000000 HYDRAULIC PRESSURE ASSEMBLY OF GEAR PUMP

LOVOL
ZSJ D13750




RV03605000000 HYDRAULIC PRESSURE ASSEMBLY OF GEAR PUMP

No.	Part No.	Description	Version	QTY.	Remark
	RV03605000000	HYDRAULIC PRESSURE ASSEMBLY OF GEAR PUMP	003	1	
1	GBT70. 1-M8X20-8. 8-A2L	HEXAGON SOCKET HEAD CAP SCREW		8	
2	GBT93-8-A3L	STANDARD SPRING WASHER		14	
3	GBT97. 1-8-A3L	FLAT WASHERS		8	
4	D1681. 50-01	OIL DRAINAGE CONNECTOR		2	
5	GBT3452. 1-16. 0X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		2	
6	GBT70. 1-M8X35-8. 8-A2L	HEXAGON SOCKET HEAD CAP SCREW		4	
7	RV03605000001	DUALPUMP		1	
8	GBT3452. 1-21. 2X1. 80G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
9	RV01605020001	SUCTION PIPE WELDING		1	
10	GBT70. 1-M8X45-8. 8-A2L	HEXAGON SOCKET HEAD CAP SCREW		2	
11	Q67632	B TYPE WORM DRIVE TYPE HOSE HOOP		2	
12	RV01605040003	OIL SUCTION HOSE		1	
13	DV01603000010	PLASTIC FASTENING STRIP		1	
14	HE2001. 50. 3. 3	OIL PIPE , PUMP VALVE		1	

RGV3506130000K EXHAUST SYSTEM

LOWVOL
ZSJ D13750




RGV3506130000K EXHAUST SYSTEM

No.	Part No.	Description	Version	QTY.	Remark
	RGV3506130000K	MANIFOLDS&EXHAUSTSYSTEM	001	1	
1	RV03506020036a	EXHAUST MANIFOLD ASSY		1	
1.1	GBT5789-M8X20-8.8-A2L	HEX FLANGE BOLTS		3	
1.2	RV03506020028	SHIELD WELDMENT		1	
1.3	RV03506020012b	EXHAUST PIPE WELDMENT		1	
2	GBT16674.1-M10X25-8.8-A3L	HEX FLANGE BOLTS		4	
3	GBT6177.1-M8-8-A2L	HEXAGON FLANGE NUT		1	
4	RV03506020014a	CLAMP 2		1	
5	RGV3506130001K	EXHAUST SILENCER		1	
6	GBT16674.1-M8X30-8.8-A2L	HEX FLANGE BOLTS		1	

RGV1703010000 ELECTRICAL ASSEMBLY OF GRAIN BOX

LOVOL
ZSJ D13750




RGV1703010000 ELECTRICAL ASSEMBLY OF GRAIN BOX

No.	Part No.	Description	Version	QTY.	Remark
	RGV1703010000	ELECTRICAL ASSEMBLY OF GRAIN BOX	001	1	
1	RGV1703010001	HARNESS		1	
2	GBT93-6-A3L	STANDARD SPRING WASHER		4	
3	GBT97. 1-6-A3L	FLAT WASHERS		4	
4	YP4. 30. 3. 11	GRAIN TANK FULL SENSOR		1	
5	DV01603000010	PLASTIC FASTENING STRIP		1	

DV0170400000 HARNESS ASSEMBLY

LOVOL
ZSJ D13750




DV01704000000 HARNESS ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	DV01704000000	HARNESS ASSEMBLY	008	1	
1	DV01704000003	HARNESS OF HEADER		1	
2	DV01603000010	PLASTIC FASTENING STRIP		1	
3	DG2002. 51. 1. 8	WORKING LAMP		1	

RGV3706050000 ACCUMULATOR ASSEMBLY

LOVOL
ZSJ D13750




RGV3706050000 ACCUMULATOR ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3706050000	ACCUMULATOR ASSEMBLY	004	1	
1	HG2201. 51A. 7-02	PRESSURE PLATE		1	
2	HG2201. 51A. 7-01	TIE ROD		2	
3	TG1204. 485. 1	BATTERY ASSEMBLY		1	
4	RGV3706010003	NEGATIVE CABLE		1	
5	G20D1. 34. 12	MAIN POWER SWITCH INSTALLATION		1	
5. 1	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		2	
5. 2	F700020	POWER SWITCH		1	
5. 3	GBT5789-M8X30-10. 9-A2L	HEX FLANGE BOLTS		2	
6	RGV1706000003	POSITIVE CABLE		1	
7	Q67405200	PLASTIC FASTENING STRIP		6	
8	D1681. 51. 4-06	BATTERY BOTTOM PLATE		1	
9	RGV1706000004	BATTERY COVER PLATE		1	
10	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		4	
11	GBT16674. 1-M10X25-8. 8-A3L	HEX FLANGE BOLTS		1	
12	RGV3706010001	BRACKET WELDMENT		1	

RGV3709020000 AWNING FAN ASSEMBLY

LOVOL
ZSJ D13750




RGV3709020000 AWNING FAN ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3709020000	AWNING FAN ASSEMBLY	001	1	
1	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		4	
2	RGV3709020005	AWNING FAN		1	
3	3203505D9-L	CABLE TIE		2	
4	RGV3709020003	FAN HARNESS		1	
5	RGV3709020006	SWITCH		1	
6	GBT16674. 1-M6X16-8. 8-A2L	HEX FLANGE BOLTS		4	
7	Q67405200	PLASTIC FASTENING STRIP		2	

RGV1701100000K ELECTRICAL ASSEMBLY OF CAB

LOVOL
ZSJ D13750



RGV1701100000K ELECTRICAL ASSEMBLY OF CAB


No.	Part No.	Description	Version	QTY.	Remark
	RGV1701100000K	ELECTRICAL ASSEMBLY OF CAB	001	1	
1	GBT96. 1-6-A3L	LARGE WASHER		3	
2	GBT16674. 1-M6X20-8. 8-A2L	HEX FLANGE BOLTS		7	
3	RGV1701070005	IGNITIONLOCK		1	
4	DV01701070005	4-GANG MEMBRANE SWITCH		1	
5	RGV1701050004	CENTRAL ELECTRICAL BOX ASSEMBLY		1	
5. 1	RGV4701020003	BOX		1	
5. 2	RGV4701020004	RELAY		1	
5. 3	RGV4701020005	MINI 12V-70A POWER RELAY		1	
5. 4	RGV4701020006	MINI 12V-40A POWER RELAY		1	
5. 5	RGV4701020007	RELAY		3	
5. 6	TD9600002300	FUSE		3	
5. 7	TD9600001800	FUSE		7	
5. 8	TD9600001900	FUSE		6	
5. 9	TD9600002100	FUSE		5	
5. 10	TD9600002200	FUSE		3	
5. 11	TD9600001200	FUSE		2	
6	GBT818-M6X12-4. 8-A2L	CROSS RECESSED PAN HEAD SCREWS		2	
7	RGV3701030002	HANDLEBALL		1	
8	RGV3701030003a	WORKING LAMP		1	
9	DG2002. 51. 2. 3	REVERSE ALARM ASSEMBLY		1	
9. 1	GBT16674. 1-M6X16-8. 8-A2L	HEX FLANGE BOLTS		1	
9. 2	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		1	

RGV1701100000K ELECTRICAL ASSEMBLY OF CAB (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
9.3	DG2002. 51. 2. 3-01	PARKING ALARM		1	
10	Q67405200	PLASTIC FASTENING STRIP		1	
11	GBT16674. 1-M6X16-8. 8-A2L	HEX FLANGE BOLTS		2	
12	RGV1701100001K	DRIVER' S PANEL HARNESS		1	
13	RGV1701050003	COMBINATION INSTRUMENT		1	
14	DG200A7. 51. 1. 4	HORN BUTTON		1	
15	DV01701050005	SWITCH		3	
16	RV03701000007	SWITCH OF NORMAL CLOSE		1	
17	FT300. 48. 055	STARTING RELAY		1	
18	TC03483010002	HORN ASSEMBLY		1	
19	GBT16674. 1-M8X20-8. 8-A2L	HEX FLANGE BOLTS		1	
20	GBT93-6-A3L	STANDARD SPRING WASHER		2	
21	GMV1802080011	USB		1	

RGV3801020000K AWNING ASSEMBLY

LOVOL
ZSJ D 13750




RGV3801020000K AWNING ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3801020000K	AWNING ASSEMBLY	001	1	
1	GBT5782-M6X40-8. 8-A2L	HEX HEAD BOLTS		4	
2	GBT5782-M6X60-8. 8-A2L	HEX HEAD BOLTS		8	
3	GBT96. 1-6-A3L	LARGE WASHER		16	
4	DB20031. 42-03	RUBBER MAT		6	
5	HE2001. 42A-01	TOP COVER		2	
6	RGV3801170001	BRACKET WELDMENT		1	
6. 1	GBT882-B16X45-A3L	PIN		1	
6. 2	GBT91-4X40-A3L	COTTER PIN		2	
6. 3	RGV3801170002	ADJUSTABLE SUPPORT WELDMENT		1	
6. 4	RGV3801000034	CONNECTING SPAN		2	
6. 5	GBT97. 1-16-A3L	FLAT WASHERS		1	
7	GBT889. 1-M6-8-A2L	HEXAGON LOCK NUTS WITH NON-METALLIC INSERT TYPE 1		2	
8	RGV3801000045b	AWNING BRACKET WELDMENT		1	
9	Q50110	LOCK PIN		8	
10	RGV3801000056	PLUG PIN WELDMENT		2	
11	GBT16674. 1-M10X45-8. 8-A3L	HEX FLANGE BOLTS		2	
12	GBT16674. 1-M10X20-8. 8-A2L	HEX FLANGE BOLTS		7	
13	GBT16674. 1-M10X30-8. 8-A2L	HEX FLANGE BOLTS		2	
14	GBT6177. 1-M10-8-A3L	HEXAGON FLANGE NUT		2	
15	GBT97. 1-10-A3L	FLAT WASHERS		2	

LOVOL
ZSJ D13750

RGV3108010000K BRIDGE ASSEMBLY-1




RGV3108010000K BRIDGE ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3108010000K	BRIDGE ASSEMBLY	001	1	
1	GBT16674. 1-M8X16-8. 8-A2L	HEX FLANGE BOLTS		15	
2	HE2001. 8A-26	FRONT COVER PLATE		1	
3	GBT894. 1-17	RETAINING RING FOR SHAFT		2	
4	DG2002. 8. 9	TENSION SPROCKET ASSEMBLY		4	
4. 1	Q43340	STEEL WIRE RETAINER RING FOR SHAFT		2	
4. 2	DG2002. 8. 9-01	TENSIONER SPROCKET		1	
4. 3	DG2002. 8. 9-02	BEARING		1	
5	DV01108020112	SEAL PLATE		1	
6	Q50108	LOCK PIN		1	
7	GBT6177. 1-M10-8-A3L	HEXAGON FLANGE NUT		10	
8	GBT882-B20X120-A3L	PIN		1	
9	GBT97. 1-20-A3L	FLAT WASHERS		2	
10	GBT91-5X50-A3L	COTTER PIN		1	
11	RGV3108010014	SAFETY COVER OF OIL CYLINDER ASSEMBLY		1	
11. 1	Q50108	LOCK PIN		1	
11. 2	RGV3108010015	CYLINDER HOUSING WELDMENT		1	
11. 3	GBT882-B10X100-A3L	PIN		1	
12	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		4	
13	RV03108000043	SEAL PLATE		1	
14	DG2006. 8-08	BEAD		1	
15	DV01108000133	REAR COVER WELDMENT		1	

RGV3108010000K BRIDGE ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
16	DV01108000011	SMALL BONNET		1	
17	GBT96. 1-8-A3L	LARGE WASHER		5	

RGV3108010000K BRIDGE ASSEMBLY-2



RGV3108010000K BRIDGE ASSEMBLY-2


No.	Part No.	Description	Version	QTY.	Remark
	RGV3108010000	BRIDGE ASSEMBLY		1	
1	RGV3108010036	BRIDGE WELDMENT		1	
1.1	RGV3108010001d	BRIDGE WELDMENT		1	
1.2	DV01108000012	GUIDE RUNNER		2	
1.3	GBT16674.1-M8X25-8.8-A2L	HEX FLANGE BOLTS		4	
2	GBT16674.1-M8X16-8.8-A2L	HEX FLANGE BOLTS		15	
3	GBT96.1-8-A3L	LARGE WASHER		5	
4	RGV3108010010	COVER INSTALLATION		1	
4.1	GBT5789-M8X16-8.8-A2L	HEX FLANGE BOLTS		3	
4.2	RGV3108010011	SHIELD		1	
4.3	RGV3108010013	COVER		1	
5	GBT6170-M14-8-A3L	TYPE 1 HEX NUT		4	
6	DG2006.8.6	TENSION INSTALLATION		1	
6.1	DG2006.8.6.1	SCREW ROD		1	
6.2	GBT97.1-18-A3L	FLAT WASHERS		1	
6.3	GBT91-3.2X28-A3L	COTTER PIN		1	
6.4	GBT882-B16X35-A3L	PIN		1	
6.5	DG2006.8.6.3	TENSION BRACKET ASSEMBLY		1	
6.5.1	DG2006.8.6.2	TENSIOING SUPPORT WELDED PART		1	
6.5.2	DG2002.8.2a-01	SLEEVE		2	
6.6	DG2002.2A.2-03	SPRING		1	
6.7	GBT97.1-16-A3L	FLAT WASHERS		1	
6.8	DG2006.8.6-01	CONNECTION PLATE		1	

RGV3108010000K BRIDGE ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
6.9	DG2006.8.6-02	BUSH 2		1	
6.10	DG2006.8.6.1	SCREW ROD		2	
6.11	DG2002.8.9	TENSION SPROCKET ASSEMBLY		1	
7	GBT91-4X32-A3L	COTTER PIN		1	
8	RV03108000045	FEED INLET BAFFLE		1	
9	GBT16674.2-M16X1.5X45-8.8-A3L	HEX FLANGE BOLTS		5	
10	DV01108020039	AXLE GASKET		5	
11	GBT97.1-20-A3L	FLAT WASHERS		2	

LOVOL
ZSJ D13750

RGV3108010000K BRIDGE ASSEMBLY-3



RGV3108010000K BRIDGE ASSEMBLY-3


No.	Part No.	Description	Version	QTY.	Remark
	RGV3108010000K	BRIDGE ASSEMBLY		1	
1	GBT6170-M14-8-A3L	TYPE 1 HEX NUT		4	
2	GBT93-14-A3L	STANDARD SPRING WASHER		2	
3	HG2007. 8-04	RETAINING RING		2	
4	RV01108020001	ACTIVE PULLEY		1	
5	GBT893. 1-62	RETAINING RING FOR HOLE		2	
6	DG2006. 8-10	ADJUSTMENT MATS		1	
7	DV01108000009	RETAINING RING		2	
8	RDL1301000036	BEARING		2	
9	GBT5783-M16X50-8. 8-A3L	HEX HEAD BOLTS		6	
10	GBT93-16-A3L	STANDARD SPRING WASHER		8	
11	DG2002. 8. 4	IDLE GEAR CONNECTING SEAT INSTALLATION		1	
11. 1	DG2002. 8. 4-01a	IDLE GEAR CONNECTING SEAT		1	
11. 2	DG2002. 8. 4-02	SLEEVE		1	
11. 3	JBT7940. 1-M8X1	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
11. 4	DV01102000150	DUSTPROOF CAP OF OIL CUP		1	
12	RV03108000064	14-TOOTH SPROCKET WHEEL		2	
13	DV01108000215	ANTI-WRAP CYLINDER		1	
13. 1	DV01108000216	ANTIWRAP CYLINDER		2	
13. 2	DV01108000218	FIXING PIPE		1	
13. 3	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		6	
13. 4	GBT93-8-A3L	STANDARD SPRING WASHER		6	
13. 5	GBT97. 1-8-A3L	FLAT WASHERS		6	

RGV3108010000K BRIDGE ASSEMBLY-3 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
14	GBT1096-C10X8X50	FLAT KEY		1	
15	DV01108000420	DRIVING SHAFT		1	
16	GBT1096-C8X7X70	FLAT KEY		1	
17	DV01108000424	SCREW		2	
18	GBT6171-M12X1.25-8-A2L	TYPE 1 HEX NUT		2	
19	DG2002.8.15	IDLE GEAR CONNECTING SEAT INSTALLATION		1	
19.1	DG2002.8.15-01a	IDLE GEAR CONNECTING SEAT		1	
19.2	DG2002.8.4-02	SLEEVE		1	
20	RV03108000023	18-TOOTH CHAIN PULLEY		1	
21	DV01108000004	REVERSAL PULLEY		1	
22	GBT6170-M16-8-A3L	TYPE 1 HEX NUT		2	
23	GBT900-AYM16-M16X40-10.9-A3L	STUD		2	
24	JBT7940.1-M8X1	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
25	DV01102000150	DUSTPROOF CAP OF OIL CUP		1	
26	DV01108000425	ADJUSTMENT MATS		1	

LOVOL
ZSJ D 13750

RGV3108010000K BRIDGE ASSEMBLY-4




RGV3108010000K BRIDGE ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RGV3108010000K	BRIDGE ASSEMBLY		1	
1	RGV3108010002K	CHAIN HARROW INSTALLATION		1	
1.1	GBT5783-M10X25-8.8-A3L	HEX HEAD BOLTS		56	
1.2	RGV3108010009	CHAINHARROW		14	
1.3	RGV3108010003K	CHAIN HARROW CONVEYOR		2	
1.4	GBT6187.1-M10-8-A3L	FULL METAL HEXAGON FLANGE LOCKING NUT		56	
2	GBT96.1-8-A3L	LARGE WASHER		5	
3	GBT16674.1-M10X25-8.8-A3L	HEX FLANGE BOLTS		8	
4	GBT96.1-10-A3L	LARGE WASHER		16	
5	GBT16674.1-M8X20-8.8-A2L	HEX FLANGE BOLTS		4	
6	GBT6177.1-M10-8-A3L	HEXAGON FLANGE NUT		10	
7	RV03108000055	ANTIWRAP BOARD		2	

LOVOL
ZSJ D13750

RGV3108010000K BRIDGE ASSEMBLY-5




RGV3108010000K BRIDGE ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
	RGV3108010000K	BRIDGE ASSEMBLY		1	
1	RV03108000083	DRIVEN ROLLER		1	
1.1	RV03108000084	CYLINDER COVER WELDMENT		1	
1.2	GBT276-6204-2RS	DEEP GROOVE BALL BEARING		2	
1.3	RV03108000066	CYLINDER BODY WELDMENT		1	
1.4	RV03108000086	CYLINDER END COVER WELD 2		1	
2	RGV3108010019	WASHER		4	
3	GBT16674. 1-M12X35-8. 8-A3L	HEX FLANGE BOLTS		6	
4	RV03108000069	SCREW WELDMENT		2	
5	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		4	

LOVOL
ZSJ D13750

RGV3803000000 SEAT INSTALLATION ASSEMBLY

LOWELOW
ZSJ D 13750




RGV3803000000 SEAT INSTALLATION ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3803000000	SEAT INSTALLATION ASSEMBLY	003	1	
1	RV01803020001	SEAT		1	
2	GBT16674. 1-M8X20-8. 8-A2L	HEX FLANGE BOLTS		4	

LOVOL
ZSJ D13750


RGV3804010000 COVER ASSEMBLY-1



RGV3804010000 COVER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3804010000	COVER ASSEMBLY	010	1	
1	RGV3804010009	ADJUSTING WASHER		2	
2	RV03804020021	UPPER SHIELD ASSEMBLY		1	
3	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		1	
4	GBT6177. 1-M8-10-A2L	HEXAGON FLANGE NUT		4	
5	RGV3804080001	FRONT BONNET		1	
6	RV03804000014	SEAL STRIP-1		2	
7	RV01804000042	SEAL STRIP-2		2	
8	RV03804000021	HINGE COMPONENT		3	
9	DV01804000024a	PNEUMATIC SPRING		1	
10	GBT91-2. 5X20-A3L	COTTER PIN		1	
11	GBT97. 1-8-A3L	FLAT WASHERS		1	
12	RGV3804010003a	WELDING PF GRAIN GUIDE BIN		1	
13	RV03804020005	FRONT LOWER SHIELD ASSEMBLY		1	
14	GBT16674. 1-M8X20-8. 8-A2L	HEX FLANGE BOLTS		15	
15	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		1	
16	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		5	
17	GBT16674. 1-M8X16-8. 8-A2L	HEX FLANGE BOLTS		4	
18	GBT93-8-A3L	STANDARD SPRING WASHER		1	

RGV3804010000 COVER ASSEMBLY-2




RGV3804010000 COVER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3804010000	COVER ASSEMBLY		1	
1	RV03804020009	CLASP HANDS		4	
2	RV03804020008	CLASP HANDS		2	
3	RGV2804010030	BUTTERFLY BOLT		1	
4	RGV3804010007	LEFT REAR LOWER SHIELD ASSEMBLY		1	
4.1	RGV3804010008	LEFT REAR LOWER SHIELD WELDMENT		1	
4.2	RV02804010061	LEFT REAR LOWER SHIELD		1	
5	RGV3804010001	LEFT FRONT LOWER SHIELD ASSEMBLY		1	
5.1	RGV3804010002	LEFT FRONT LOWER SHIELD FRAME WELDING		1	
5.2	RV02804010063	LEFT FRONT LOWER SHIELD		1	
6	RV03804020021	UPPER SHIELD ASSEMBLY		1	
6.1	RV03804020023	LEFT FRONT UPPER SHIELD		1	
6.2	RV03804020024	LEFT REAR UPPER SHIELD		1	
6.3	RV03804020025	UPPER SHIELD WELDMENT		1	
7	GBT818-M4X10-4.8-A2L	CROSS RECESSED PAN HEAD SCREWS		6	
8	GBT97.1-4-A3L	FLAT WASHERS		6	
9	GBT93-4-A3L	STANDARD SPRING WASHER		6	

LOVOL
ZSJ D13750

RGV3805000000 REARVIEW MIRROR ASSEMBLY

LOWVOL
ZSJ D13750




RGV3805000000 REARVIEW MIRROR ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3805000000	REARVIEW MIRROR ASSEMBLY	001	1	
1	DG2001. 31. 2	LEFT REAR MIRROR ASSEMBLY		1	
2	GBT16674. 1-M8X25-8. 8-A2L	HEX FLANGE BOLTS		2	
3	GBT16674. 1-M8X50-8. 8-A2L	HEX FLANGE BOLTS		2	
4	RGV3805000010	RIGHT REAR MIRROR ASSEMBLY		1	
5	GBT6187. 1-M8-8	FULL METAL HEXAGON FLANGE LOCKING NUT		2	

RV0180600000a REAR TAIL LADDER ASSEMBLY

LOVOL
ZSJ D13750




RV01806000000a REAR TAIL LADDER ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RV01806000000a	REAR TAIL LADDER ASSEMBLY	003	1	
1	DV01901000015	SIGN		1	
2	GBT5783-M10X20-8.8-A3L	HEX HEAD BOLTS		6	
3	GBT93-10-A3L	STANDARD SPRING WASHER		6	
4	GBT97.1-10-A3L	FLAT WASHERS		6	
5	RV01806000001a	REAR TAIL BONNET WELDMENT		1	
6	G2013.51.1-10	SAFETY WARNING SIGN		3	
7	RGV3806000010	BEZEL WELDING		1	

RGV3802030000K DRIVER' S PANEL ASSEMBLY

LOVOL
ZSJ D 13750




RGV3802030000K DRIVER' S PANEL ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3802030000K	DRIVER' S PANEL ASSEMBLY	001	1	
1	RGV3802020028	AUTO PRETECTED STRIPE		1	
2	GBT16674. 1-M8X20-8. 8-A2L	HEX FLANGE BOLTS		16	
3	GBT16674. 1-M10X30-8. 8-A2L	HEX FLANGE BOLTS		3	
4	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		21	
5	RGV3802000003K	LEFT CONSOLE WELDMENT		1	
6	RGV3503040012	AGRAFFE		1	
7	GBT16674. 1-M6X16-8. 8-A2L	HEX FLANGE BOLTS		16	
8	RGV3802020024	SUPPORT PLATE WELDMENT		1	
9	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		6	
10	GBT96. 1-10-A3L	LARGE WASHER		1	
11	GBT96. 1-6-A3L	LARGE WASHER		14	
12	RGV3802020082	LEFT BEZEL		1	
13	RGV3802020012a	BRACKET WELDING		1	
14	RGV3802030001K	RIGHT RETAINER PLATE WELDMENT		1	
15	RGV3802020019a	BEZEL		1	
16	RGV3802000009K	DRIVER' S PANEL WELDMENT		1	
17	RGV3802020016	CONNECTION PLATE		1	
18	RGV3802020050	WELDING OF HANDRAILS		1	
19	GBT16674. 1-M8X16-8. 8-A2L	HEX FLANGE BOLTS		9	
20	GBT16674. 1-M6X45-8. 8-A2L	HEX FLANGE BOLTS		2	
21	RV02802020055	COTTON PAD 3		1	
22	GBT16674. 1-M8X30-8. 8-A2L	HEX FLANGE BOLTS		1	

RGV3802030000K DRIVER' S PANEL ASSEMBLY (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	GBT16674. 1-M6X20-8. 8-A2L	HEX FLANGE BOLTS		4	
24	DV01802000027	SUPPORT BENDING PLATE		1	
25	DG2001. 32-03	STELPLESS SPEED CHANGING LIMIT PLATE		1	
26	RGV3802020005a	LEFT POLE WELDMENT		1	
27	DG2001. 32-07	SPRING WASHER		1	
28	DG2001. 32-10	SWITCH CONTACT		1	
29	RGV3802020080	BREATHING BRACKET		1	
30	GBT16674. 1-M8X35-8. 8-A2L	HEX FLANGE BOLTS		2	
31	GBT16674. 1-M8X45-8. 8-A2L	HEX FLANGE BOLTS		3	
32	GBT6170-M10-10-A3L	TYPE 1 HEX NUT		1	
33	GBT93-10-A3L	STANDARD SPRING WASHER		1	


RGV3501280000K ENGINE ASSEMBLY



RGV3501280000K ENGINE ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3501280000K	ENGINE ASSY	001	1	
1	GBT6171-M12X1.25-10-A2L	TYPE 1 HEX NUT		8	
2	GBT93-12-A3L	STANDARD SPRING WASHER		8	
3	RV01501040010	SUPPORT SEAT WELDMENT		1	
4	GBT16674.1-M10X20-10.9-A3L	HEX FLANGE BOLTS		16	
5	BA150B2.1.6	DAMPER WASHER COMBINATION		4	
6	GBT96.1-12-A3L	LARGE WASHER		4	
7	RGV3501080003	SUPPORT SEAT WELDMENT		2	
8	RV01501040007	SUPPORT SEAT WELDMENT		1	
9	RGV3501280001K	DIESEL ENGINE		1	
9.1	2409532610301	Oil filter element		1	
9.2	1408502810102	Fine fuel filter element		1	
9.3	2409532810101	Fuel water separator filter element		1	

RGV3501280000K ENGINE ASSEMBLY-1




RGV3501280000K ENGINE ASSEMBLY-1 (1)

No.	Part No.	Description	Version	QTY.	Remark
2	Q150B0825	HEX HEAD BOLTS		5	
3	Q40308	WASHER 8		7	
4	Q40108	WASHER 8		5	
5	2409000130000	READ OIL SEAL PARTS		1	
6	2409000101903	REAR OIL SEAL COVER GASKET		1	
7	Q5220820	CYLINDRICAL PIN		3	
8	Q5221022	CYLINDRICAL PIN		2	
9	1409020311400	SCREW PLUG		2	
10	2409000110700	PLUG		6	
11	1408500300403	OIL PRESSURE SENSOR		1	
18	2409000110300	PLUG #60		1	
19	2409530110200	REAR BUSH OF CAMSHAFT		1	
20	2409500102900	CYLINDER COVER LOCATING BUSH		2	
21	2409830100201	CYLINDER BUSH		4	
23	2409530100400	CYLINDER HEAD BOLT II		4	
24	2409000100300	BOLT		14	
25	2409830100501	CYLINDER COVER GASKET		1	
26	2409830110102	CYLINDER BLOCK		1	
27	1408500310200	BOWL PLUG #30		8	
30	2409530110500	MIDDLE BUSH OF CAMSHAFT		1	
31	2409530110600	FRONT BUSH OR CAMSHAFT		1	
32	Q1840825	HEX HEAD BOLTS		2	
33	2409530102602-C	MAIN BEARING		5	
34	2409530102602-C(2)	MAIN BEARING		5	
35	2409530110800	MAIN BEARING COVER		3	
36	2409530102200-C	CRANKSHAFT THRUST PIECE		2	
37	2409530102200-C(2)	CRANKSHAFT THRUST PIECE		2	

RGV3501280000K ENGINE ASSEMBLY-1 (2)

38	2409530110400	REAR MAIN BEARING COVER	1
39	2409530110900	MAIN BEARING COVER BOLT	10
40	2409530111200	FRONT MAIN BEARING COVER	1
41	2410200210300	PLUG $\phi 35$	2
42	2409500310400	BOWL TYPE STOPPER PATCH 25	2
43	2409000101300	WATER INLET PIPE GASKET	1
44	2409000101223	WATER INLET PIPE	1
45	2409000700910	ANTERIOR BRANCH	2
46	Q150B1025	HEX HEAD BOLTS	4
47	Q40310	SPRING WASHER	4


RGV3501280000K ENGINE ASSEMBLY-2



RGV3501280000K ENGINE ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
1	2409530200800	CAMSHAFT THRUST PLATE		1	
2	Q40308 (2)	SPRING WASHER		4	
4	Q150B0820	HEX HEAD BOLTS		2	
5	2409000200400	TIMING IDLE GEAR SHAFT		1	
6	2409530210200	TIMING IDLE GEAR BUSH		1	
7	2409000201400	OIL INJECTION PUMP TIMING GEAR CONNECTING PLATE		1	
8	2409000200300	OIL INJECTION PUMP TIMING GEAR		1	
9	2409530210100	TIMING IDLE GEAR		1	
10	2409530201200	IDLE GEAR SHAFT PRESS PLATE		1	
11	Q150B0855	HEX HEAD BOLTS		2	
12	2409530200900	CAMSHAFT TIMING GEAR		1	
13	2409000200700	CRANKSHAFT TIMING GEAR		1	
14	2410200500600	CAMSHAFT TIMING GEAR PRESSURE PLATE		1	
15	Q40312	SPRING WASHER		1	
16	Q150B1235	HEX HEAD BOLTS		1	
17	Q1840820	HEX FLANGE BOLTS		4	

RGV350128000K ENGINE ASSEMBLY-3




RGV350128000K ENGINE ASSEMBLY-3(1)

No.	Part No.	Description	Version	QTY.	Remark
1	Q2841010	SCREW		2	
2	Q43118	RETAINING RING FOR SHAFT		2	
3	2409000320100	GASKET		6	
4	2409000321000	VALVE ROCKER		8	
5	2409500320600	ROCKER SHAFT		1	
6	Q150B1065	HEX HEAD BOLTS		9	
7	Q40310(2)	SPRING WASHER		9	
8	2409500320700	REAR ROCKER ARM SEAT		1	
9	1408500220300	VALVE CLEARANCE ADJUSTING NUT		8	
10	2409000320301	VALVE CLEARANCE ADJUSTING SCREW		8	
11	2409000320500	VALVE ROCKER SPRING		3	
12	2409500320400	ROCKER SEAT		4	
13	2409500310300	BOWL PLUG #20		3	
14	2409530301100-C	VALVE OIL SEAL		8	
15	2409530300700	VALVE SPRING UPPER SEAT		8	
16	2409530300600-C	VALVE COLLET		16	
17	2409000300400-C	Valve spring		8	
18	2409000300400-C(2)	Valve spring		8	
19	2409530310200	AIR INLET VALVE GUIDE PIPE		4	
19	2409530311100-C	EXHAUST VALVE GUARD PIPE		4	
20	2409000300304	EXHAUST PIPE GASKET		4	
21	2409000300901	STATIONARY RING (POSTERIOR)		1	
22	2409000301300	REAR END COVER GASKET		1	
23	2409000301200	REAR END COVER		1	
24	Q40308(3)	WASHER 8		4	
25	Q1840820(2)	HEX FLANGE BOLTS		5	
26	2409530310100	CYLINDER COVER		1	
27	2409000300204	AIR INLET PIPE GASKET		4	

RGV3501280000K ENGINE ASSEMBLY-3 (2)

28	2410200110800	BOWL PLUG #30	4
29	2409530310701-C	AIR INLET VALVE SEAT	4
30	2409530301400	AIR INLET VALVE	4
31	2409530310801-C	EXHAUST VALVE SEAT	4
32	2409530301500-C	EXHAUST VALVE	4
33	Q150B0820(2)	HEX HEAD BOLTS	4
34	2409000300900	STATIONARY RING (ANTERIOR)	1
37	2408000301100	OIL INJECTOR PRESSURE PLATE	4
38	2408000300101	OIL INJECTOR PRESSURE PLATE BOLT	4
39	3408525100502	HEAT PLUG	4
40	3409020201001	HEAT PLUG CONNECTING WIRE	3
41	3409020201109	HEAT PLUG CONNECTING WIRE	1


RGV3501280000K ENGINE ASSEMBLY-4



RGV3501280000K ENGINE ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
1	2409830410002	PISTON RING PARTS		4	
2	2409830410002 (2)	PISTON RING PARTS		4	
3	2409830410002 (3)	PISTON RING PARTS		4	
4	2409830400107	PISTON		4	
5	Q43034	CIRCLIPS FOR HOLE		8	
6	2409830400400	PISTON PIN		4	
7	2409830420000	Connecting rod assembly		4	
8	2409830420000 (2)	Connecting rod assembly		4	
9	2409830420301-C	CONNECTING ROD BEARING		4	
10	2409830420301-C (2)	CONNECTING ROD BEARING		4	
11	2409830420000 (3)	Connecting rod assembly		4	
12	2409830420500	CONNECTING ROD BOLT		8	
13	2409830420700	ORIENTATION PIN		8	


RGV350128000K ENGINE ASSEMBLY-5



RGV3501280000K ENGINE ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
1	1408500600500	FLYWHEEL BOLT		6	
2	Q5221025	CYLINDRICAL PIN		1	
3	2409000510106	FLYWHEEL		1	
4	2409000510200-H	FLYWHEEL GEAR RING		1	
5	2409530500402	CRANKSHAFT		1	
6	Q5511263	STRAIGHT KEY		1	
7	2409000500637	CRANKSHAFT BELT PULLEY		1	
8	1408500600200	PULLEY PRESSURE WASHERS		1	
9	2410200400701	BOLT		1	


RGV350128000K ENGINE ASSEMBLY-6



RGV3501280000K ENGINE ASSEMBLY-6

No.	Part No.	Description	Version	QTY.	Remark
1	2409530600300-C	VALVE PUSH ROD		8	
2	2409000600200-C	VALVE TAPPET		8	
3	Q5510822	STRAIGHT KEY		1	
4	2409000600102	CAMSHAFT		1	


RGV3501280000K ENGINE ASSEMBLY-7



RGV3501280000K ENGINE ASSEMBLY-7

No.	Part No.	Description	Version	QTY.	Remark
1	2409000710040	OIL PAN JOINTING PART		1	
2	2409000700104	OIL SUMP GASKET		1	
3	2409530722007	OIL DIPSTICK ASSEMBLY		1	
4	2409530721006	OIL DIPSTICK PIPE		1	
5	2409530730105	OIL GUIDE CLAMP		1	
6	2409000750002	DRAIN PIPE COMPONENTS		1	
7	1408501100301	OIL DRAIN PLUG		1	
8	Q1800816	HEXAGON FLANGE FACE MULTIPLY TOOTHED BOLT		25	
9	ZHD20	COMBINATION GASKET		1	


RGV3501280000K ENGINE ASSEMBLY-8



RGV3501280000K ENGINE ASSEMBLY-8

No.	Part No.	Description	Version	QTY.	Remark
1	2409530800101	EXHAUST PIPE		1	
2	1409023200200	TURBOCHARGER		1	
3	Q40308 (4)	SPRING WASHER		4	
4	2409533301000	LOCKING NUT		4	
5	3408020800800	TURBOCHARGER FIXING BOLT		4	
6	Q1200835	STUD		8	
7	Q340B08	TYPE 1 HEX NUT		8	
8	Q40308 (5)	SPRING WASHER		8	

RGV350128000K ENGINE ASSEMBLY-9



RGV3501280000K ENGINE ASSEMBLY-9

No.	Part No.	Description	Version	QTY.	Remark
1	2409530900302	AIR INLET CONNECTING PIPE		1	
2	2409530900405	AIR INLET CONNECTING PIPE WASHER		1	
3	Q150B0830	HEX HEAD BOLTS		4	
4	2409530900110	INTAKE PIPE		1	
5	Q150B0825 (2)	HEX HEAD BOLTS		8	
6	Q40308 (6)	SPRING WASHER		12	
7	Q40108 (2)	FLAT WASHERS		12	
8	2409533300401	MIDDLE CONNECTING RUBBER PIPE		1	


RGV350128000K ENGINE ASSEMBLY-10



RGV3501280000K ENGINE ASSEMBLY-10

No.	Part No.	Description	Version	QTY.	Remark
1	2409001110001	FILLER CAP		1	
2	2409531110003	CYLINDER COVER PARTS		1	
3	Q1840820(3)	HEX FLANGE BOLTS		10	
4	Q673B23	STEEL PLATE ELASTIC RING		1	
5	2409531120200	RUBBER HOSE		1	
6	2409531110300	CYLINDER COVER SEAL RING		1	


RGV350128000K ENGINE ASSEMBLY-11



RGV350128000K ENGINE ASSEMBLY-11

No.	Part No.	Description	Version	QTY.	Remark
1	2410200204701	COVER		2	
2	2409531201901	HYDRAULIC PUMP WASHER		2	
3	2409531200401	GEAR CHAMBER GASKET		1	
4	2409001200724	GENERATOR BRACKET		1	
5	Q150B1025 (2)	HEX HEAD BOLTS		2	
6	Q40310 (3)	SPRING WASHER		5	
7	1408501800100	OIL INJECTION PUMP CONNECTING PLATE GASKET		1	
8	2409531200300	GEAR CHAMBER		1	
9	2409531200201	GEAR CHAMBER COVER GASKET		1	
10	2409531200101	GEAR CHAMBER COVER		1	
11	2410202300202	GASKET		1	
12	Q340B10	I-TYPE HEX NUT		3	
13	6006	BEARING		2	
14	2409000201605	HYDRAULIC PUMP GEAR		1	
15	Q1840825 (2)	HEX FLANGE BOLTS		2	
15	Q1840820 (4)	HEX FLANGE BOLTS		6	
16	Q5220820 (2)	CYLINDRICAL PIN		2	
17	FB06008012	OIL SEAL		1	
18	Q150B0816	HEX HEAD BOLTS		4	
19	Q150B0840	HEX HEAD BOLTS		2	
19	Q150B0825 (3)	HEX HEAD BOLTS		7	
19	Q150B0865	HEX HEAD BOLTS		4	
19	2409531200500	GEAR ROOM COVER BOLT		2	
20	Q40308 (7)	SPRING WASHER		23	
21	Q40108 (3)	FLAT WASHERS		23	
22	Q1201045	STUD		3	
23	Q150B0820 (3)	HEX HEAD BOLTS		4	
24	2410200204800	COVER		1	
25	2409001200901	TIMING POINTER		1	


RGV3501280000K ENGINE ASSEMBLY-12



RGV3501280000K ENGINE ASSEMBLY-12

No.	Part No.	Description	Version	QTY.	Remark
1	Q174B0612	HEXAGON BOLT WITH CROSS RECESS		2	
2	Q40306	SPRING WASHER		2	
3	Q40106	FLAT WASHERS		2	
4	2409001300400	FLYWHEEL HANDHOLE COVER		1	
5	2409531300107	FLYWHEEL HOUSING		1	
6	Q1201235	STUD		2	
7	Q40312 (2)	SPRING WASHER		8	
8	Q40112	FLAT WASHERS		2	
9	Q340B12	TYPE 1 HEX NUT		2	
10	Q150B1035	HEX HEAD BOLTS		8	
11	Q40310 (4)	SPRING WASHER		8	
12	2410200203100	GAG		1	
13	2409000700922	POSTERIOR RAMUS		2	
14	Q150B1025 (3)	HEX HEAD BOLTS		4	
15	Q40310 (5)	SPRING WASHER		4	


RGV3501280000K ENGINE ASSEMBLY-13



RGV3501280000K ENGINE ASSEMBLY-13

No.	Part No.	Description	Version	QTY.	Remark
1	2409001400015	HIGH PRESSURE OIL PIPE ASSEMBLY		1	
2	2409001400015 (2)	HIGH PRESSURE OIL PIPE ASSEMBLY		1	
3	2409001400015 (3)	HIGH PRESSURE OIL PIPE ASSEMBLY		1	
4	2409001400015 (4)	HIGH PRESSURE OIL PIPE ASSEMBLY		1	
5	3409021450005	DOUBLE HOLE PIPE CLAMP		1	


RGV350128000K ENGINE ASSEMBLY-14



RGV3501280000K ENGINE ASSEMBLY-14

No.	Part No.	Description	Version	QTY.	Remark
1	2409531510003	SUCTION FILTER PARTS		1	
3	Q40306(2)	SPRING WASHER		6	
4	Q40106(2)	FLAT WASHERS		6	
5	Q150B0845	HEX HEAD BOLTS		2	
5	Q150B0850	HEX HEAD BOLTS		2	
5	Q150B08105	HEX HEAD BOLTS		1	
6	2409531500601	OIL FILTER GASKET		1	
15	2409531500003	OIL PUMP ASSEMBLY		1	


RGV3501280000K ENGINE ASSEMBLY-15



RGV3501280000K ENGINE ASSEMBLY-15

No.	Part No.	Description	Version	QTY.	Remark
1	Q150B0820 (4)	HEX HEAD BOLTS		2	
2	Q40308 (8)	SPRING WASHER		4	
3	Q218B0820	HEXAGON SOCKET HEAD CAP SCREW		2	
4	2409531710001	OIL PIPE WELDING PARTS		1	
5	2409531700302	OIL PIPE GASKET		1	
6	2409531700402	GASKET		1	


RGV350128000K ENGINE ASSEMBLY-16



RGV3501280000K ENGINE ASSEMBLY-16

No.	Part No.	Description	Version	QTY.	Remark
1	Q150B0835	HEX HEAD BOLTS		4	
2	Q40308 (9)	SPRING WASHER		8	
3	Q40108 (4)	FLAT WASHERS		4	
4	2410201910017	FAN		1	
5	2409001801320	FAN PAD		1	
6	2409001801502	WATER PUMP BELT PULLEY		1	
7	AV17X1080Li	V-BELT		1	
8	2409531810002	WATER PUMP ASSEMBLY		1	
14	Q150B0885	HEX HEAD BOLTS		1	
15	2409001910000	GENERATOR POLES		1	


RGV350128000K ENGINE ASSEMBLY-17



RGV3501280000K ENGINE ASSEMBLY-17

No.	Part No.	Description	Version	QTY.	Remark
1	2409001900100	THERMOSTAT COVER		1	
2	2409001900203	THERMOSTAT COVER GASKET		1	
3	2409001900404	THERMOSTAT HOUSING GASKET		1	
4	2409001900601	THERMOSTAT HOUSING		1	
5	Q150B0835 (2)	HEX HEAD BOLTS		4	
6	Q150B0830 (2)	HEX HEAD BOLTS		3	
7	2410200140600	WATER TEMPERATURE PLUG		4	
8	Q40308 (10)	SPRING WASHER		7	
9	Q40108 (5)	FLAT WASHERS		7	


RGV350128000K ENGINE ASSEMBLY-18



RGV3501280000K ENGINE ASSEMBLY-18

No.	Part No.	Description	Version	QTY.	Remark
1	2409002110107	OIL INJECTION PUMP		1	
2	2409002130002	PIPE		1	


RGV350128000K ENGINE ASSEMBLY-19



RGV3501280000K ENGINE ASSEMBLY-19

No.	Part No.	Description	Version	QTY.	Remark
1	Q340B10(2)	I-TYPE HEX NUT		1	
2	Q40310(6)	SPRING WASHER		1	
3	Q40110	FLAT WASHERS		1	
4	Q150B10135	HEX HEAD BOLTS		1	
5	Q150B0850(2)	HEX HEAD BOLTS		1	
6	2410202520035	GENERATOR		1	
7	1408501700700	ADJUSTING WASHER		1	
8	Q40308(11)	SPRING WASHER		1	


RGV3501280000K ENGINE ASSEMBLY-20



RGV3501280000K ENGINE ASSEMBLY-20

No.	Part No.	Description	Version	QTY.	Remark
1	1409021510300	OIL RETURN HOSE		3	
2	2409832430000	FILTER OIL OUTPUT PIPE PARTS		1	
3	2409832440000	OIL OUTLET PIPE ASSEMBLY OF OIL CONVEYING PUMP		1	
4	2409002400106	OIL INLET JOINT		1	
5	2409002411072	OIL RETURN PIPE JOINT		1	

RGV350128000K ENGINE ASSEMBLY-21



RGV3501280000K ENGINE ASSEMBLY-21

No.	Part No.	Description	Version	QTY.	Remark
1	2409802500059	FUEL INJECTOR ASSEMBLY KBAL-P035		4	
2	1409022500002	OIL ATOMIZER MAT		4	


RGV3501280000K ENGINE ASSEMBLY-22



RGV3501280000K ENGINE ASSEMBLY-22

No.	Part No.	Description	Version	QTY.	Remark
2.1	2409532610301	Oil filter element		1	
2	2409832610000	OIL FILTER PARTS		1	
3	Q40310 (7)	SPRING WASHER		2	
4	Q40110 (2)	FLAT WASHERS		2	
5	Q150B1075	HEX HEAD BOLTS		1	
6	Q150B1095	HEX HEAD BOLTS		1	


RGV350128000K ENGINE ASSEMBLY-23



RGV3501280000K ENGINE ASSEMBLY-23

No.	Part No.	Description	Version	QTY.	Remark
5.1	1408502810102	Fine fuel filter element		1	
1	Q150B0825 (4)	HEX HEAD BOLTS		2	
2	Q340B08 (2)	TYPE 1 HEX NUT		2	
3	Q150B0830 (3)	HEX HEAD BOLTS		2	
4	2409532800100	BRACKET		1	
5	1408502810001	FUEL FILTER		1	
6	Q40308 (12)	SPRING WASHER		4	
7	Q40108 (6)	FLAT WASHERS		4	


RGV3501280000K ENGINE ASSEMBLY-24



RGV350128000K ENGINE ASSEMBLY-24

No.	Part No.	Description	Version	QTY.	Remark
1	2409003010052	STARTING MOTOR		1	


RGV3501280000K ENGINE ASSEMBLY-25



RGV3501280000K ENGINE ASSEMBLY-25

No.	Part No.	Description	Version	QTY.	Remark
1	Q218B0820 (2)	HEXAGON SOCKET HEAD CAP SCREW		2	
2	Q40308 (13)	SPRING WASHER		2	
3	Q40108 (7)	FLAT WASHERS		2	
4	2409533310003	TURBOCHARGER		1	
5	1409023220500	TURBOCHARGER RETURN OIL PIPE JOINT GASKET		1	
6	Q40300	SPRING WASHER		2	
7	Q40106 (3)	FLAT WASHERS		2	
8	Q150B0620	HEX HEAD BOLTS		2	
9	2409533300300	TURBOCHARGER RETURN LINE I I		1	
10	3408523220300	OIL RETURN RUBBER HOSE		1	
11	2409533300200	TURBOCHARGER RETURN LINE I		1	
12	1409023220402	TURBOCHARGER RETURN OIL PIPE JOINT GASKET		1	
13	1409023200300	TURBOCHARGER EXHAUST JOINT PIPE GASKET		1	
14	ZHD10	COMBINATION GASKET		2	
15	1409023210100	THE OIL INLET PIPE JOINT SCREW		1	
16	2409533300103	OIL INLET PIPE OF TURBOCHARGER		1	
17	2409530800424	EXHAUST JOINT PIPE		1	
18	2409000800304	EXHAUST NOZZLE RETAINING BOLT		3	
19	2409530800502	EXHAUST PIPE GASKET		2	
20	1409023210200	THE OIL INLET PIPE JOINT SCREW		1	
21	JB6013-DQ12	WASHER 12		2	
25	Q150B0825 (5)	HEX HEAD BOLTS		5	
26	Q40308 (14)	SPRING WASHER		5	
27	2409533301100	SUPERCHARGER COVER		1	


RGV350128000K ENGINE ASSEMBLY-26



RGV3501280000K ENGINE ASSEMBLY-26

No.	Part No.	Description	Version	QTY.	Remark
1	2409531120102	OIL GAS SEPARATOR SUPPORT		1	
2	2409531120204	RUBBER PIPE		1	
3	1409020100900	OIL-GAS SEPARATOR		1	
4	Q1840625	HEX FLANGE BOLTS		2	
5	4408021100500	OIL-GAS SEPARATOR OIL RETURN RUBBER HOSE		1	
6	Q1840816	HEX FLANGE BOLTS		2	

RGV350128000K ENGINE ASSEMBLY-27



RGV350128000K ENGINE ASSEMBLY-27

No.	Part No.	Description	Version	QTY.	Remark
1	2409833700101	OIL COOLER GASKET		1	
2	2409833710000	OIL COOLER		1	
3	Q150B0835 (3)	HEX HEAD BOLTS		6	
3	Q150B0825 (6)	HEX HEAD BOLTS		2	
3	Q150B0855 (2)	HEX HEAD BOLTS		1	
4	Q40308 (15)	SPRING WASHER		9	
5	2409000101402	DRAIN VALVE BLOCK		1	
6	2409000103702	DRAIN VALVE BLOCK		1	
7	2409000103800	WATER RELEASE SWITCH HOSE		1	
8	Q676B19	C-TYPE WORM TRANSMISSION HOSE CLAMP		1	